

Beafon Flexy 2F (BEASH-2F-W)

Beafon Flexy 2F Smart Home Indoor Surveillance Camera

Model: FLEXY 2F (BEASH-2F-W)

1. INTRODUCTION

The Beafon Flexy 2F is a smart indoor surveillance camera designed to provide comprehensive monitoring for your home or office. Featuring a 3MP Super HD resolution, 360° flexible orientation with a magnetic base, and a 110° wide-angle lens, it offers clear and extensive coverage. This manual provides detailed instructions for setting up, operating, and maintaining your Flexy 2F camera.

2. WHAT'S IN THE BOX

Please check the package contents to ensure all items are present:

- Beafon Flexy 2F Camera
- USB Type-C Cable (2m)
- Power Adapter/Charger
- Adhesive Pad
- User Manual

3. PRODUCT OVERVIEW

Familiarize yourself with the components of your Beafon Flexy 2F camera.



bea-fon

Figure 3.1: Front view of the Beafon Flexy 2F camera, showing the lens and the Beafon logo.





Figure 3.2: Side view of the Beafon Flexy 2F camera, highlighting its compact design.





Figure 3.3: Back view of the Beafon Flexy 2F camera, showing the speaker grille and the 'PUSH' button for accessing the Micro SD card slot.



Figure 3.4: Diagram illustrating the dimensions of the Beafon Flexy 2F camera: 88mm height, 55mm width, and 45mm depth.

4. SETUP

4.1 Powering On

1. Connect the USB Type-C cable to the camera's power port.
2. Plug the other end of the cable into the provided power adapter.

3. Plug the power adapter into a wall outlet. The camera will power on and indicate readiness for setup (e.g., a blinking LED).

4.2 App Installation and Account Creation

1. Download the official Beafon Smart Home app from your smartphone's app store (iOS App Store or Google Play Store).
2. Open the app and follow the on-screen instructions to create a new account or log in if you already have one.

4.3 Connecting to Wi-Fi

1. In the Beafon app, tap on "Add Device" or the '+' icon.
2. Select the Flexy 2F camera from the list of available devices.
3. Follow the app's instructions to connect the camera to your Wi-Fi network. The Flexy 2F supports both 2.4 GHz and 5 GHz Wi-Fi bands.
4. Ensure your Wi-Fi password is entered correctly.

4.4 Micro SD Card Installation (Optional)

To enable local video recording, you can install a Micro SD card (up to 128 GB, not included).

1. Locate the Micro SD card slot on the back of the camera (behind the 'PUSH' cover).
2. Gently push the cover to open the slot.
3. Insert the Micro SD card into the slot with the gold contacts facing down until it clicks into place.
4. Close the cover.

4.5 Mounting the Camera

The Flexy 2F features a magnetic base for flexible placement.

- **Tabletop Placement:** Simply place the camera on any flat surface. The magnetic base allows for easy adjustment of the camera's angle.
- **Wall/Ceiling Mounting:** Use the included adhesive pad to secure the camera to a clean, flat surface. Ensure the surface is suitable for adhesion. The magnetic base allows for 360° rotation and flexible positioning after mounting.

5. OPERATING INSTRUCTIONS

5.1 Live View

Once connected, open the Beafon app and select your Flexy 2F camera to view the live feed. You can pan and tilt the camera view within the app to utilize its 360° flexible orientation and 110° wide-angle lens.

5.2 Two-Way Audio

The camera supports two-way audio communication. Tap the microphone icon in the app to speak through the camera's speaker, and listen to audio from the camera's built-in microphone.

5.3 Motion Detection and Alarms

The Flexy 2F features automatic motion detection. When motion is detected, the camera can trigger an alarm and send push notifications to your smartphone. Configure motion detection sensitivity and notification settings within the

app.

5.4 Night Vision

The camera automatically switches to night vision mode in low-light conditions, utilizing its infrared sensor to provide clear video up to 10 meters. This ensures continuous surveillance day and night.

5.5 Recording and Playback

If a Micro SD card is installed, the camera will record events based on your settings (e.g., continuous recording, motion-triggered recording). You can access and play back recorded footage directly from the Beafon app.

6. MAINTENANCE

6.1 Cleaning

To clean the camera, gently wipe the lens and body with a soft, dry cloth. Do not use liquid cleaners or abrasive materials, as they may damage the camera.

6.2 Software Updates

Periodically check the Beafon app for firmware updates for your camera. Keeping the firmware updated ensures optimal performance and access to new features.

7. TROUBLESHOOTING

- **Camera not connecting to Wi-Fi:** Ensure your Wi-Fi password is correct. Verify that your router is broadcasting on a supported frequency (2.4 GHz or 5 GHz). Move the camera closer to the router to improve signal strength.
- **No live view:** Check the camera's power connection. Ensure your internet connection is stable. Restart the camera and the Beafon app.
- **Poor video quality:** Ensure the camera lens is clean. Check your Wi-Fi signal strength; a weak signal can affect video quality.
- **Motion detection not working:** Verify that motion detection is enabled in the app settings. Adjust sensitivity levels if necessary. Ensure there are no obstructions blocking the camera's view.
- **Micro SD card not recognized:** Ensure the Micro SD card is inserted correctly. Format the Micro SD card through the app settings if it's a new card or if issues persist.

8. SPECIFICATIONS

Feature	Specification
Model Name	FLEXY 2F
Model Number	BEASH-2F-W
Video Resolution	3 Megapixels (Super HD)


Feature	Specification
Viewing Angle	110 degrees
Night Vision Range	Up to 10 meters
Wireless Technology	Wi-Fi (2.4G and 5G)
Two-Way Audio	Yes
Motion Detection	Yes, with automatic alarm trigger
Storage	Micro SD card slot (up to 128 GB, not included)
Power	5 Watts (via 2m USB Type-C cable)
Dimensions (L x W x H)	5.5 x 4.5 x 8.8 cm
Weight	91 grams
Material	Metal
Color	White/Black
Mounting Type	Table Mount (flexible magnetic base)
Recommended Use	Indoor Surveillance, Motion Detection
Compatible Devices	Tablet, Smartphone
Controller Type	Beafon Application




9. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the official Beafon website or contact Beafon customer service directly. Details regarding spare parts availability are not provided in this manual.

© 2024 Beafon. All rights reserved.

Related Documents - Flexy 2F (BEASH-2F-W)

	<p>Beafon SL495 Silver Line Mobile Phone - Specifications and Features</p> <p>Detailed overview of the Beafon SL495 Silver Line mobile phone, including its specifications, functions, safety features, and package contents. This document provides comprehensive information for potential users.</p>
---	---

	<p>Beaon SL860 Silver Line Mobile Phone - Features and Specifications</p> <p>Detailed specifications for the Beaon SL860 Silver Line mobile phone, including 4G LTE, WhatsApp, SOS functions, camera details, and multimedia capabilities. Learn about its user interface, display, and connectivity options.</p>
	<p>Ewon Device Cybersecurity and Firmware Update Guidance</p> <p>Guidance on updating Ewon device firmware for enhanced cybersecurity, securing physical access, managing user permissions, and accessing technical documentation from WACHENDORFF and HMS Networks.</p>
	<p>GeoVision GV-IPCam Hardware Manual</p> <p>Comprehensive hardware manual for GeoVision GV-IPCam series network cameras, covering installation, features, and specifications for various models including Mini Fixed Dome, Mini Fixed Rugged Dome, Target Mini Fixed Dome, Target Mini Fixed Rugged Dome, Cube Camera, and Advanced Cube Camera.</p>
	<p>Mitsubishi Heavy Industries Air Conditioner Dimensions and Installation Guide</p> <p>Detailed installation dimensions, specifications, and notes for Mitsubishi Heavy Industries SRK, DXK, and SRC series indoor and outdoor air conditioning units.</p>
	<p>Hugolog Indoor Security Cameras User Manual</p> <p>User manual for Hugolog indoor security cameras, detailing features like 4K resolution, AI sound processing, night vision, and Alexa compatibility for baby, pet, and home monitoring. Includes setup guidance and model specifications.</p>



[pdf] User Manual

bea fon Smarthome FLEXY 2F Manual GESAMT LAY indd Bedienungsanleitung Bea fon Flex ab € 49 41
2025 Preisvergleich Geizhals Österreich 4eaa9b30d5e7cc32bf7e63489b143ede4cbe gzhls at blob ldb 1
0 d c |||
Smart H me FLEXY 2F Deutsch S. 2-18 English P. 19-34 Espao P. 35-50 Italiano P.
51-66 Franais P. 67-82 Dutch P. 83-98 eafon_Smarthome_FLEXY
2F_Manual_GESAMT-LAY.indd 1 27.04.23 14:58 Smart H me FLEXY 2F
Bedienungsanleitung eafon_Smarthome_FLEXY 2F_Manual_GESAMT-LAY.indd 2
27.04.23 14:...
lang:de score:43 filesize: 6.47 M page_count: 98 document date: 2023-04-27



[pdf] Declaration of Conformity

Becker Florian KONFORMITÄTSERKLÄRUNG DOC DE bea fon Modell FLEXY 2F BEASH W Mini 18T
Artikelbeschreibung ETSI EN 301 489 3 V2 0 2022 07 17 V3 2 4 2020 09 71T5aNvNhL ref dp product
quick view m media amazon images l |||
KONFORMITTSEKLRUNG DOC DE Hersteller: Importeur: Website: Modell:
Artikelbeschreibung: Bea-fon Mobile GmbH Enzing 4, 4722 Peuerbach, Austria Bea-
fon Mobile GmbH www.bea-fon.com; FLEXY 2F / BEASH-2F-W / Mini 18T IP battery
Camera Shenzhen Global Test Service Co.,Ltd Add: No. 7-101 and 8A-104, Bu...
lang:de score:26 filesize: 157.02 K page_count: 1 document date: 2023-04-18