

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [AMIPEPE](#) /

› [AMIPEPE Smart LED Christmas Cone Tree Light 7.5ft \(Model SW-LSL-30-300\) User Manual](#)

AMIPEPE SW-LSL-30-300

AMIPEPE Smart LED Christmas Cone Tree Light 7.5ft User Manual

Model: SW-LSL-30-300

1. INTRODUCTION

Thank you for choosing the AMIPEPE Smart LED Christmas Cone Tree Light. This 7.5-foot cone tree features 310 RGB LEDs, a star topper, and offers a wide range of customizable lighting options. Control is available via a dedicated smartphone application and an included remote control. Enjoy music synchronization, various scene modes, and timer functions to enhance your indoor or outdoor holiday decorations.



Figure 1: AMIPEPE Smart LED Christmas Cone Tree Light in operation.

2. PACKAGE CONTENTS

Please verify that all components are present before assembly:

- LED Cone Tree Light (7.5ft, 310 LEDs)
- Star Topper
- Base Frame Components
- Central Pole Sections
- Ground Stakes
- Power Adapter
- Remote Control
- User Manual



Figure 2: Included components of the LED Cone Tree Light.

3. SETUP AND ASSEMBLY

Follow these steps to assemble your AMIPEPE Smart LED Christmas Cone Tree Light:

1. **Assemble the Base:** Connect the curved base sections to form a complete circle. Ensure they are securely interlocked.
2. **Attach Base Supports:** Insert the straight support pieces into the central hub of the base, creating a stable star-shaped foundation.
3. **Assemble the Central Pole:** Connect the central pole sections by twisting them together until they are firm.
4. **Attach Star Topper:** Place the star topper onto the top of the assembled central pole.
5. **Connect LED Strings to Base:** Carefully uncoil the LED light strings. Attach the bottom end of each string to the corresponding hooks on the base frame. The strings should hang down from the star topper.
6. **Secure to Ground (Outdoor Use):** For outdoor installation, use the provided ground stakes to firmly secure the base to the ground, preventing tipping in windy conditions.

7. **Connect Power:** Plug the power adapter into a suitable outdoor-rated power outlet.



Figure 3: Visual guide for tree assembly.

Assembly Video Guide

Video 1: Step-by-step assembly instructions for the Smart Christmas Cone Tree LED Light.

4. OPERATING INSTRUCTIONS

The AMIPEPE Smart LED Christmas Cone Tree Light can be controlled via a smartphone application or the included remote control.

4.1. Smartphone App Control

Download the companion app (e.g., "Symphony Controller" or similar, refer to packaging for exact app name and QR code) from your device's app store. Once installed, enable Bluetooth on your smartphone and open the app. The app will guide you through connecting to your LED tree light. The app provides comprehensive control over:

- **Color Selection:** Choose from 16 million RGB colors.

- **DIY Lighting:** Create custom lighting patterns and sequences for each individual LED.
- **Scene Modes:** Select from multiple pre-set and customizable scene modes.
- **Music Sync:** Synchronize light effects with music played through your phone's microphone.
- **Timer Function:** Schedule automatic on/off times.
- **Brightness Adjustment:** Adjust the intensity of the lights (1%-100%).
- **Speed Adjustment:** Control the speed of dynamic lighting effects.
- **Group Control:** Control multiple AMIPEPE cone tree lights simultaneously.



Figure 4: Smartphone app interface for controlling the lights.

4.2. Remote Control

The included remote control offers quick access to essential functions:

- **ON/OFF:** Power the lights on or off.
- **Brightness/Speed:** Adjust brightness levels and effect speed.
- **Static Colors:** Select from 7 static colors or RGB cycling.
- **Loop Mode:** Cycle through various pre-set effects.
- **Dynamic Effects:** Choose from fading, flowing, and circular patterns.

- **Scene Modes (S1-S4):** Activate pre-programmed scenes.
- **Music Modes (1-4):** Activate music synchronization effects.
- **Timer:** Set 30-minute or 1-hour delay off timers.




Figure 5: Remote control functions.

4.3. General Operation Overview

Video 2: Overview of the Smart LED Christmas Cone Tree Lights features, including app and remote control, DIY modes, music sync, and timer functions.

5. MAINTENANCE

- **Cleaning:** Gently wipe the LED strings and frame with a soft, dry cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** When not in use, carefully disassemble the tree and coil the LED strings. Store all components in their original packaging or a protective container in a cool, dry place away from direct sunlight.
- **Inspection:** Before each use, inspect the power cord, adapter, and LED strings for any signs of damage. Do not use if any part is damaged.

- **Water Resistance:** The product is rated IP44 waterproof, suitable for outdoor use in light rain. However, avoid submerging the product in water or exposing it to heavy downpours for extended periods. Ensure the power adapter connection is protected from moisture.



Figure 6: The LED cone tree light is IP44 waterproof.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Lights do not turn on.	No power, loose connection, faulty adapter.	Check power outlet, ensure all connections are secure, try a different outlet. Verify power adapter is functioning.
Some LED strings or individual LEDs are not working or display incorrect colors.	Damaged LED string, loose connection within the string, internal component failure.	Inspect the affected string for visible damage or loose connections. If a specific strand is consistently malfunctioning, contact customer support for assistance.

Problem	Possible Cause	Solution
Remote control is not responding.	Dead battery, remote out of range, obstruction.	Replace the remote control battery. Ensure you are within range and there are no obstructions between the remote and the tree's receiver.
App cannot connect to the device.	Bluetooth off, app not updated, device not powered on.	Ensure Bluetooth is enabled on your smartphone. Verify the tree light is powered on. Restart the app and try connecting again. Ensure the app is updated to the latest version.
Lights are flickering or behaving erratically.	Unstable power supply, loose connection, interference.	Ensure the power supply is stable. Check all connections. Try moving the tree away from other electronic devices that might cause interference.

7. SPECIFICATIONS

Feature	Detail
Model Number	SW-LSL-30-300
Height	7.5 feet
Number of LEDs	310 RGB LEDs
Color Options	16 Million Colors (RGB)
Control Methods	Bluetooth App, Remote Control
Special Features	DIY Patterns, Music Sync, Built-in Scenes, Dimmable, Group Control
Power Source	Corded Electric
Material	Metal, Polyvinyl Chloride
Waterproof Rating	IP44
Item Weight	4.44 pounds
Manufacturer	Shenzhen Starway Photoelectric Technology Co, Ltd

8. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product packaging or contact AMIPEPE customer service directly. Keep your purchase receipt for any warranty claims.