

FACETEL Q10

FACETEL Q10 10-inch Android 13 Tablet User Manual

Model: Q10

1. INTRODUCTION

This manual provides instructions for the FACETEL Q10 10-inch Android 13 Tablet. It covers initial setup, operation, maintenance, troubleshooting, and product specifications to ensure optimal use of your device.

2. PACKAGE CONTENTS

Verify that all items are present in the package:

- FACETEL Q10 Tablet
- Bluetooth Keyboard
- Wireless Mouse
- Charger
- Data Cable (USB-C)
- USB-A to USB-C Adapter (for mouse dongle)



Image: FACETEL Q10 Tablet with its accessories, including a keyboard, mouse, charger, and cables.

3. SETUP

3.1 Charging the Tablet

Before first use, fully charge the tablet. Connect the provided charger to the tablet's USB Type-C port and plug it into a power outlet.



Image: Close-up of the tablet's side, highlighting the USB Type-C charging port and the 3.5mm headphone jack.

3.2 Powering On/Off

- **To Power On:** Press and hold the Power button located on the side of the tablet until the screen illuminates.
- **To Power Off:** Press and hold the Power button, then select "Power off" from the options that appear on the screen.
- **To Restart:** Press and hold the Power button, then select "Restart" from the options.

3.3 Initial Android Setup

Upon first power-on, follow the on-screen prompts to complete the initial Android 13 setup. This includes selecting your language, connecting to a Wi-Fi network, and signing in with your Google account (optional, but recommended for app access).



Image: A visual representation of the Android 13 operating system interface, showing multiple application icons and improved privacy features.

3.4 Connecting Accessories (Keyboard & Mouse)

- **Bluetooth Keyboard:**
 1. Ensure the keyboard is charged and powered on.
 2. On your tablet, go to **Settings > Connected devices > Bluetooth**.
 3. Turn on Bluetooth and scan for available devices.
 4. Select the keyboard from the list and follow any pairing instructions.

- **Wireless Mouse:**

1. Insert the USB-A dongle from the mouse into the provided USB-A to USB-C adapter.
2. Plug the adapter into the tablet's USB Type-C port.
3. Ensure the mouse has batteries and is powered on. The tablet should automatically detect the mouse.

Note: The tablet has only one USB-C port. Using the mouse via the adapter will occupy this port, preventing simultaneous charging or use of other USB-C peripherals.

4. OPERATING YOUR TABLET

4.1 Display and Navigation

The tablet features a 10.1-inch IPS display with a resolution of 1280x800 pixels. Navigate the interface using touch gestures (tap, swipe, pinch-to-zoom).




Image: The tablet screen showcasing vibrant, high-definition visuals, emphasizing the 10.1-inch display.

4.2 Performance and Storage

The tablet is equipped with an Octa-Core 2.0 GHz processor and 14GB RAM (8GB physical + 6GB extended virtual RAM) for smooth operation. It includes 128GB of internal storage (ROM), expandable up to 1TB using a microSD (TF) card.



Image: A diagram highlighting the tablet's Octa-Core processor and its 2.0GHz operating frequency, indicating high performance.



14(6+8)GB 1TB Extension

Everything you love has a place in it

The tablet's 128GB internal memory allows you to store all your entertainment (videos, games, photos, etc.). You can also expand the storage space up to 1TB with a microSD card

Image: An illustration detailing the tablet's memory configuration: 14GB RAM, 128GB internal storage, and support for up to 1TB expandable memory.

4.3 Connectivity

- **Wi-Fi:** Supports dual-band 2.4GHz and 5GHz Wi-Fi for stable and fast internet access. Connect via **Settings > Network & internet > Wi-Fi**.
- **Bluetooth 5.0:** For connecting wireless headphones, speakers, and other Bluetooth-enabled devices. Access via **Settings > Connected devices > Bluetooth**.

Stable WiFi connection

The tablet supports connections to the stable and fast 2.4G+5G WiFi stable and fast, which offers higher speeds and lower latency. Energy-efficient Bluetooth 5.0 makes it easy to connect wireless headphones, so you can enjoy the great sound of wireless headphones.



 **2.4G+5G WiFi**
Enhanced compatibility

 **Bluetooth 5.0**
Ultra-fast transfer

Image: A visual representation of the tablet's stable 2.4G+5G Wi-Fi and Bluetooth 5.0 capabilities, indicating enhanced compatibility and ultra-fast transfer speeds.

4.4 Camera Functions

The tablet features an 8MP rear camera and a 5MP front camera. Use the pre-installed Camera application to capture photos and videos.




Image: A depiction of the tablet's 8MP rear camera and 5MP front camera, illustrating their use for capturing portraits and scenes.

4.5 Battery Management

The 8000mAh battery provides extended usage. Battery life estimates:

- Gaming: Approximately 4-6 hours
- HD Video Playback: Approximately 4.5-7 hours
- Web Browsing: Approximately 6-9 hours
- Music Playback: Approximately 15-18 hours
- Call Time: Approximately 20-26 hours
- Standby Time: Approximately 36 hours

To optimize battery life, reduce screen brightness, close unused applications, and disable Wi-Fi/Bluetooth when not in use.




Image: The tablet screen showing a battery charging indicator and the prominent display of "8000mAh", signifying its high-capacity battery.

4.6 Audio

The tablet is equipped with two speakers for ambient stereo sound and a 3.5mm headphone jack for private listening.

4.7 Wireless Screen Projection

You can project your tablet's screen wirelessly to a compatible TV or display. Refer to your TV's manual for instructions on enabling screen mirroring or casting, then access this feature from your tablet's quick settings panel or display settings.




Image: A tablet wirelessly displaying its content on a larger television screen, demonstrating the screen projection feature.

5. MAINTENANCE

- **Cleaning:** Use a soft, lint-free cloth to clean the screen and body of the tablet. Avoid abrasive cleaners or solvents.
- **Storage:** Store the tablet in a cool, dry place away from direct sunlight and extreme temperatures.
- **Software Updates:** Periodically check for system updates via **Settings > System > System update** to ensure optimal performance and security.
- **Data Backup:** Regularly back up important data to cloud storage or an external device to prevent data loss.

6. TROUBLESHOOTING

6.1 Common Issues and Solutions

- **Tablet does not power on:**

Ensure the tablet is sufficiently charged. Connect the charger and wait a few minutes before attempting to power on again.
- **Slow performance or freezing:**

Close unused applications. Restart the tablet. Clear cache data for frequently used apps. Consider performing a factory reset if issues persist (backup data first).
- **Wi-Fi connectivity issues:**

Ensure Wi-Fi is enabled. Restart your router and the tablet. Forget the network and reconnect. Check if other devices can connect to the same Wi-Fi network.
- **Short battery life:**

Adjust screen brightness. Disable Wi-Fi, Bluetooth, and GPS when not in use. Close background applications. Some users report that fully draining the battery and then fully charging it can help calibrate the battery meter.
- **Mouse not responding:**

Ensure the mouse has fresh batteries and is powered on. Verify the USB-A dongle is securely inserted into the USB-C adapter, and the adapter is firmly connected to the tablet's USB-C port.

- **"Corrupted" message or software issues:**

If you encounter messages about corrupted software or persistent system errors, a factory reset may be necessary. Navigate to **Settings > System > Reset options > Erase all data (factory reset)**. **Warning: This will delete all data on your tablet.** If the issue persists after a factory reset, contact customer support.

7. SPECIFICATIONS

Feature	Detail
Model Name	Q10
Operating System	Android 13
Processor	Octa-Core, 2.0 GHz (ARM)
RAM	14 GB (8GB physical + 6GB extended)
Internal Storage (ROM)	128 GB
Expandable Storage	Up to 1 TB (via TF/microSD card)
Screen Size	10.1 Inches
Screen Resolution	1280 x 800 Pixels (IPS)
Rear Camera	8 MP
Front Camera	5 MP
Battery Capacity	8000 mAh (Lithium Polymer)
Average Battery Life	Up to 26.67 hours (usage dependent)
Wireless Connectivity	5G Wi-Fi (2.4G + 5G), Bluetooth 5.0
Ports	USB Type-C, 3.5mm Headphone Jack
Dimensions (LxWxH)	9.6 x 5.98 x 0.3 inches
Item Weight	2.75 pounds

FACETEL Q10 Tablet Android 13



Image: An infographic summarizing key specifications of the FACETEL Q10 Tablet, including dimensions, screen resolution, connectivity, camera, battery, RAM, and storage.

8. WARRANTY AND SUPPORT

FACETEL provides lifelong technical support services for its products. If you encounter any issues with your FACETEL Q10 Tablet, please contact seller support promptly.

- **Technical Support:** Lifelong technical support is available.
- **Response Time:** Customer messages are typically replied to within 24 hours.
- **Contact:** For product issues or support, please reach out to the seller directly through your purchase platform.