

## Goshyda GOSHYDAztkn0grvai

# Goshyda PC Receiver Gaming Controller Adapter Console for 360 Instruction Manual

## 1. INTRODUCTION

---

This manual provides detailed instructions for the installation, operation, and maintenance of your Goshyda PC Receiver Gaming Controller Adapter. This device allows you to connect up to four wireless Xbox 360 controllers and four wireless headsets to your PC, enhancing your gaming experience with seamless integration.

The receiver features a robust ABS construction, a USB interface for easy connection, and comes with a driver CD for straightforward setup.

## 2. PACKAGE CONTENTS

---

Please verify that all items listed below are included in your package:

- 1 x Goshyda PC Receiver Gaming Controller Adapter
- 1 x PC Driver CD

## 3. SETUP

---

Follow these steps to set up your Goshyda PC Receiver:

1. **Connect the Receiver:** Plug the USB connector of the Goshyda PC Receiver into an available USB port on your computer.
2. **Install Drivers:** Insert the included PC Driver CD into your computer's CD-ROM drive. Follow the on-screen instructions to install the necessary drivers. If your computer does not have a CD-ROM drive, drivers may be available for download from the manufacturer's support website.
3. **Pair Controllers/Headsets:** Once the drivers are installed, press the sync button on the PC Receiver. Then, activate the pairing mode on your wireless Xbox 360 controller or headset. The devices will connect automatically using the same binding technology as the Xbox 360 console. You can connect up to four controllers and four headsets simultaneously.



The Goshyda PC Receiver, featuring its compact black design and integrated USB cable for connecting to a computer.

## Including CD-ROM driver

High quality ABS material  
long lasting  
Small and light weight  
Easy to carry around



The Goshyda PC Receiver is shown with the accompanying CD-ROM, which contains the necessary drivers for installation on your computer.

## Gaming Receiver



A detailed view of the PC Receiver's sync button and status indicator lights, used for pairing devices.

### 4. OPERATING INSTRUCTIONS

---

Once the Goshyda PC Receiver is set up and your controllers/headsets are paired, you can begin using them for PC gaming.

- **Automatic Recognition:** Your PC should automatically recognize the connected controllers and headsets as standard Xbox 360 input devices.
- **Game Compatibility:** Most PC games that support Xbox 360 controllers will work seamlessly with the connected devices.
- **Multiple Devices:** Enjoy multiplayer gaming or use multiple headsets with support for up to four controllers and four headsets simultaneously.

# Easily integrate with PC game scenes

Use up to four wireless controllers and four wireless headsets at the same time.



This image shows the Goshyda PC Receiver connected, highlighting its capability to integrate seamlessly with PC gaming environments for wireless controllers and headsets.

## 5. MAINTENANCE

---

To ensure the longevity and optimal performance of your Goshyda PC Receiver, follow these simple maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe the surface of the receiver. Avoid using liquid cleaners or abrasive materials.
- **Storage:** Store the receiver in a cool, dry place away from direct sunlight and extreme temperatures when not in use.
- **Handling:** Avoid dropping the device or subjecting it to strong impacts. Do not attempt to disassemble the receiver.

## 6. TROUBLESHOOTING

---

If you encounter issues with your Goshyda PC Receiver, please refer to the following common solutions:

- **Device Not Recognized:**

- Ensure the receiver is securely plugged into a working USB port.
  - Verify that the drivers have been installed correctly from the included CD. Reinstall if necessary.
  - Try connecting the receiver to a different USB port on your PC.
- **Controllers/Headsets Not Pairing:**
    - Make sure the receiver's sync button has been pressed and its indicator light is active.
    - Ensure your controller/headset is in pairing mode. Refer to your controller/headset's manual for specific instructions.
    - Check that the controller/headset has sufficient battery power.
  - **Intermittent Connection:**
    - Ensure there are no significant obstructions between the receiver and your wireless devices.
    - Avoid placing the receiver near other wireless devices or sources of electromagnetic interference.

## 7. SPECIFICATIONS

---

Feature	Specification
Item Type	PC Receiver
Material	ABS
Color	Black
Vibration Mode	No Vibration (Receiver Function)
Interface	USB Type B
Cable Length	Approx. 1.6m (1.7yd)
Applicable Model	For Xbox 360 Wireless Controllers/Headsets
Max Connected Devices	4 Controllers, 4 Headsets
Model Number	GOSHYDAztkn0grvai
Item Weight	100 Grams

## 8. WARRANTY INFORMATION

---

This Goshyda PC Receiver Gaming Controller Adapter comes with a limited warranty. Please retain your proof of purchase for any warranty claims. For specific terms and conditions of the warranty, refer to the documentation provided at the time of purchase or contact Goshyda customer support.

## 9. SUPPORT

---

If you require further assistance or have questions not covered in this manual, please contact Goshyda customer support. Contact information can typically be found on the product packaging or the official Goshyda website.

