

[Manuals.plus](#) /

> [Diydeg](#) /

> Diydeg Pitcher Rinser Instruction Manual

## Diydeg Diydeg6ugxh4g29d-11

# Diydeg Pitcher Rinser Instruction Manual

Model: Diydeg6ugxh4g29d-11



## INTRODUCTION

---

The Diydeg Pitcher Rinser is a stainless steel countertop cup washer designed for efficient and hygienic rinsing of various beverage containers. It utilizes high-pressure water jets to quickly clean pitchers, cups, and glasses, making it ideal for home kitchens, cafes, bars, and restaurants. This manual provides detailed instructions for installation, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your rinser.



For restaurants, bars, coffee shops and  
cafes

Quickly rinse shot glasses, pitchers and  
cups in just seconds

Image: The Diydeg Pitcher Rinser integrated into a bar countertop, demonstrating its use for quick glass rinsing.

## SETUP AND INSTALLATION

---

Before installation, ensure all components are present and undamaged. The rinser is designed for easy integration into standard kitchen countertops or sink holes.

### Included Components:

- Pitcher Rinser Unit (Stainless Steel Tray with Rinser Mechanism)
- Drain Assembly
- Water Inlet Hose
- Water Outlet Hose



Image: A complete view of the Diydeg Pitcher Rinser components, including the main unit, drip tray, and connection hoses.

### Installation Steps:

- 1. Prepare Countertop:** Identify a suitable location on your countertop or sink. Ensure there is adequate space for the rinser unit (dimensions: 32.5cm x 17.7cm x 4cm). A standard kitchen countertop or sink hole can be used for installation.
- 2. Insert Rinser Unit:** Place the stainless steel rinser unit into the prepared opening. Ensure it sits flush with the countertop surface.
- 3. Connect Water Inlet:** Locate the water inlet connection on the underside of the rinser. Attach the provided water inlet hose to this connection. Connect the other end of the hose to a cold water supply line. Ensure all connections are tight to prevent leaks.
- 4. Connect Drain:** Attach the drain assembly to the drain outlet on the underside of the rinser. Connect the drain

hose to a suitable drainage system, such as a sink drain or a dedicated waste line.

5. **Test for Leaks:** Once all connections are secure, slowly turn on the water supply and check for any leaks around the connections. Tighten any leaking connections as necessary.



Image: An illustrative diagram detailing the connection points for water supply and drainage on the rinser unit.

## OPERATING INSTRUCTIONS

The Diydeg Pitcher Rinser operates without external power, using water pressure to activate the rinsing mechanism.

### How to Use:

1. **Position Container:** Place the pitcher, cup, or glass upside down over the star-shaped base of the rinser.
2. **Activate Rinser:** Gently press the rim of the container down onto the star-shaped base. This action will engage the high-pressure water jets.
3. **Rinse:** Water will spray from multiple angles, thoroughly rinsing the interior of the container. Continue pressing for 1-3 seconds, or until the container is clean.
4. **Release:** Lift the container from the base. The water spray will automatically stop.

The multi-angle outlet water ensures comprehensive cleaning, effectively removing milk deposits, coffee residues, and other debris from various types of drinkware, including bar utensils, coffee cups, beer cups, milk cartons, and teacups.

Video: A short demonstration of the Diydeg Pitcher Rinser in action, showing how to press a cup onto the star-shaped base to activate the water spray for quick rinsing.



Image: A detailed view of the rinser's star-shaped base and the central nozzle, which delivers multi-angle water for effective cleaning.

## MAINTENANCE

---

Regular cleaning and maintenance will ensure the longevity and optimal performance of your Diydeg Pitcher Rinser.

### Cleaning Instructions:

- **Daily Cleaning:** After each use, wipe down the stainless steel surface and the drip tray with a soft cloth and mild detergent. Rinse thoroughly with water.
- **Drip Tray:** The perforated drip tray is removable for easy cleaning. Lift the tray and clean any accumulated debris or water stains.
- **Rinser Nozzle:** Periodically check the rinser nozzle for any mineral buildup or blockages. If necessary, use a small brush or toothpick to clear the spray holes.
- **Material Care:** The rinser is made of 304 stainless steel, which is resistant to water and fingerprints. Avoid using abrasive cleaners or scouring pads that could scratch the polished finish.



Image: A detailed view of the perforated drip tray, highlighting its design for efficient water collection and drainage.

## TROUBLESHOOTING

---

If you encounter issues with your pitcher rinser, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No water spray or weak spray	Low water pressure, clogged nozzle, kinked hose, water supply off	Check water supply valve. Ensure hoses are not kinked. Clean the rinser nozzle for blockages. Verify adequate water pressure.
Water leaks from connections	Loose connections, damaged O-rings/washers	Tighten all hose connections. Inspect O-rings and washers for damage and replace if necessary.
Slow drainage	Clogged drain hose or drain assembly	Remove and clean the drip tray. Check the drain hose and assembly for any blockages and clear them.

## SPECIFICATIONS

Detailed specifications for the Diydeg Pitcher Rinser (Model Diydeg6ugxh4g29d-11).

Feature	Detail
Model Number	Diydeg6ugxh4g29d-11
Material	304 Stainless Steel
Finish Type	Polished
Package Dimensions	15.24 x 8.86 x 3.82 inches (38.7 x 22.5 x 9.7 cm)
Item Weight	2.51 pounds (1.14 kg)
Included Components	Rinser Unit, Drain, Hose
Power Required	No



Image: A clear diagram illustrating the key dimensions of the Diydeg Pitcher Rinser for installation planning.

## WARRANTY INFORMATION

Diydeg is committed to customer satisfaction. If you are not completely satisfied with your purchase, please contact our customer service team for assistance. We offer a satisfaction guarantee, and if the product fails to meet your expectations, we will work to resolve the issue, which may include a full purchase refund.

## CUSTOMER SUPPORT

For any questions, concerns, or assistance regarding your Diydeg Pitcher Rinser, please do not hesitate to contact our customer service. We are dedicated to providing prompt and helpful support.

Please refer to your purchase documentation or the retailer's website for specific contact details.

