

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [ProtoArc](#) /

› [ProtoArc Ergonomic Foldable Keyboard XK03 User Manual](#)

ProtoArc XK03

ProtoArc Ergonomic Foldable Keyboard XK03 User Manual

Model: XK03 | Brand: ProtoArc

INTRODUCTION

Thank you for choosing the ProtoArc Ergonomic Foldable Keyboard XK03. This ultra-slim, portable, and rechargeable keyboard is designed for comfort and convenience, allowing you to type efficiently across multiple devices. Its unique split ergonomic design promotes a natural typing position, reducing strain during extended use. This manual provides detailed instructions for setup, operation, and maintenance to ensure optimal performance.



Image: The ProtoArc XK03 keyboard being used in different environments, highlighting its versatility for business, education, and travel.

PRODUCT FEATURES

- **Split Ergonomic Design:** Features a unique U-shape with a 166-degree angle for a natural typing position, minimizing hand and wrist pressure.
- **Multi-Device Connectivity:** Pair up to 3 devices simultaneously via Bluetooth channels and switch between them easily.
- **Ultra Slim & Elegant:** Pocket-sized and foldable with a wear-resistant PU leather surface, ideal for portability.
- **Rechargeable Battery:** Built-in 250mAh lithium battery offers up to 150 days of standby time on a single 2-hour charge via USB-C.
- **Multimedia Function Keys:** Includes 13 multimedia function keys for quick access to various controls.



SPLIT ERGONOMIC DESIGN For natural typing position



Image: Visual representation of the keyboard's split ergonomic design, emphasizing the 166-degree angle for comfortable typing.



Image: The keyboard demonstrating multi-device connectivity with Bluetooth channels BT1, BT2, and BT3.

PACKAGE CONTENTS

- ProtoArc Ergonomic Foldable Keyboard XK03
- USB-C Charging Cable
- User Manual
- Phone/Tablet Stand



Image: All items included in the ProtoArc XK03 product package.

SETUP

1. Charging the Keyboard

Before first use, fully charge the keyboard using the provided USB-C cable. Connect the USB-C end to the keyboard's charging port and the USB-A end to a power source (e.g., computer USB port, USB wall adapter).



Image: The keyboard's USB-C charging port with the charging cable inserted.

2. Bluetooth Pairing

1. Unfold the keyboard to power it on. The indicator light for the current channel (1, 2, or 3) will blink.
2. Press and hold the **Fn** key along with one of the Bluetooth channel keys (**Q** for channel 1, **W** for channel 2, or **E** for channel 3) for 3-5 seconds until the corresponding indicator light starts blinking rapidly. This indicates the keyboard is in pairing mode.
3. On your device (mobile phone, tablet, or laptop), go to Bluetooth settings and enable Bluetooth.
4. Search for available devices. You should see "XK03" or "ProtoArc XK03" in the list.
5. Select "XK03" to connect. Once connected, the indicator light on the keyboard will stop blinking and remain solid for a few seconds before turning off.
6. To pair additional devices, repeat steps 2-5, selecting a different Bluetooth channel key (Q, W, or E).

Your browser does not support the video tag.

Video: An overview of the ProtoArc XK03 Foldable Keyboard, demonstrating its features and multi-device pairing capabilities.

Your browser does not support the video tag.

Video: A detailed overview of the ProtoArc XK03 Foldable Keyboard, including demonstrations of its ergonomic design and multi-device switching.

OPERATING INSTRUCTIONS

Auto Power On/Off

The keyboard features an automatic power on/off function. Simply unfold the keyboard to power it on, and fold it to power it off. This helps conserve battery life.



Image: The keyboard showing its auto power on/off functionality based on its folded or unfolded state.

Switching Between Devices

Once paired with multiple devices, you can switch between them by simply pressing the **Fn** key along with the corresponding Bluetooth channel key (**Q**, **W**, or **E**) for the desired device. The switch is instant.

Multimedia Function Keys

The keyboard includes dedicated multimedia function keys. To activate these functions, press the **Fn** key simultaneously with the desired F1-F12 key. Some common functions include:

- Directly press **Esc** to get "".
- Directly press **F1~F10** to get numbers 1~0.
- Press **Fn + Esc & F1 ~ F12** to achieve multimedia functions (e.g., access homepage, brightness, volume).
- Press **Shift + Esc & F1 ~ F12** corresponding keys to get symbols.
- Press **Fn + Shift + F1 ~ F12** corresponding keys to achieve FN function.

Note: This portable keyboard may not fully replicate all functions of a general office full-size keyboard. Some key combinations like "Ctrl + Alt + Delete" on Windows may not be achievable.

SPECIFICATIONS

Model	XK03
Connectivity Technology	Bluetooth (USB-C for charging)
Battery Capacity	250mAh Lithium Battery
Standby Time	150 Days
Charging Time	Approx. 2 Hours
Keyboard Description	Foldable Ergonomic
Compatible Devices	Mobile Phones, Tablets, Laptops
Item Weight	14.9 ounces
Package Dimensions	9.84 x 6.5 x 1.46 inches
Material	Metal (with PU leather surface)



Image: The folded dimensions of the ProtoArc XK03 keyboard, illustrating its compact and portable nature.

TROUBLESHOOTING

- **Keyboard not connecting:** Ensure the keyboard is fully charged and in pairing mode (indicator light blinking rapidly). Check your device's Bluetooth settings to ensure it's enabled and searching for devices. Try restarting both the keyboard and your device.
- **Keys not responding:** Verify the keyboard is connected to the correct Bluetooth channel. Ensure the keyboard is not in sleep mode (unfold and refold if necessary).
- **Lag or delayed input:** Ensure your device is within the effective Bluetooth range. Minimize interference from other wireless devices.
- **Multimedia keys not working:** Ensure you are pressing the **Fn** key simultaneously with the desired function key.

MAINTENANCE

- Clean the keyboard regularly with a soft, dry cloth.
- Avoid exposing the keyboard to extreme temperatures, moisture, or direct sunlight.
- Do not use harsh chemicals or abrasive cleaners.
- Store the keyboard in its folded state when not in use to protect the keys and conserve battery.

WARRANTY AND SUPPORT

ProtoArc products come with a standard manufacturer's warranty. For specific warranty details, technical support, or any inquiries regarding your XK03 keyboard, please refer to the contact information provided in the original product packaging or visit the official ProtoArc website.