

[Manuals.plus](#) /

› [Schildmeyer](#) /

› Schildmeyer Reno 400 701798 Reception Counter Instruction Manual

Schildmeyer 701798

Schildmeyer Reno 400 701798 Reception Counter Instruction Manual

Model: 701798

1. PRODUCT OVERVIEW

The Schildmeyer Reno 400 701798 is a versatile reception counter designed for various office and home office environments. It features a clean white finish, an integrated front shelf, and ample storage with three cabinets and an open compartment. This unit is constructed from engineered wood and includes adjustable feet for stability on uneven surfaces.



Image 1.1: The Schildmeyer Reno 400 Reception Counter in use, showcasing its functional design and integrated workspace.

2. SAFETY INFORMATION

WARNING: This furniture is heavy and may tip over if not properly secured. Always ensure the unit is stable and, if necessary, anchored to a wall according to local safety guidelines. Ensure all doors are

carefully closed to prevent the risk of pinching.

- Keep small parts away from children during assembly.
- Do not climb on or lean heavily on the unit.
- Distribute weight evenly across shelves and compartments.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all components are present and undamaged. This product is shipped in multiple packages, which may arrive at different times.

- Reception Counter panels (engineered wood)
- Front shelf (97.7 x 11 cm)
- 3 cabinet doors with soft-close dampers
- 3 adjustable shelves for cabinets
- Metal handles and fittings
- Black plastic furniture glides (adjustable height 1.8 to 2.7 cm)
- Assembly hardware (screws, dowels, etc.)
- Assembly instructions

4. SETUP AND ASSEMBLY

Assembly of the Schildmeyer Reno 400 Reception Counter is designed to be straightforward with clear instructions provided. It is recommended to have two people for assembly due to the size and weight of the components.

4.1 Tools Required

- Phillips head screwdriver
- Hammer (for dowels)
- Measuring tape (optional, for placement)

4.2 Assembly Steps

1. Unpack all components and lay them out on a clean, soft surface to prevent scratches.
2. Follow the detailed assembly instructions provided in the package to connect the main panels, shelves, and back panel.
3. Attach the front shelf to the designated area.
4. Install the three cabinet doors, ensuring the soft-close dampers are correctly positioned.
5. Insert the adjustable shelves into the cabinets at your desired height.
6. Attach the metal handles to the cabinet doors.
7. Screw in the black plastic furniture glides to the base of the unit. Adjust their height (1.8 to 2.7 cm) to level the counter on uneven floors.
8. Position the assembled counter in its final location.




Image 4.1: Interior view of the counter, illustrating the open compartment and adjustable shelves within the cabinets.

5. OPERATING INSTRUCTIONS

The Schildmeyer Reno 400 Reception Counter is designed for functional use in various settings.

- **Front Shelf:** Utilize the front shelf (97.7 x 11 cm) for displaying items, holding small documents, or as a temporary writing surface.
- **Open Compartment:** The large open compartment (97.7 x 29.3 x 23.7 cm) provides easy access storage for binders, books, or decorative items.
- **Cabinets:** The three rear cabinets offer concealed storage. Each cabinet features an adjustable shelf, allowing you to customize the storage space (compartment dimensions: 31.5 x 27.5 x 80 cm). The soft-close doors ensure quiet and gentle closing.
- **Adjustable Feet:** Ensure the counter remains level by adjusting the feet as needed, especially if relocating the unit.

6. MAINTENANCE

To ensure the longevity and appearance of your reception counter, follow these simple maintenance guidelines:

- **Cleaning:** Wipe surfaces with a damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Spills:** Clean up spills immediately to prevent staining or damage to the engineered wood.
- **Sunlight:** Avoid prolonged exposure to direct sunlight to prevent fading or discoloration.
- **Hardware:** Periodically check all screws and fittings to ensure they are tight. Retighten if necessary.

7. TROUBLESHOOTING

This section addresses common issues you might encounter with your reception counter.

- **Wobbling/Instability:** If the counter feels unstable, check that the adjustable feet are properly leveled. Adjust each foot until the unit is firm on the floor. Ensure all assembly screws are tightened.
- **Doors Not Closing Properly:** Verify that the soft-close dampers are correctly installed and not obstructed. Check door hinges for proper alignment and adjust if needed. Ensure the unit is level.
- **Scratches/Minor Damage:** For minor scratches, touch-up pens or furniture repair kits matching the white finish can be used.

If you encounter issues not covered here, please refer to the manufacturer's support information.

8. SPECIFICATIONS




Image 8.1: Front view with key dimensions: 107 cm width, 44 cm depth, 111 cm height.

Feature	Detail
Model Number	701798
Brand	Schildmeyer
Dimensions (W x D x H)	107 x 44 x 111 cm
Material	Engineered Wood
Color	White
Weight	24 Kilograms
Front Shelf Dimensions (W x D)	97.7 x 11 cm
Open Compartment Dimensions (W x D x H)	97.7 x 29.3 x 23.7 cm
Cabinet Compartment Dimensions (W x D x H)	31.5 x 27.5 x 80 cm (each)
Number of Doors	3 (with soft-close)

Number of Shelves	4 (1 open, 3 adjustable in cabinets)
Adjustable Feet Height	1.8 to 2.7 cm
Country of Origin	Germany

9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your purchase or contact Schildmeyer customer service directly. Keep your proof of purchase for any warranty claims.

For further assistance, visit the official Schildmeyer website or contact your retailer.