

[manuals.plus](#) /

› [Polti](#) /

› [Polti Coffea S15B Espresso Coffee Machine User Manual](#)

**Polti PCEU0122**

## Polti Coffea S15B Espresso Coffee Machine User Manual

Model: PCEU0122



### INTRODUCTION

---

The **Polti Coffea S15B** is an advanced espresso coffee machine designed for convenience and quality. It is compatible with **E.S.E. 44 mm coffee pods**, offering a simple and clean way to prepare your favorite coffee. Key features include electronic control for coffee quantity, adjustable temperature settings, and an automatic pod ejection system.



Figure 1: Polti Coffea S15B Espresso Coffee Machine.

## SETUP

---

### 1. Unpacking and Initial Cleaning

Carefully remove all packaging materials from the coffee machine. Before first use, it is recommended to clean the water tank, drip tray, and pod collection drawer with warm water and mild detergent. Rinse thoroughly.

### 2. Filling the Water Tank

The Polti Coffea S15B features a removable **0.85 L water tank**. To fill, gently lift the tank from its base and fill it with fresh tap water. Ensure the tank is securely placed back into position before operating the machine.



## **SERBATOIO REMOVIBILE DA 850 ML RIEMPIBILE DIRETTAMENTE AL RUBINETTO**

Figure 2: Removing the 0.85 L removable water tank for refilling.

### **OPERATING INSTRUCTIONS**

#### **1. Powering On and Heating Up**

Plug the machine into a suitable power outlet. Press the power button (usually indicated by a light) to turn on the machine. Wait for the indicator light to become steady, signaling that the machine has reached the optimal brewing temperature.

#### **2. Inserting an E.S.E. Pod**

Lift the top lever to open the pod insertion slot. Place one **E.S.E. 44 mm coffee pod** into the slot. Close the lever firmly until it clicks into place. The machine is designed for **automatic pod ejection** into the internal collection drawer, ensuring your hands remain clean.



**CAFFÈ CORTO O LUNGO?**  
DECIDI TU CON I COMODI PULSANTI  
SUPERIORI

Figure 3: Inserting an E.S.E. coffee pod.

### 3. Brewing Coffee (Short or Long)

Place your cup on the drip tray. The machine offers two buttons on the top panel for selecting your desired coffee length: one for a **short espresso** and one for a **longer coffee**. Press the corresponding button to start brewing. The machine will automatically stop dispensing once the programmed quantity is reached.



**TEMPERATURA E LUNGHEZZA  
PERSONALIZZABILI  
PER SODDISFARE OGNI ESIGENZA**

Figure 4: Selecting coffee length with the control buttons.



## **ESPULSIONE AUTOMATICA DELLE CIALDE NELL'APPOSITO CASSETTO: PER AVERE MANI SEMPRE PULITE**

Figure 5: Coffee being dispensed into a cup.

### **4. Adjusting Coffee Temperature and Quantity**

The Polti Coffea S15B allows you to customize the coffee temperature across **three levels**. Refer to the detailed instructions in the full manual for specific steps on how to access and adjust these settings. You can also reprogram the dispensed coffee quantity for both short and long options to suit your preference.

## **MAINTENANCE**

### **1. Cleaning the Drip Tray and Pod Collection Drawer**

Regularly empty and clean the **drip tray** and the internal **pod collection drawer**. The drip tray is located within the pod collection drawer. While the automatic ejection system keeps your hands clean, the collection drawer may accumulate residue and should be cleaned thoroughly. Due to its design, careful cleaning may be required to reach all areas.

### **2. Descaling**

Over time, mineral deposits can build up inside the machine, affecting performance. It is recommended to **descall** the machine periodically, depending on the hardness of your water and frequency of use. Use a descaling solution specifically designed for coffee machines and follow the product's instructions carefully. Refer to the complete manual for the descaling procedure.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Machine not turning on.	Not plugged in; power outlet issue; auto-shutoff activated.	Ensure the power cord is securely plugged into a working outlet. Press the power button. The machine has an <b>auto-shutoff function</b> after 25 minutes of inactivity to save energy.
No coffee dispensed or very little coffee.	Water tank empty; pod not inserted correctly; machine needs descaling.	Refill the water tank. Ensure the E.S.E. pod is correctly seated in the slot. Perform a descaling cycle if necessary.
Inconsistent coffee quantity dispensed.	Water tank not properly seated; programmed quantity needs recalibration.	Ensure the water tank is sufficiently filled and properly positioned. Recalibrate the programmed coffee quantity if necessary by following the instructions in the full manual.
Coffee is not hot enough.	Temperature setting too low; machine not fully preheated.	Adjust the temperature setting to a higher level (three levels available). Allow the machine sufficient time to preheat before brewing.
Machine is excessively noisy.	Air in the system; machine not on a stable surface.	Run a few cycles of hot water without a pod to prime the pump. Ensure the machine is placed on a stable, flat surface.
Cannot find the cup holder.	Cup holder is integrated.	The <b>cup holder</b> is located within the pod collection drawer.

## SPECIFICATIONS

Feature	Detail
Brand	Polti
Model	PCEU0122
Color	Black
Product Dimensions (L x W x H)	38 x 30 x 15 cm
Item Weight	2.9 Kilograms
Water Tank Capacity	0.85 Liters
Pump Pressure	19 Bar
Compatibility	E.S.E. 44 mm Coffee Pods
Special Features	Programmable, Removable Tank, Automatic Shut-off, Automatic Pod Ejection

## WARRANTY AND SUPPORT

---

For detailed warranty information, please refer to the manufacturer's official website or the documentation included with your purchase. Polti provides customer support for any inquiries or issues you may encounter with your Coffea S15B machine.

For further assistance, visit the [Polti Store on Amazon](#) or contact Polti customer service directly.

© 2023 Polti. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.