

## GTRACING BF001-2504

# GTRACING Gaming Chair Instruction Manual

Model: BF001-2504

## INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your GTRACING Gaming Chair, Model BF001-2504. Designed for comfort and support during extended periods of sitting, this ergonomic chair features adjustable components to enhance your gaming, working, or studying experience. Please read this manual thoroughly before assembly and use to ensure proper function and longevity of your chair.



Figure 1: GTRACING Gaming Chair (Model BF001-2504)

## SAFETY INFORMATION

---

To ensure safe operation and prevent injury or damage, please observe the following safety guidelines:

- **Regular Inspection:** Periodically check the chair for signs of wear and tear. Look for loose bolts, frayed upholstery, or cracks in the frame.
- **Listen for Unusual Noises:** Creaking, crackling, or other unusual noises can indicate stress on the chair's components. If such noises occur, discontinue use and inspect the chair.
- **Weight Capacity:** Do not exceed the maximum recommended weight capacity of **100 Pounds** (approximately 45 kg) to prevent structural damage or injury.
- **Proper Use:** Use the chair only for its intended purpose. Avoid standing on the chair or using it as a step stool.
- **Assembly:** Ensure all parts are correctly assembled and tightened according to the instructions before use.

## SETUP & ASSEMBLY

---

A detailed instruction manual is included with your product, along with all necessary accessories for assembly. Please follow the step-by-step guide provided in the package. General assembly typically involves:

1. **Base Assembly:** Attach the casters to the chair base.
2. **Gas Lift Installation:** Insert the gas lift into the center of the chair base.
3. **Seat Mechanism:** Secure the seat mechanism to the underside of the seat cushion.
4. **Seat and Backrest:** Attach the backrest to the seat cushion using the provided hardware.
5. **Armrests:** Install the armrests to the seat.
6. **Headrest and Lumbar Pillows:** Position the adjustable headrest and lumbar support pillows as desired.

For visual guidance on the chair's features and adjustments, please refer to the video below:

Your browser does not support the video tag.

Video 1: GTRACING Gaming Chair Features Overview. This video demonstrates the various adjustable features of the GTRACING gaming chair, including height, recline, armrests, and footrest operation.

## OPERATING INSTRUCTIONS

---

Your GTRACING Gaming Chair is equipped with multiple adjustable features for personalized comfort:

- **Seat Height Adjustment:** Use the lever located under the seat on the right side to raise or lower the chair. Pull the lever up to raise the seat; release to lock. To lower, pull the lever up while seated.
- **Backrest Recline:** The backrest can be reclined between 90 and 160 degrees. Use the lever on the side of the seat to adjust the recline angle.
- **3D Armrest Adjustment:** The armrests can be moved in multiple directions (up/down, inward/outward rotation) to find the optimal position for your arms and wrists.
- **Footrest Operation:** Pull the footrest out from under the seat to extend it. Push it back in when not in use.
- **Swivel Function:** The chair features a 360-degree swivel for easy movement and access to your workspace.



Figure 2: Key Adjustable Features of the GTRACING Gaming Chair.





Figure 3: User demonstrating the recline and footrest features for relaxation.

## MAINTENANCE

---

To maintain the quality and appearance of your GTRACING Gaming Chair, follow these simple maintenance tips:

- **Cleaning:** Wipe clean with a damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the faux leather material.
- **Fasteners:** Periodically check and tighten all bolts and screws to ensure the chair remains stable and secure.
- **Moving Parts:** Ensure the casters, gas lift, and recline mechanism operate smoothly. Lubricate if necessary with a silicone-based spray, avoiding oil-based lubricants that can attract dust.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause the faux leather to fade or crack.

## TROUBLESHOOTING

---

If you encounter any issues with your GTRACING Gaming Chair, please refer to the following common solutions:

- **Chair Squeaks:** Check all bolts and screws for tightness. Apply a small amount of silicone lubricant to moving parts and joints.
- **Difficulty Adjusting Height:** Ensure the gas lift lever is fully engaged or disengaged. If the issue persists, the gas lift may need replacement.
- **Chair Feels Unstable:** Verify that all components, especially the base and backrest, are securely fastened. Ensure the casters are properly inserted.
- **Footrest Not Extending/Retracting Smoothly:** Check for any obstructions. Clean the tracks and apply a small amount of lubricant if needed.

If these steps do not resolve the issue, please contact GTRACING customer support for further assistance.

## SPECIFICATIONS

Key specifications for the GTRACING Gaming Chair (Model BF001-2504):

Feature	Detail
Brand	GTRACING
Model Name	BF001-2504
Color	White (variant shown in images may vary)
Material	Faux Leather, Sponge Fill
Product Dimensions	22"D x 22"W x 47"H (approx. 56cm D x 56cm W x 119cm H)
Item Weight	30 pounds (approx. 13.6 kg)
Maximum Weight Recommendation	100 Pounds (approx. 45 kg)
Special Features	Arm Rest, Cushion Availability, 3D Armrest, Footrest, Headrest, Lumbar Support
Reclining Angle	Multiple positions, up to 160 degrees
Base Movement	360-degree Swivel

# PRODUCT DIMENSIONS



Figure 4: Detailed Product Dimensions.

## WARRANTY & SUPPORT

GTRACING is committed to customer satisfaction. Your gaming chair comes with the following warranty and support:

- **30-Day Guarantee:** Free replacement or refund within 30 days of purchase.
- **1-Year Warranty:** Free replacement or repair within 1 year of purchase for manufacturing defects.

For any warranty claims, product support, or inquiries, please refer to the contact information provided with your purchase documentation or visit the official GTRACING website.