

## Xoopar Octopus Gamma XP61075

# Xoopar Octopus Gamma XP61075 Multi-Connector USB Cable with 3000mAh Power Bank User Manual

## INTRODUCTION

Welcome to the user manual for your Xoopar Octopus Gamma XP61075. This versatile device combines a multi-connector USB charging cable with an integrated 3000mAh portable power bank, designed for convenience and compatibility with a wide range of electronic devices. Please read this manual carefully to ensure proper use and maintenance of your product.

## PRODUCT OVERVIEW

The Xoopar Octopus Gamma XP61075 features a compact design with multiple charging connectors and an internal battery. It is crafted with recycled materials, reflecting a commitment to sustainability.

### Key Features:

- Integrated 3000mAh portable power bank.
- Multi-cable design with USB-C and USB-A input connectors.
- Output connectors: Lightning, USB-C, and Micro-USB.
- Capable of charging two devices simultaneously.
- Luminous charge indicator for battery status.
- Lightweight and compact for portability.
- Constructed with recycled plastic and recycled leather components.

### Components:

The Octopus Gamma XP61075 includes a central unit housing the power bank and five flexible cables extending from it:

- **Input Connectors:** 1x USB-A, 1x USB-C
- **Output Connectors:** 1x Lightning, 1x USB-C, 1x Micro-USB



Image: The Xoopar Octopus Gamma XP61075 showing its various input and output connectors: Lightning, USB-C, Micro USB, and USB-A.



Image: The Xoopar Octopus Gamma XP61075 highlighting its construction from recycled plastic, 4-in-1 multi-adapter functionality, and ability to charge two devices simultaneously.

## SETUP

### Initial Charge:

Before first use, it is recommended to fully charge your Xoopar Octopus Gamma XP61075. Connect either the USB-A or USB-C input connector to a compatible power source (e.g., wall adapter, computer USB port). The luminous indicator on the device will show the charging status.

### Connecting to Devices:

Select the appropriate output connector (Lightning, USB-C, or Micro-USB) for your device. Plug the connector securely into your device's charging port.



Image: The Xoopar Octopus Gamma XP61075 connected to a power strip via its USB-A input, demonstrating its compatibility with various power sources for recharging.

## OPERATING INSTRUCTIONS

### Charging Your Device:

1. Identify the correct output cable for your device (Lightning, USB-C, or Micro-USB).
2. Plug the chosen cable into your device's charging port.
3. The Octopus Gamma XP61075 will automatically begin charging your device using its internal 3000mAh battery.
4. The luminous indicator will show the power bank's battery status.




Image: A smartphone being charged by the Xoopar Octopus Gamma XP61075, illustrating its function as a 3000mAh portable charger.

### Recharging the Power Bank:

The Octopus Gamma XP61075 can be recharged by connecting its USB-A or USB-C input cable to a power source. A unique feature allows it to recharge simultaneously with your smartphone when both are connected to an external power source. This ensures the power bank is always ready for use.

### Simultaneous Charging:

The device supports charging up to two devices at once. For example, you can charge a smartphone via the Lightning cable and another device via the USB-C or Micro-USB cable, while the power bank itself is connected to a power source via its USB-A or USB-C input.

---

## MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the device. Avoid liquid cleaners or abrasive materials.
- **Storage:** Store the Octopus Gamma XP61075 in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the power bank frequently. Recharge it

regularly, even if not in constant use.

- **Environmental Considerations:** This product is made with recycled plastic. Please dispose of it responsibly according to local electronic waste regulations.

---

## TROUBLESHOOTING

### Device Not Charging:

- Ensure the correct connector is securely plugged into your device.
- Check if the Octopus Gamma XP61075 has sufficient charge. The luminous indicator should provide status.
- Try a different output cable if available.

### Power Bank Not Recharging:

- Verify that the input cable (USB-A or USB-C) is securely connected to a working power source.
- Try a different power source or wall adapter.
- Ensure the input cable itself is not damaged.

### Slow Charging:

- Ensure the power source provides adequate current.
- Charging multiple devices simultaneously may reduce individual charging speeds.
- Check for any debris in the charging ports of both the power bank and your device.

---

## SPECIFICATIONS

Feature	Detail
Model Name	Octopus Gamma RP
Model Number	XP61075
Battery Capacity	3000mAh Lithium-Polymer
Input Connectors	USB-C, USB-A
Output Connectors	Lightning, USB-C, Micro-USB
Number of Connectors	5 (2 input, 3 output)
Dimensions	5.1 x 1.7 x 13.5 cm (2.0 x 0.7 x 5.3 inches)
Weight	70 Grams (2.5 ounces)
Special Features	Fast Charge, Lightweight, Luminous Charge Indicator
Materials	Recycled Plastic (RABS, RTPE, RPET), Recycled Leather
Compatibility	Universal (Smartphones, Tablets, Earphones, Laptops, Speakers, GoPro, etc.)



Image: The Xoopar Octopus Gamma XP61075 with its dimensions indicated: 135 mm length and 51 mm width.

## WARRANTY INFORMATION

The Xoopar Octopus Gamma XP61075 is covered by a 2-year manufacturer's warranty from the date of

purchase. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims. The warranty does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

---

## **SUPPORT**

For further assistance, technical support, or warranty inquiries, please contact Xoopar customer service. You can find contact details and additional resources on the official Xoopar website. Please have your product model number (XP61075) and proof of purchase ready when contacting support.

---