

[manuals.plus](#) /› [WMF](#) /› [WMF Milk Frother Whisk Instruction Manual for Lono Milk & Choc \(FS-1000050131\)](#)

WMF FS-1000050131

WMF Milk Frother Whisk Instruction Manual for Lono Milk & Choc (FS-1000050131)

Model: FS-1000050131 | Brand: WMF

1. INTRODUCTION

This manual provides essential information for the proper use, maintenance, and care of your WMF Milk Frother Whisk. This whisk is an original replacement part (FS-1000050131) specifically designed for the WMF Lono Milk & Choc milk frother (model 0413170011). Please read these instructions carefully before use and retain them for future reference.

2. SAFETY INSTRUCTIONS

- Always ensure the main frother unit is unplugged and cool before handling or installing the whisk.
- Keep the whisk and frother out of reach of children.
- Use the whisk only for its intended purpose with the compatible WMF Lono Milk & Choc frother.
- Inspect the whisk for any damage before each use. Do not use if damaged.
- The whisk is made of stainless steel. Handle with care to avoid injury.

3. PRODUCT OVERVIEW

The WMF Milk Frother Whisk is a precision-engineered accessory designed to create perfect milk foam for various beverages. It is constructed from high-quality stainless steel for durability and hygiene.



Image showing the WMF Milk Frother Whisk, a stainless steel component with a central shaft and a frothing head featuring multiple loops.

4. SETUP AND INSTALLATION

1. Ensure your WMF Lono Milk & Choc frother is unplugged and completely cool.
2. Locate the designated whisk attachment point inside the frother's jug.
3. Carefully insert the WMF Milk Frother Whisk into the attachment point. Push down gently until it is securely seated.
4. Verify that the whisk is stable and does not wobble before proceeding with operation.

5. OPERATING INSTRUCTIONS

The WMF Milk Frother Whisk operates in conjunction with your WMF Lono Milk & Choc frother. Follow the instructions below for optimal performance:

1. After installing the whisk (as per Section 4), add the desired amount of milk or other liquid to the frother jug. Do not exceed the maximum fill line indicated on your frother.
2. Securely place the lid on the frother.

3. Plug in the WMF Lono Milk & Choc frother and select your desired program (e.g., hot foam, cold foam, hot milk) according to the frother's main instruction manual.
4. The whisk will automatically rotate to create the desired texture.
5. Once the frothing cycle is complete, carefully remove the lid and pour the frothed milk.

Note: For detailed operating procedures and specific recipes, please refer to the comprehensive instruction manual provided with your WMF Lono Milk & Choc frother unit.

6. MAINTENANCE AND CLEANING

Proper cleaning ensures the longevity and hygienic operation of your WMF Milk Frother Whisk. This whisk is designed for **hand wash only**.

1. After each use, allow the whisk to cool down completely.
2. Carefully remove the whisk from the frother jug.
3. Wash the whisk thoroughly by hand using warm water and a mild dishwashing detergent. Use a soft brush if necessary to remove any milk residue from the loops.
4. Rinse the whisk completely under running water to remove all soap residue.
5. Allow the whisk to air dry completely before storing or re-installing it in the frother.

Important: Do not wash the whisk in a dishwasher, as this may damage the material or affect its performance.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Whisk does not rotate or froths poorly.	<ul style="list-style-type: none">Whisk not properly installed.Residue build-up on whisk.Damage to the whisk.Issue with the main frother unit.	<ul style="list-style-type: none">Remove and re-install the whisk, ensuring it clicks into place.Clean the whisk thoroughly as per Section 6.Inspect for bends or breaks. Replace if damaged.Refer to the WMF Lono Milk & Choc frother's main manual for troubleshooting the unit itself.

8. SPECIFICATIONS

Brand: WMF

Part Number (Model): FS-1000050131

Compatible Frother Model: WMF Lono Milk & Choc (0413170011)

Material: Stainless Steel

Color: Silver

Product Weight: 100 Grams

Care Instructions: Hand wash only

Recommended Uses: For creating foam for coffee (cappuccino, latte), hot chocolate, and milk drinks (e.g., milkshake)

Style: Modern

9. WARRANTY AND SUPPORT

This WMF Milk Frother Whisk is an original WMF replacement part. For information regarding warranty coverage, product support, or to purchase additional replacement parts, please contact WMF customer service or visit the official WMF website. Please have your product model number (FS-1000050131) and the compatible frother model (WMF Lono Milk & Choc 0413170011) available when seeking support.