

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Hatchimals](#) /

› [Hatchimals Alive Egg Carton Toy: Self-Hatching Figures Instruction Manual](#)

Hatchimals 6071092

Hatchimals Alive Egg Carton Toy: Self-Hatching Figures Instruction Manual

Model: 6071092 | Brand: Hatchimals

INTRODUCTION

The Hatchimals Alive Egg Carton Toy provides an interactive experience where collectible figures hatch from eggs with the help of water. This set includes six Hatchimals figures and eleven accessories, designed for imaginative play. This manual outlines the setup, hatching process, and care instructions for your Hatchimals Alive set.

WHAT'S INCLUDED

Your Hatchimals Alive Egg Carton Toy includes the following components:

- 6 Hatchimals Figures
- 1 Egg Carton Playset
- 11 Accessories (e.g., pacifiers, bottle, microphone, drum, kazoo)
- 1 Instruction Sheet



Image: The complete Hatchimals Alive Egg Carton Toy set in its packaging.

SETUP

Before beginning play, ensure all components are removed from the packaging. The egg carton serves as both storage and a play area. No assembly is required for the main components.

OPERATING INSTRUCTIONS: HATCHING YOUR HATCHIMALS

Follow these steps to hatch your Hatchimals figures:

1. **Prepare the Eggs:** Locate the pacifiers on each egg and gently remove them.
2. **Fill the Bottle:** Fill the included baby bottle with clean water.
3. **Initiate Hatching:** Squeeze the water from the bottle into the small opening on top of each Hatchimals egg. Observe as the egg shell begins to crack and dissolve.



Image: A child feeding a Hatchimals egg with water to initiate hatching.

Alternatively, you can submerge the eggs in water to hatch them:

1. **Submerge Eggs:** Place the eggs into a container of water. The egg shell will gradually break apart, revealing the figure inside.
2. **Reveal Figure:** Once the egg has sufficiently cracked, gently peel away any remaining shell pieces to fully reveal your Hatchimals figure.



SELF-HATCHING EGGS

Hatch like real eggs!

Image: A child submerging a Hatchimals egg in water for hatching.



6 CHARACTERS INCLUDING DRAGON TWINS!

Image: Multiple Hatchimals figures in various stages of hatching from their eggs.

Official Product Video: Hatching Process

Your browser does not support the video tag.

Video: An official product video demonstrating the hatching process of Hatchimals Alive figures.

PLAY AND ACCESSORIES

Once hatched, your Hatchimals figures are ready for play. The egg carton transforms into a music class play area. Use the included accessories to create various scenarios and adventures for your Hatchimals.

- **Music Class Adventures:** Place your Hatchimals in the designated spots within the carton. Utilize accessories like the microphone, drum, and kazoo for music-themed storytelling.
- **Pacifier Use:** The pacifiers can be placed in each character's mouth for interactive play.
- **On-the-Go Play:** The egg carton features a locking lid, allowing you to securely store and transport your Hatchimals and accessories.



10+ SURPRISES INSIDE!

Image: The egg carton playset with hatched figures and accessories, ready for play.



PLAY AREA FOR MUSIC CLASS ADVENTURES

Image: Children engaging in imaginative play with their Hatchimals figures.

MAINTENANCE

To ensure the longevity of your Hatchimals Alive Egg Carton Toy:

- **Cleaning:** Wipe figures and the playset with a damp cloth as needed. Do not submerge the entire playset in water.
- **Storage:** Store all figures and accessories inside the egg carton with the lid locked when not in use to prevent loss.
- **Water Play:** Use clean water for hatching. Dispose of water and any dissolved egg shell residue responsibly after play.

TROUBLESHOOTING

If you encounter any issues with your Hatchimals Alive Egg Carton Toy, consider the following:

- **Egg Not Hatching:** Ensure enough water is applied to the egg. If using the bottle, squeeze firmly. If submerging, ensure the egg is fully immersed.

- **Missing Pieces:** Carefully check all packaging materials. If a piece is genuinely missing, refer to the support section.

SPECIFICATIONS

Brand	Hatchimals
Model Number	6071092
Age Range	3 years and up
Material	Plastic
Item Dimensions (L x W x H)	9.25 x 4.33 x 2.76 inches
Item Weight	0.72 Pounds
Color	Yellow/Pink Carton
Theme	Adventure

SAFETY INFORMATION

WARNING: CHOKING HAZARD – Small parts. Not for children under 3 years.

Adult supervision is recommended during play, especially during the hatching process involving water.

WARRANTY AND SUPPORT

This product is provided without a manufacturer's warranty. For any product-related inquiries or support, please refer to the retailer where the product was purchased.