

70UQ70, 75UQ80(70) and 86UQ70

Instruction Manual for LG Smart TV Replacement Legs

Model: 70UQ70, 75UQ80(70), 86UQ70

PRODUCT OVERVIEW

This product provides replacement base stands for specific LG Smart TV models. It includes one left leg, one right leg, and all necessary screws for assembly. These legs are designed to provide stable support for your television.

It is crucial to verify your TV model number to ensure compatibility before installation. This set is specifically compatible with LG Smart TV Models 70UQ70, 75UQ80(70), and 86UQ70.

SETUP AND INSTALLATION

Follow these steps to properly install the replacement TV legs:

1. Step 1: Model Verification

Before beginning, locate the model number on the sticker at the back of your TV or check the 'About TV' section in your settings. Confirm that your TV model is one of the following: 70UQ70, 75UQ80(70), or 86UQ70. This leg set is only compatible with these specified models.

2. Step 2: Prepare Your Workspace

Lay your television screen-down on a soft, clean, and flat surface (e.g., a blanket or foam padding) to prevent scratches or damage during installation. Ensure you have adequate space to work safely.

3. Step 3: Identify Components

Unpack the contents. You should have one left leg, one right leg, and the necessary screws. Identify the left and right legs; they are typically marked or shaped to fit specific sides of the TV.





Image: The complete set of replacement TV legs and screws.

4. **Step 4: Position the Legs**

Align each leg with the corresponding mounting holes on the bottom of your television. Ensure the legs are oriented correctly, typically with the wider base facing outwards for stability.



Image: Side view of the TV stand legs, illustrating their design.

5. **Step 5: Secure the Legs**

Using a Phillips screwdriver (not included), insert the provided screws into the designated holes and tighten them securely. Do not overtighten, as this may damage the TV or the legs.



Image: Angled view of the TV stand legs, highlighting the attachment points.

6. **Step 6: Final Placement**

Carefully lift the television and place it upright on a stable, level surface. Ensure both legs are firmly seated and the TV is stable before connecting any cables or powering it on.

Installation Tool Required: A Phillips screwdriver is needed for the installation process.

USAGE GUIDELINES

Once installed, ensure your television is placed on a flat, stable surface that can support its weight. Avoid placing the TV near edges where it could be easily knocked over. Do not attempt to move the TV by pulling on the legs; always lift the TV from its main body.

MAINTENANCE

To maintain the appearance and integrity of your TV stand legs, simply wipe them with a dry cloth. Avoid using abrasive cleaners or solvents, as these may damage the finish. Periodically check the screws to ensure they remain tight and secure.

TROUBLESHOOTING

- **Legs do not fit:** Double-check your TV model number against the compatible models (70UQ70, 75UQ80(70), 86UQ70). If your model is not listed, these legs are not compatible.
- **TV is unstable:** Ensure all screws are securely tightened. Verify that the legs are correctly oriented and fully inserted into the TV's mounting points. Make sure the surface the TV is placed on is flat and level.
- **Missing parts:** If any components (left leg, right leg, or screws) are missing from the package, please contact customer support immediately.

SPECIFICATIONS

Brand	generic
Color	Black
Compatible Models	70UQ70, 75UQ80(70), 86UQ70
Product Dimensions	2 x 2 x 12 inches
Item Weight	1 pounds
Installation Type	Screw-In
Product Care Instructions	Wipe with Dry Cloth

CUSTOMER SUPPORT






If you encounter any issues or have questions regarding the compatibility or installation of these TV legs, please do not

hesitate to contact us. We are available to assist you in finding the correct part for your television or resolving any concerns you may have.

For assistance, please refer to the contact information provided by your retailer or on the product packaging.



Related Documents - 70UQ70, 75UQ80(70) and 86UQ70

	<p>LG LED TV Owner's Manual and Safety Guide</p> <p>Comprehensive owner's manual for LG LED TVs, covering setup, safety instructions, troubleshooting, specifications, and regulatory information. Includes guidance on installation, connections, and remote control usage.</p>
	<p>LG LED TV Owner's Manual: Safety, Setup, and Specifications</p> <p>Comprehensive owner's manual for LG LED TVs, covering safety instructions, installation, troubleshooting, remote control usage, connectivity options, and technical specifications. Includes guidance for models like 75NANO80AQA and other series.</p>
	<p>Thermo Pride 70-BASE Combustible Floor Base Installation Guide</p> <p>Comprehensive installation instructions for the Thermo Pride 70-BASE combustible floor base, detailing floor preparation, duct connections, and essential combustion air requirements for safe and efficient HVAC system setup.</p>
	<p>Smappee EV Base Quick Install Guide</p> <p>Concise guide for installing and configuring the Smappee EV Base electric vehicle charging station, including safety warnings and component lists.</p>
	<p>LG LED TV Owner's Manual: Safety, Setup, and Specifications</p> <p>Comprehensive owner's manual for LG LED TVs, covering safety instructions, installation guides, connection options, technical specifications, and troubleshooting tips for various QNED, NANO, and UQ series models.</p>



Grundfos UPM3 Auto L 15/70 Asennusohjeet – Käyttö ja Asetukset

Asennusohjeet Grundfos UPM3 Auto L 15/70 -kiertovesipumpulle. Opi käyttämään, säätämään ja ymmärtämään pumpun eri tiloja, käyriä ja hälytyksiä. Sisältää tekniset tiedot ja kytkentäohjeet.