



Manuals.plus /

› Swarovski /

› Swarovski SK 7011 Crystal Clip-on Butterfly Sunglasses User Manual

Swarovski SK7011

Swarovski SK 7011 Crystal Clip-on Butterfly Sunglasses User Manual

INTRODUCTION

Thank you for choosing Swarovski SK 7011 Crystal Clip-on Butterfly Sunglasses. These sunglasses are designed to offer both sophisticated style and essential eye protection. This manual provides important information on how to properly set up, operate, maintain, and care for your new eyewear to ensure its longevity and optimal performance.

The SK 7011 model features a distinctive butterfly shape with a gold frame and light brown lenses, enhanced by a multi-shaped cut stone rim clip-on. The lenses are coated with 100% UV protection to shield your eyes from harmful ultraviolet rays.

SETUP

Unboxing and Initial Inspection

Upon receiving your Swarovski SK 7011 sunglasses, carefully open the packaging. Remove the sunglasses, cleaning cloth, and case. Inspect the sunglasses for any visible damage or imperfections. If you notice any issues, please contact customer support immediately.



Image: Front view of the Swarovski SK 7011 Crystal Clip-on Butterfly Sunglasses with gold frame and light brown lenses, featuring the crystal clip-on.

Attaching and Detaching the Crystal Clip-on

The SK 7011 sunglasses come with a unique crystal clip-on feature. To attach the clip-on, gently align it with the frame of the sunglasses and secure it into place. Ensure it is firmly seated to prevent accidental detachment. To detach, carefully unclip it from the frame. Handle the clip-on with care to avoid damaging the crystals or the frame.



Image: Close-up front view of the sunglasses, highlighting the intricate crystal detailing around the lenses.

OPERATING INSTRUCTIONS

Wearing Your Sunglasses

Place the sunglasses on your face, ensuring the nose pads rest comfortably on your nose bridge and the temples extend over your ears without causing pressure. The fit should be regular, providing stability without being too tight or too loose.



Image: A model wearing the Swarovski SK 7011 Crystal Clip-on Butterfly Sunglasses, demonstrating the fit and style.

UV Protection

These sunglasses are equipped with lenses that provide 100% UV protection, safeguarding your eyes from harmful UVA and UVB rays. They are suitable for general use in various light conditions but are not intended for direct sun observation or as protective eyewear against artificial light sources.

MAINTENANCE AND CARE

Cleaning Your Sunglasses

- Use the provided cleaning cloth to gently wipe the lenses and frame. For best results, breathe lightly on the lenses before wiping to create a slight mist.
- For stubborn smudges, use a lens cleaning spray specifically designed for eyewear. Avoid using paper towels, clothing, or harsh cleaning agents, as these can scratch the lenses or damage the frame finish.
- Clean the crystal elements carefully with the cloth, ensuring no residue is left behind.

Storage

Always store your sunglasses in the provided protective case when not in use. This prevents scratches to the lenses and protects the frame and crystal embellishments from damage. Avoid leaving sunglasses in direct sunlight or extreme temperatures, such as on a car dashboard, as this can warp the frame or damage the lens coating.

**SWAROVSKI EYEWEAR INCLUDES ONE OF VARIOUS COLOR PACKAGES,
CONTAINING A MATCHING CLEANING CLOTH AND LEAFLET.**



Image: Example of Swarovski eyewear packaging, including a protective case and cleaning cloth, essential for proper

storage and maintenance.

General Handling

- Always use both hands to put on and take off your sunglasses to prevent bending the frame.
- Avoid placing sunglasses face down on hard surfaces to protect the lenses from scratches.
- Do not expose the sunglasses to saltwater or chlorinated water, as these can corrode metal parts and damage coatings.

TROUBLESHOOTING

Loose Fit

If your sunglasses feel too loose, the temples may need slight adjustment. It is recommended to visit a professional optician for frame adjustments to avoid accidental damage.

Scratched Lenses

Minor scratches can sometimes be polished by a professional. For significant scratches that impair vision, lens replacement may be necessary. Always use the provided cleaning cloth and case to prevent scratches.

Crystal Detachment

If a crystal becomes loose or detaches, avoid attempting to reattach it yourself if you are unsure. Contact Swarovski customer support or an authorized repair center for assistance.

SPECIFICATIONS

Feature	Detail
Model Number	SK7011
Department	Womens
Frame Material	Metal
Lens Material	Plastic
Lens Color	Light Brown
Item Shape	Butterfly
Style Name	Sk 7011 With Crystal Clip-on
Sunglasses Form	Clip-on
Fit Type	Regular
Lens Type	Non-Polarized
UV Protection	100% UV Protection Coating
Arm Length	140 Millimeters
Bridge Width	20 Millimeters
Item Weight	202 Grams

WARRANTY INFORMATION

Swarovski sunglasses purchased from authorized sellers, such as Amazon.com, are eligible for all applicable manufacturer warranties and guarantees. Please retain your proof of purchase for warranty claims. The warranty typically covers manufacturing defects but does not cover damage resulting from misuse, accidents, or unauthorized repairs.

For specific details regarding your product's warranty period and coverage, please refer to the documentation included with your purchase or visit the official Swarovski website.

SUPPORT

For further assistance, product inquiries, or warranty claims, please contact Swarovski customer service. You can also visit the official Swarovski store online for more information about their products and services.

Swarovski Official Store: Visit the Swarovski Store on Amazon