

AW Y526

Awei Y526 Wireless Bluetooth Speaker User Manual

Model: Y526

INTRODUCTION

This manual provides comprehensive instructions for the Awei Y526 Wireless Bluetooth Speaker. Please read this guide carefully before using the product to ensure proper operation, optimal performance, and longevity. Keep this manual for future reference.

IMPORTANT SAFETY PRECAUTIONS

- Do not expose the speaker to extreme temperatures, direct sunlight, or open flames.
- Avoid dropping or subjecting the speaker to strong impacts.
- Do not disassemble, repair, or modify the speaker yourself. This will void the warranty.
- Keep the speaker away from water and liquids, despite its waterproof rating, to prevent damage to internal components.
- Use only the specified charging cable and power adapter.
- Keep out of reach of children.

PACKAGE CONTENTS

Please check that all items listed below are present in your package:

- Awei Y526 Wireless Bluetooth Speaker
- USB Charging Cable
- User Manual

PRODUCT DIAGRAM

Familiarize yourself with the speaker's components and controls.



Figure 1: Front view of the Awei Y526 speaker, showing the central Awei logo and the integrated carrying strap.



Figure 2: Side view of the Awei Y526 speaker, highlighting the volume control buttons ('+' and '-') and the multi-function button (often integrated with the power button or between volume controls).

Button Functions:

- **Power Button:** Press and hold to power on/off. Short press for play/pause (music) or answer/end call.
- **'+' Button:** Short press to increase volume. Long press to skip to the next track.
- **'-' Button:** Short press to decrease volume. Long press to go to the previous track.

GETTING STARTED

1. Charging the Speaker

1. Connect the USB charging cable to the charging port on the speaker.
2. Connect the other end of the USB cable to a suitable USB power adapter (5V/1A recommended) or a computer's USB

port.

3. The LED indicator will illuminate during charging and turn off once fully charged.
4. A full charge typically takes approximately 2-3 hours.

2. Powering On/Off

- **To Power On:** Press and hold the Power button for approximately 3 seconds until you hear an audible prompt and the LED indicator flashes.
- **To Power Off:** Press and hold the Power button for approximately 3 seconds until you hear an audible prompt and the LED indicator turns off.

BLUETOOTH CONNECTION

Follow these steps to pair your Awei Y526 speaker with a Bluetooth-enabled device.

1. Ensure the speaker is powered on and in pairing mode (the LED indicator will typically flash rapidly).
2. On your mobile device (smartphone, tablet, etc.), enable Bluetooth.
3. Search for available Bluetooth devices. You should see "Awei Y526" in the list.
4. Select "Awei Y526" to connect. Once successfully paired, you will hear a confirmation sound, and the LED indicator will stop flashing and remain solid.
5. The speaker will automatically attempt to reconnect to the last paired device when powered on.

OPERATING FUNCTIONS

Music Playback

- **Play/Pause:** Short press the Power button.
- **Next Track:** Long press the '+' button.
- **Previous Track:** Long press the '-' button.

Volume Adjustment

- **Increase Volume:** Short press the '+' button.
- **Decrease Volume:** Short press the '-' button.

Call Handling

- **Answer Call:** Short press the Power button when an incoming call rings.
- **End Call:** Short press the Power button during a call.
- **Reject Call:** Long press the Power button when an incoming call rings.

True Wireless Stereo (TWS) Pairing

The Awei Y526 supports TWS functionality, allowing two Y526 speakers to connect wirelessly for a stereo sound experience.

1. Ensure both Awei Y526 speakers are powered off.
2. Power on both speakers simultaneously. They will enter Bluetooth pairing mode.
3. On one of the speakers, double-press the Power button. The speakers will attempt to pair with each other.
4. Once successfully paired in TWS mode, you will hear a confirmation sound. The LED indicator on one speaker will flash (master), and the other will be solid (slave).
5. Now, connect your device to the master speaker (the one with the flashing LED) via Bluetooth as described in the

"Bluetooth Connection" section.

CARE AND MAINTENANCE

- Clean the speaker with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- If the speaker gets wet, wipe it dry immediately. Ensure the charging port cover is securely closed to maintain its waterproof rating.
- Store the speaker in a cool, dry place when not in use for extended periods.
- Avoid exposing the speaker to strong magnetic fields.

TROUBLESHOOTING

Problem	Solution
Speaker won't turn on.	Ensure the speaker is fully charged. Connect it to a power source and try again.
Cannot pair with device.	1. Ensure the speaker is in pairing mode. 2. Make sure Bluetooth is enabled on your device. 3. Move the speaker closer to your device. 4. Forget "Awei Y526" from your device's Bluetooth list and try pairing again.
No sound or low volume.	1. Check the volume levels on both the speaker and your connected device. 2. Ensure the speaker is properly connected via Bluetooth. 3. If in TWS mode, ensure both speakers are correctly paired.
Sound distortion.	1. Reduce the volume on both the speaker and your device. 2. Move the speaker closer to your device to avoid interference. 3. Ensure the audio source is of good quality.

SPECIFICATIONS

Feature	Detail
Model Name	Awei Y526
Connectivity Technology	Bluetooth
Bluetooth Version	5.0
Speaker Maximum Output Power	6 Watts
Audio Output Mode	Stereo
Special Features	Waterproof (IPX4)
Compatible Devices	Smartphone
Product Dimensions	10 x 10 x 14 cm
Item Weight	400 g

Feature	Detail
Mounting Type	Tabletop

WARRANTY AND SUPPORT

For warranty information, technical support, or customer service inquiries, please contact Awei directly.

- **Official Website:** www.awei.hk
- **Email Support:** service@awei.hk

Please retain your proof of purchase for warranty claims.