

[Manuals.plus](#) /

› [Keurig](#) /

› Keurig K-Compact Single-Serve K-Cup Pod Coffee Maker User Manual

Keurig 5000376527

Keurig K-Compact Single-Serve K-Cup Pod Coffee Maker User Manual

Model: 5000376527 | Brand: Keurig

PRODUCT OVERVIEW

The Keurig K-Compact single-serve coffee maker offers a space-saving design while delivering the convenience and delicious taste associated with the Keurig brand. Measuring just over 8 inches wide, it fits comfortably on most countertops. This brewer allows you to prepare 6, 8, or 10 oz. of your favorite beverages in minutes. It is compatible with hundreds of K-Cup pod varieties, including coffee, tea, hot cocoa, and iced beverages. The Smart Start feature ensures quick heating and brewing, eliminating wait times. A removable drip tray accommodates travel mugs up to 7.0 inches tall, and the 36 oz. removable water reservoir minimizes refilling frequency.

KEY FEATURES

- **Multiple Brew Sizes:** Brews 6, 8, or 10 oz. for customized strength and volume. The 6 oz. option provides the strongest brew.
- **Fast & Fresh Brewed:** Enjoy coffee prepared in minutes.
- **Compact Multi-Cup Reservoir:** Features a 36 oz. removable water reservoir for easy refilling and multiple brews.
- **Smart Start:** The coffee maker heats and brews in one continuous process, eliminating pre-heating wait times.
- **Simple Button Controls:** Easy operation – just insert a pod, select your desired brew size, and enjoy.
- **Energy Efficient:** An auto-off feature turns the coffee maker off 2 hours after the last brew to conserve energy.
- **Removable Drip Tray:** Accommodates travel mugs up to 7.0 inches tall and simplifies cleanup of accidental spills.
- **Hot Water Dispense:** Obtain hot water on demand by opening and closing the brewer handle without a pod and selecting a cup size.

SETUP

1. **Unpacking and Initial Setup:** Remove all packing tape and materials from the coffee maker. Place the coffee maker on a stable, level surface.
2. **Water Reservoir Preparation:** Remove the water reservoir from the back of the brewer. Wash the reservoir and lid

with warm, soapy water, then rinse thoroughly. Fill the reservoir with fresh water up to the MAX fill line. Place the reservoir back onto the brewer, ensuring it is seated properly.

3. **First Brew Cycle (Cleansing):** Place a large mug (10 oz. or larger) on the drip tray. Lift and lower the brewer handle without inserting a K-Cup pod. Press the power button to turn on the brewer. The brew size buttons will flash. Select the 8 oz. brew size button. The cleansing brew will begin. Once complete, discard the hot water. The brewer is now ready for use.

OPERATING INSTRUCTIONS

1. **Add Water:** Ensure the water reservoir is filled with fresh water. The "Add Water" indicator light will illuminate if the water level is low.
2. **Place Mug:** Place a mug on the drip tray.
3. **Insert K-Cup Pod:** Lift the brewer handle. Place a K-Cup pod in the K-Cup pod holder. Lower the handle completely to close the lid. The brew size buttons will begin to flash.
4. **Select Brew Size:** Choose your desired brew size (6, 8, or 10 oz.) from the illuminated buttons. For a stronger brew, select the 6 oz. option.
5. **Brew:** The brewing process will begin automatically. The brew size button will remain illuminated during brewing and turn off once complete.
6. **Enjoy:** Carefully remove your freshly brewed beverage. Lift the handle, remove and discard the used K-Cup pod.
7. **Hot Water Dispense:** To dispense hot water without a K-Cup pod, simply lift and lower the brewer handle (without a pod) and select your desired cup size.

MAINTENANCE

- **Daily Cleaning:**
 - **Drip Tray:** The drip tray can accumulate up to 7.0 oz. of overflow. It should be emptied and cleaned regularly. Remove the drip tray, separate the components, wash with warm, soapy water, rinse, and dry.
 - **K-Cup Pod Holder:** The K-Cup pod holder can be removed for cleaning. Wash with warm, soapy water, rinse, and dry. Ensure the exit needle is clear of any coffee grounds.
- **Descaling:** Over time, calcium deposits (scale) can build up in your coffee maker. Descaling is essential to maintain optimal performance. The descaling frequency depends on the mineral content of your water.
 - Use a Keurig descaling solution or a vinegar solution (consult the full user manual for specific instructions and ratios).
 - Perform several cleansing brews with plain water after descaling to ensure all solution is flushed from the system.

TROUBLESHOOTING

- **Coffee Not Brewing:**
 - Ensure the water reservoir is filled and properly seated.
 - Check that the K-Cup pod is correctly inserted and the handle is fully lowered.
 - Verify the brewer is powered on and the brew size button is selected.
- **Weak Coffee:**
 - Try using a smaller brew size (e.g., 6 oz.) for a stronger concentration.
 - Consider using a bolder roast K-Cup pod.

- **Water Leaking:**
 - Ensure the water reservoir is securely in place and not overfilled.
 - Check the drip tray for proper seating.
- **Machine Not Turning On:**
 - Verify the power cord is securely plugged into a grounded outlet.
 - Check if the power outlet is functional by plugging in another appliance.

PRODUCT SPECIFICATIONS

Specification	Detail
Brand	Keurig
Model Name	K-Compact
Item Model Number	5000376527
Color	Turquoise
Product Dimensions	10.93"D x 14.53"W x 13.94"H
Item Weight	7.85 pounds
Water Reservoir Capacity	36 oz.
Brew Sizes	6, 8, 10 oz.
Special Feature	Space saving
Coffee Maker Type	Coffee Infuser
Filter Type	Reusable (not included)
Operation Mode	Fully Automatic
Voltage	1500 Volts
Auto-Off Feature	2 hours after last brew

PRODUCT VISUALS



The Keurig K-Compact in turquoise, actively brewing coffee into a white mug, showcasing its sleek design and functionality.

SPACE-SAVING DESIGN

Our slimmest removable reservoir coffee maker

 **3 CUP SIZES**

 **36oz RESERVOIR**

 **<1 MINUTE BREW TIME**



Visual representation of the Keurig K-Compact's space-saving design, along with key features like three brew sizes, a 36oz reservoir, and fast brew time.



 **3 CUP SIZES**
6, 8, 10oz

 **<1 MINUTE BREW TIME**
for fresh brewed coffee

 **ENERGY SAVER**
auto off

Detailed view of the intuitive control panel, featuring the power button and dedicated buttons for 6, 8, and 10 oz. brew sizes.



**REMOVABLE
DRIP TRAY**
Fits a 7.0"
travel mug



The removable drip tray of the Keurig K-Compact, designed to accommodate taller travel mugs for on-the-go convenience.



**PRODUCT
DIMENSIONS**

12.5" High
(16.3" High when open)
8.2" Wide
13.2" Deep
Weighs 6.9lbs



16.3"
(when open)

12.5"

8.2"

A clear diagram illustrating the compact dimensions of the Keurig K-Compact, including its height, width, and depth.



36oz
Removable
water reservoir



An overhead view highlighting the 36oz removable water reservoir, emphasizing its capacity and ease of access for refilling.

K-Compact™

SINGLE SERVE COFFEE MAKER

HOW THE K-CUP® POD WORKS



An illustrative diagram detailing the brewing process of a K-Cup pod, from hot water saturation to the extraction of full-flavored coffee.

Official Product Videos

No official product videos from the seller are available for this product at this time.

WARRANTY & SUPPORT

Keurig products typically come with a limited one-year warranty from the date of purchase. For detailed warranty information, product registration, and customer support, please refer to the official Keurig website or the full user manual.

For a comprehensive guide and additional support, please download the official user manual:

[Download Full User Manual \(PDF\)](#)