

[Manuals.plus](#) /

› [USonline911](#) /

› Electric Shaver Replacement Head User Manual

USonline911 52S

Electric Shaver Replacement Head User Manual

Brand: USonline911 | Model: 52S

1. PRODUCT OVERVIEW

This replacement foil and trimmer cassette head, model 52S, is designed to restore 100% performance to your electric shaver. It is an aftermarket replacement part, tested and quality controlled to ensure optimal function.

Compatible with various Braun Series 5 models, including: 5020, 5020s, 5030, 5030s, 5040, 5040s, 5050, 5050cc, 5070, 5070cc, 5090, and 5090cc.




Image: The 52S replacement head, shown both in its sealed packaging and as a standalone unit, highlighting its design and components.

2. KEY FEATURES

- **Ultrathin Omentum:** The 0.056 mm ultra-thin membrane fits perfectly to the skin, designed to capture more whiskers and effectively shave long and soft whiskers, reducing back shaving and enhancing comfort.
- **Floating Three Heads:** Engineered to shave different types of whiskers. It features two omentum heads for shorter stubble and a middle trimmer to evenly comb and trim longer whiskers, ensuring a smooth shave for both long and short beards.
- **Durable Design:** Manufactured to provide reliable performance, ensuring a close and comfortable shave.
- **Easy Replacement:** Designed for simple plug-and-play installation, allowing for quick and easy replacement of your old shaver head.

Ultrathin omentum

The 0.056 mm omentum fits perfectly into the skin, and the geometric omentum captures more whiskers, effectively shaving long/soft whiskers, reducing back shaving, and shaving comfort.



0.056 mm ultra-thin membrane and the skin perfect fit, 2000 + mesh beard root easily shaved.



Image: A detailed diagram illustrating the ultrathin omentum technology, showing how the 0.056 mm membrane and mesh capture beard roots for an efficient shave.

Floating three heads

Shave off different types of whiskers, 2 omentum grab shorter stubble, middle trimmer evenly comb and trim longer whiskers, easily shave long and short whiskers.



Short Beard



Long Beard



Image: An illustration demonstrating the effectiveness of the floating three heads on different beard lengths, from short stubble to longer whiskers.

3. INSTALLATION & REPLACEMENT

Replacing your shaver head is a simple process. Follow these steps to ensure proper installation and optimal performance.

3.1. Removing the Old Shaver Head

1. Ensure the shaver is turned off and unplugged from any power source.
2. Gently press the release buttons (if present) on the sides of the shaver head, or simply pull the head upwards to detach it from the shaver body.
3. Carefully remove the old foil and cutter block.

3.2. Installing the New Shaver Head

1. Align the new 52S replacement head with the shaver body.
2. Press down firmly until you hear a click, indicating it is securely in place.
3. Test the shaver by turning it on briefly to ensure the head is properly attached and functioning.

Your browser does not support the video tag.

Video: This video demonstrates the disassembly and reassembly process of a Braun shaver head, which is similar to replacing the 52S foil and cutter block. It shows how to remove the old head and attach the new one.

4. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your shaver head.

4.1. Cleaning the Shaver Head

The shaver replacement head is designed for easy cleaning. You can directly wash the high-quality knife net under running water to remove hair clippings and debris. Ensure the shaver is turned off and unplugged before cleaning.

Shaver replacement head

Easy to clean, easy to remove, direct washing, high-quality knife net, easy and smooth shaving clean beard.



Image: A visual representation of the shaver head in use, emphasizing its clean and smooth shaving capability, which is maintained through proper cleaning.

4.2. Recommended Replacement Schedule


Over time, the cutting parts of your shaver head will wear out, leading to a less close and comfortable shave. It is recommended to change your shaver's foil and cutter block every **18 months** to maintain maximum performance. This ensures the blades remain sharp and reduces skin friction.

Change the head on time

Easy to clean, easy to remove, recommended 18 months to replace the razor head, keep the head sharp, reduce skin friction.



Normal use



After 18 months the blade becomes dull and pulls at the skin

Image: A diagram illustrating the difference between a new, sharp blade and a dull blade after 18 months of use, highlighting why timely replacement is crucial for optimal shaving performance and skin comfort.

5. SPECIFICATIONS

Attribute	Value
Type	Series 5 Replacement Foil and Trimmer Cassette Head
Model	52S
Compatible Models	Braun Series 5 Models: 5020, 5020s, 5030, 5030s, 5040, 5040s, 5050, 5050cc, 5070, 5070cc, 5090, 5090cc
Item Weight	1.76 ounces

Attribute	Value
Manufacturer	USonline911
ASIN	B0CDBQDPZD

6. WARRANTY & SUPPORT

For any questions regarding installation, compatibility, or performance of your USonline911 52S Electric Shaver Replacement Head, please contact the manufacturer directly. This product is an aftermarket replacement part and is subject to the warranty and return policies of the seller.

You can visit the official USonline911 Store for more information: [USonline911 Store](#)

© 2024 USonline911. All rights reserved.

This manual is for informational purposes only. Always refer to your original shaver's manual for specific safety instructions.