watnature 47.2inch_L

watnature Large Outdoor Water Fountain User Manual

Model: 47.2inch_L

Brand: watnature

1. Introduction

Thank you for choosing the watnature Large Outdoor Water Fountain. This 9-tier outdoor garden fountain with LED lights is designed to bring a natural, stone-like waterfall feature to your patio, garden, lawn, or office decor. Crafted from durable resin with fiberglass, it offers a soothing and tranquil ambiance with its cascading water sounds and soft LED illumination. This manual provides essential information for safe setup, operation, and maintenance of your fountain.



Figure 1: The watnature Large Outdoor Water Fountain, showcasing its multi-tier design and integrated LED lights.

2. Package Contents

Please ensure all components are present and undamaged before proceeding with assembly:

- 1 x Water Fountain (built-in LED lights)
- 1 x Waterfall Fountain Pump with Power Cord and Plug
- 1 x LED Lights Plug
- 1 x Instruction Manual



Figure 2: Overview of the watnature fountain and its main accessories included in the package.

3. Safety Information

Read all instructions carefully before operating the fountain. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always disconnect the power supply before performing any maintenance or cleaning.
- Ensure the fountain is placed on a stable, level surface to prevent tipping.
- Do not operate the pump without water. This can damage the pump.
- Keep children and pets away from the fountain during operation, especially if they are unsupervised.
- Use only the provided pump and power adapter.
- Protect electrical cords from damage. Do not run cords under carpets or in areas where they can be tripped over.
- Do not immerse the plug or transformer in water.
- In freezing temperatures, drain the fountain completely and store it indoors to prevent damage.

4. Setup Instructions

Follow these steps to set up your watnature water fountain:

1. **Unpack and Inspect:** Carefully remove all components from the packaging. Inspect for any damage during transit.
2. **Positioning:** Choose a stable, level location for your fountain. Ensure it is near a power outlet and away from areas where splashing water could cause damage. The fountain dimensions are approximately 19.6"L x 13.9"W x 47.2"H.



Figure 3: Product dimensions for proper placement and setup.

3. **Connect Pump:** Locate the pump and the tubing inside the fountain. Connect the pump's outlet to the tubing. Ensure a secure fit.
4. **Submerge Pump:** Place the pump at the bottom of the fountain's reservoir, ensuring it is fully submerged in water once filled.
5. **Fill with Water:** Fill the fountain with distilled water until the pump is completely covered and the water level is sufficient for circulation. Do not overfill.
6. **Connect Power:** Connect the pump's power cord and the LED lights plug to their respective transformers/adapters. Then, plug the transformers into a grounded outdoor-rated electrical outlet.



Figure 4: The fountain in operation, showing water flow and LED illumination.

7. **Test Operation:** Once plugged in, the pump should start circulating water, and the LED lights should illuminate. Allow a few minutes for water to fully circulate and air bubbles to clear.

Your browser does not support the video tag.

Video 1: A demonstration of the watnature Large Outdoor Water Fountain in operation, showcasing its water flow and lighting effects.

5. Operating Instructions

Operating your watnature fountain is straightforward:

- **Power On/Off:** The fountain is controlled by plugging and unplugging it from the electrical outlet.
- **Water Flow Adjustment:** The pump typically has an adjustable flow rate switch. Refer to the pump's specific instructions for details on how to adjust the water speed to your preference.
- **Water Level:** Regularly check the water level, especially in warm weather, as water evaporates. Refill with distilled water as needed to ensure the pump remains fully submerged.

6. Maintenance

Regular maintenance will prolong the life and appearance of your fountain:

- **Cleaning:**
  - Periodically clean the fountain and pump to prevent mineral buildup and algae growth.
  - Disconnect power before cleaning.
  - Use a soft brush and mild soap with water to clean the fountain surface. Rinse thoroughly.
  - Clean the pump by disassembling it (refer to pump manual if necessary) and removing any debris from the impeller.
- **Water Quality:** Use distilled water to minimize mineral deposits. If using tap water, consider adding a fountain algaecide/clarifier (follow product instructions).
- **Winterization (for outdoor use):**
  - Before the first frost, completely drain all water from the fountain and pump.
  - Clean the fountain and pump thoroughly.
  - Store the fountain and pump indoors in a dry, frost-free location. Freezing water can crack the resin material.

7. Troubleshooting

If you encounter issues with your fountain, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fountain not working / No water flow	Not plugged in Low water level Pump clogged Pump broken	Ensure power cord is securely plugged into a working outlet. Add distilled water until the pump is fully submerged. Disconnect power, remove pump, and clean impeller and intake. Contact customer support if pump is damaged.
Water flow is weak	Low water level Pump clogged Kink in tubing Pump flow rate set too low	Add water. Clean pump. Check tubing for kinks or obstructions. Adjust pump flow rate switch to a higher setting.
LED lights not working	LED plug not connected LED transformer faulty LED lights damaged	Ensure LED plug is securely connected to its transformer and outlet. Test with another compatible transformer if available. Contact customer support for replacement parts.
Excessive splashing	Water level too high Pump flow rate too high Fountain not level	Remove some water. Adjust pump flow rate to a lower setting. Ensure fountain is on a perfectly level surface.

8. Specifications

Feature	Detail
Model	47.2inch_L
Dimensions (L x W x H)	19.6" x 13.9" x 47.2"
Material	Resin with fiberglass
Color	Gray_l
Power Source	Corded Electric
Special Features	Fade Resistant, Lighted, Weather Resistant, UV Resistant, Rust Resistant
Manufacturer	watnature

9. Warranty and Support

For any questions, concerns, or warranty inquiries regarding your watnature Large Outdoor Water Fountain, please contact watnature customer support. Refer to your purchase documentation for specific warranty terms and contact information.

You can also visit the official watnature store on Amazon for more information and support:watnature Amazon Store

© 2024 watnature. All rights reserved.