



Manuals.plus /

› Depulat /

› Depulat 4-in-1 Flame Aroma Essential Oil Diffuser Instruction Manual

Depulat HYB-02

Depulat 4-in-1 Flame Aroma Essential Oil Diffuser Instruction Manual

Brand: Depulat | Model: HYB-02

INTRODUCTION

Thank you for choosing the Depulat 4-in-1 Flame Aroma Essential Oil Diffuser. This versatile device combines the functions of an air humidifier, an essential oil diffuser, a Bluetooth speaker, and a white noise machine. Designed to enhance your environment, it features a stunning 7-color simulated flame effect, adjustable mist volume, and convenient remote control. Please read this manual thoroughly before use to ensure proper operation and maintenance.

IMPORTANT SAFETY PRECAUTIONS

- Avoid overfilling the water tank with more than 450ml of water.
- Keep the device out of reach of children and pets.
- The device features an automatic shut-off mechanism when the water runs out, safeguarding it from potential damage.
- Use only BPA-free essential oils.
- Avoid direct skin contact with undiluted essential oils.
- Ensure the device is placed on a stable, flat surface away from direct sunlight or heat sources.
- Do not block the mist outlet or air inlet during operation.

PACKAGE CONTENTS

- Depulat 4-in-1 Flame Aroma Essential Oil Diffuser Unit
- Remote Control
- USB Power Cable
- User Manual

SETUP GUIDE

1. Place the diffuser on a flat, stable surface.
2. Carefully remove the top cover of the diffuser.
3. Fill the water tank with up to 450ml of pure or distilled water. Do not exceed the 'Max Line' indicator.
4. Add 3-5 drops of your preferred essential oils (not included) directly into the water tank. Adjust quantity based on desired aroma intensity.
5. Replace the top cover securely.
6. Connect the USB power cable to the diffuser and plug it into a compatible USB power adapter (not included).

The diffuser is now ready for operation. You can use the remote control or the manual buttons on the unit to manage settings.

OPERATING INSTRUCTIONS

The Depulat diffuser can be operated using the buttons on the front panel or the included remote control. The front panel features buttons for power/mist, light, and timer/night mode. The remote offers more comprehensive control.

1. Essential Oil Diffuser Function

After filling the water tank and adding essential oils, press the mist button (looks like three wavy lines) on the unit or remote to start misting. The device uses ultrasonic technology to create a fine, gentle mist, effectively diffusing aromas throughout your space.



Figure 1: Adding essential oils to the diffuser. The transparent water tank is visible, showing the 'Max line' indicator.

2. Humidifier Function

The large 450ml water tank allows the device to function as a humidifier, providing moisture to the air. The mist volume is adjustable to suit your specific humidity needs. It can operate for up to 15 hours continuously on a full tank.



Figure 2: The humidifier function in action, showing mist output and highlighting the 450ML capacity.

3. Flame & Ambient Light Effects

Press the light button (looks like a sun icon) on the unit or remote to cycle through the 7-color flame effects. The combination of RGB lights and mist creates a visually appealing simulated flame. You can also dim the light for a softer ambiance, making it suitable as a night light.



Figure 3: The diffuser showcasing its 7-color ambient light options, creating various atmospheric effects.

4. Bluetooth Speaker Function

This diffuser doubles as a Bluetooth speaker. To pair, ensure Bluetooth is enabled on your smartphone or audio device. Search for 'Depulat' in your device's Bluetooth settings and connect. You can then stream your favorite music through the diffuser's integrated speaker.




Figure 4: Illustration of the diffuser's Bluetooth speaker capability, showing seamless music streaming.

5. White Noise Machine

The device comes with sleep-assisting white noises to help you relax and fall asleep. These include the gentle patter of rain, the crackling of a campfire, and the sweet chirping of birds. Use the dedicated white noise button on the remote to cycle through these sounds.



Figure 5: Visual representation of the sleep-assisting white noises available, including nature sounds.

6. Timer and Auto-Off Function

Customize the operating duration using the timer function. Available settings typically include 1 hour, 3 hours, and 6 hours. The device will automatically shut off when the selected time elapses or when the water level in the tank becomes too low, ensuring safety and energy efficiency.

Aromatherapy Difusser Enjoy your life

Add 2-3 drops essential oil inside the aroma comes to relax the whols body



Figure 6: The diffuser highlighting its 3 modes timer function for scheduled operation.

7. Remote Control Operation

The included remote control allows for convenient adjustment of all functions from a distance. Buttons typically include power, mist intensity, light color/mode, timer settings, and white noise selection.



Figure 7: The main product image showing the diffuser unit and its remote control.

MAINTENANCE

Regular cleaning is essential to ensure the longevity and optimal performance of your diffuser.

- **Daily Cleaning:** After each use, empty any remaining water from the tank. Wipe the inside of the water tank and the lid with a clean, soft cloth.
- **Weekly Cleaning:** For a more thorough clean, add a small amount of white vinegar to the water tank and let it sit for 10-15 minutes. Gently wipe the tank and the ultrasonic disc with a cotton swab or soft brush. Rinse thoroughly with clean water, ensuring no vinegar residue remains.
- **Avoid Harsh Chemicals:** Do not use corrosive detergents or abrasive materials, as these can damage the unit.
- **Air Dry:** Allow all parts to air dry completely before reassembling or storing.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No mist output	Low water level; Power not connected; Mist button not pressed.	Refill water tank; Ensure power cable is securely connected; Press the mist button.
Weak mist output	Insufficient water; Dirty ultrasonic disc; Blocked mist outlet.	Refill water; Clean the ultrasonic disc; Clear any obstructions from the mist outlet.
No light effect	Light button not pressed; Device not powered on.	Press the light button; Ensure the device is powered on.
Bluetooth not connecting	Bluetooth not enabled on device; Incorrect pairing.	Ensure Bluetooth is on and visible; Re-pair the device (search for 'Depulat').
Device leaking	Overfilled water tank; Lid not properly secured.	Do not overfill past the 'Max Line'; Ensure the lid is correctly and tightly placed.
Remote control not working	Battery drained; Obstruction between remote and unit.	Replace remote battery; Ensure clear line of sight to the unit's sensor.

SPECIFICATIONS

Brand	Depulat
Model Name	Bluetooth Aromatherapy Diffusers
Item Model Number	HYB-02
Color	Transparent Black
Material	Acrylonitrile Butadiene Styrene (ABS)
Product Dimensions	7.87"L x 3.94"W x 5.35"H
Item Weight	1.08 Pounds
Capacity	450 Milliliters
Runtime	Up to 15 hours
Power Source	Corded Electric
Wattage	20 watts
Special Features	7-Color Flame Effect, Bluetooth Speaker, White Noise Machine, Remote Control, Auto Shutoff
Auto Shutoff	Yes
Country of Origin	China
UPC	671716943204

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided on the product packaging or visit the official Depulat website. Keep your purchase receipt as proof of purchase for any warranty claims.