

manuals.plus /

› [YCCTEAM](#) /

› [YCCTEAM Wireless Game Controller User Manual](#)

YCCTEAM YCCTEAM Wireless Game Controller

YCCTEAM Wireless Game Controller User Manual

Model: YCCTEAM Wireless Game Controller

Brand: YCCTEAM

1. PRODUCT OVERVIEW

The YCCTEAM Wireless Game Controller is designed for an immersive gaming experience across multiple platforms. It features enhanced dual vibration, precise analog sticks, and a 6-axis motion sensor. This controller is compatible with PS4, PS4 Slim, PS4 Pro, PC (Windows 7/8/10/11), Android, iOS, and Mac devices.



Image: Front view of the YCCTEAM Wireless Game Controller.

2. PACKAGE CONTENTS

Please check the package contents upon unboxing to ensure all items are present:

- 1 x YCCTEAM Wireless Controller
- 1 x USB Charging Cable
- 1 x Instruction Manual

What's in the box

1X Wireless Controller
1X USB Cable
1X Instruction Manual



Image: The package includes one wireless controller, one USB cable, and one instruction manual.

3. PRODUCT FEATURES

- **Wide Compatibility:** Compatible with PS4, PS4 Slim, PS4 Pro, PC (Windows 7/8/10/11), Android, iOS, and Mac. Note: PC connection may require a receiver (not included) or a USB cable.
- **Enhanced Vibration & Motion Sensing:** Features dual motor vibration and a 6-axis gyro sensor for immersive feedback and precise control.
- **Precise Analog Sticks & Touchpad:** 360° refined analog sticks with no dead zone and a new touch pad for accurate input.

Highly-sensitive Analog Stick and Excellent Response Time

There's nothing new about that, but both felt highly-sensitive, which led to more accurate and enjoyable gameplay.



Smooth 360°
Joysticks



Image: Close-up of the controller highlighting the highly-sensitive analog sticks for precise control.

- **Audio Options:** Built-in speaker and a 3.5mm headset jack for versatile audio output.

Built-in speakers and immersive Gameplay

There's nothing new about that, but both felt highly-sensitive,
which led to more accurate and enjoyable gameplay.



Built-in
Speakers



3.5mm Stereo
Audio Jack

Image: Diagram showing the location of the built-in speaker and 3.5mm audio jack on the controller.

- **Ergonomic Design:** Optimized buttons, triggers, and non-slip grips provide comfortable handling during extended gaming sessions.

Extremely simple and truly ergonomic

Share and options button offer exciting ways to experience your games and share your greatest moments.



Ergonomic
Design



Image: Two controllers demonstrating the ergonomic design for comfortable use.

- **Integrated Light Bar:** Provides real-time feedback on controller status.
- **Stable Wireless Connection:** Utilizes stable wireless technology with a maximum connection distance of 10 meters.
- **Long Battery Life:** Equipped with a 1000mAh battery, offering 6-8 hours of playtime on a 2-3 hour charge.

4. SETUP GUIDE

4.1 Connecting to PS4/PS4 Slim/PS4 Pro

To connect the controller to your PS4 console:

1. Ensure your PS4 console is powered on.
2. Connect the controller to the PS4 console using the provided USB charging cable.
3. Press the PS button on the controller. The light bar will flash, indicating it's pairing.
4. Once the light bar turns solid, the controller is successfully paired and ready for use. You can then disconnect the USB cable for wireless play.

Use your Wireless Controller on PS-4/ Slim/Pro to its full potential



PS-4



PS-4 SLIM



PS-4 PRO



Image: The controller shown with PS4, PS4 Slim, and PS4 Pro consoles, indicating compatibility.

4.2 Connecting to PC (Windows 7/8/10/11)

For PC connection, a receiver (not included) is recommended for wireless play. Alternatively, you can connect via USB cable or Bluetooth if your PC has Bluetooth functionality.

Via USB Cable:

1. Connect the controller to your PC using the USB charging cable.
2. The PC should automatically detect and install the necessary drivers.
3. For Steam games, open Steam and navigate to "Account" > "Controller" > "Controller Settings". Check the box for "PlayStation Configuration Support" to ensure proper mapping.

Via Bluetooth (if PC has Bluetooth):

1. On your PC, go to Bluetooth settings and ensure Bluetooth is enabled.
2. On the controller, press and hold the "Share" button and the "PS" button simultaneously until the light bar starts flashing rapidly. This indicates pairing mode.
3. On your PC, search for new Bluetooth devices. Select "Wireless Controller" when it appears.
4. Once paired, the light bar will turn solid.

4.3 Charging the Controller

To charge the controller:

- Connect the USB charging cable to the controller's charging port.
- Connect the other end of the USB cable to a PS4 console, PC, or a standard USB wall adapter (5V/1A).
- The light bar will slowly pulse orange while charging. It will turn off when fully charged.
- A full charge typically takes 2-3 hours.



Image: Close-up of the controller's USB port, indicating charging capability.

5. OPERATING INSTRUCTIONS

5.1 Basic Controls

The controller features standard button layouts for intuitive gameplay:

- **D-Pad:** Directional input.
- **Analog Sticks (Left/Right):** 360° movement for precise control.
- **Action Buttons (X, O, Square, Triangle):** Primary game actions.
- **L1/R1, L2/R2 Buttons:** Shoulder and trigger buttons.

- **Share Button:** Quickly share screenshots and video clips.
- **Options Button:** Access in-game menus and options.
- **PS Button:** Power on/off the controller, access PS4 home menu.

Your browser does not support the video tag.

Video: A demonstration of the YCCTEAM wireless controller in use, highlighting its responsiveness and features. This video shows the controller's design and basic functionality.

5.2 Using Special Features

- **Touch Pad:** The clickable touch pad on the front of the controller can be used for navigation and specific in-game actions.



Image: Close-up of the controller's touch pad and light bar, illustrating their interactive elements.

- **Light Bar:** The integrated light bar changes color to indicate player number, health status, or other in-game information.
- **3.5mm Headset Jack:** Plug in your compatible headset for game audio and voice chat.




Image: Close-up view of the 3.5mm stereo headset jack located on the bottom of the controller.

- **Dual Motor Vibration:** Provides haptic feedback for in-game events, enhancing immersion.



Image: Diagram illustrating the dual motor vibration components within the controller's grips.

- **Motion Sensor:** The built-in 6-axis motion sensor allows for motion-controlled gameplay in supported titles.



Image: Graphic representing the motion sensing capabilities of the controller.

6. MAINTENANCE

Proper care will extend the life of your controller:

- Keep the controller clean by wiping it with a soft, dry cloth.
- Avoid exposing the controller to extreme temperatures, humidity, or direct sunlight.
- Do not disassemble the controller, as this may void the warranty and cause damage.
- Store the controller in a safe place when not in use to prevent accidental drops or damage.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Controller does not turn on.	Low battery.	Charge the controller using the provided USB cable.

Problem	Possible Cause	Solution
Controller does not connect to PS4/PC.	Not paired correctly; out of range; interference.	Ensure the controller is fully charged. Reconnect the controller via USB cable to re-pair. Move closer to the console/PC. Restart the console/PC and try again.
Input lag or unresponsiveness.	Wireless interference; low battery; driver issue (PC).	Charge the controller. Reduce distance to console/PC. Ensure no other wireless devices are causing interference. For PC, update or reinstall controller drivers.
Vibration not working.	Feature disabled in game/system settings; malfunction.	Check in-game settings and console/PC settings to ensure vibration is enabled. If problem persists, contact customer support.

8. SPECIFICATIONS

Feature	Detail
Model	YCCTEAM Wireless Game Controller
Compatibility	PS4, PS4 Slim, PS4 Pro, PC (Windows 7/8/10/11), Android, iOS, Mac
Connectivity	Wireless (Bluetooth), USB Wired
Battery Capacity	1000mAh
Charging Time	Approx. 2-3 hours
Play Time	Approx. 6-8 hours (on full charge)
Wireless Range	Up to 10 meters (33 feet)
Sensors	6-axis motion sensor (gyroscope, accelerometer)
Vibration	Dual motor vibration
Audio Port	3.5mm stereo headset jack
Dimensions	6.69 x 4.65 x 2.64 inches (approximate)
Weight	10.8 ounces (approximate)





9. WARRANTY AND SUPPORT

YCCTEAM products are designed for reliability and performance. For warranty information, technical support, or any inquiries regarding your YCCTEAM Wireless Game Controller, please refer to the contact information provided on the product packaging or visit the official YCCTEAM website.

Please retain your proof of purchase for warranty claims.

© 2023 YCCTEAM. All rights reserved.


Related Documents - YCCTEAM Wireless Game Controller

 <p>Wireless game controller for PS4/PS4 Slim/PS4 Pro/PC</p> <p>Instruction Manual</p>	<p>YCCTEAM Wireless Controller Instruction Manual for PS4, PS4 Slim, PS4 Pro, PC</p> <p>Detailed instruction manual for the YCCTEAM wireless game controller, compatible with PS4, PS4 Slim, PS4 Pro, and PC. Covers controller diagram, connection, and pairing instructions.</p>
 <p>Wireless Pro game controller for Switch/Switch Lite/OLED</p> <p>User Guide</p>	<p>YCCTEAM Wireless Pro Controller User Guide for Nintendo Switch, Switch Lite, OLED</p> <p>Official user guide for the YCCTEAM Wireless Pro Controller. Learn how to connect, use features, and troubleshoot your controller for Nintendo Switch, Switch Lite, and OLED consoles, plus PC compatibility.</p>
 <p>YCCTEAM®</p> <p>Wireless Pro game controller for Switch/Switch Lite</p> <p>User Guide</p> <p>Model: YCC-SW4001</p> <p>Instruction Manual</p>	<p>YCCTEAM YCC-SW4001 Wireless Pro Controller User Guide for Nintendo Switch/Lite and PC</p> <p>Comprehensive user guide for the YCCTEAM YCC-SW4001 Wireless Pro game controller, detailing features, connection instructions for Nintendo Switch/Lite and PC, LED indicators, parameters, precautions, and testing.</p>
	<p>YCCTEAM SW4004ZX-H Wireless Pro Controller for Nintendo Switch User Guide</p> <p>This user guide provides detailed instructions for the YCCTEAM SW4004ZX-H Wireless Pro Controller, covering its features, connection methods for Nintendo Switch and PC, button functions, LED indicators, calibration, and technical specifications. It also includes FCC compliance information.</p>



[YCCTEAM SW4007MZ-H Switch Pro Controller User Guide for Nintendo Switch & PC](#)

Official user guide for the YCCTEAM SW4007MZ-H Wireless Pro Controller. Learn about features, connection instructions for Nintendo Switch and PC, LED indicators, specifications, and troubleshooting. Includes FCC compliance information.



[YCCTEAM X-ONE Power Supply for Xbox One: Instruction Manual & Specifications](#)

Comprehensive guide for the YCCTEAM X-ONE Power Supply (Model: YCC-XB043) for Xbox One consoles. Includes setup, usage tips, safety information, troubleshooting, and specifications.