

[Manuals.plus](#) /

› [OLEVS](#) /

› OLEVS Men's Diamond Watch User Manual

OLEVS 5513

OLEVS Men's Diamond Watch User Manual

Brand: OLEVS | Model: 5513 (ASIN: B0CDBWMSQB)

1. PRODUCT OVERVIEW

The OLEVS Men's Diamond Watch is a sophisticated timepiece featuring a quartz movement, a durable stainless steel construction, and a luxurious design. It is designed for business and dress occasions, offering accurate timekeeping and a refined aesthetic with diamond and Roman numeral hour markers, along with double date windows.



Figure 1.1: Front view of the OLEVS Men's Diamond Watch, showcasing its blue dial, diamond hour markers, and stainless steel band.

2. PRODUCT FEATURES

- **Quartz Movement:** Utilizes an imported original quartz movement for stable and accurate timekeeping, powered by a high-quality battery.
- **Luxury Design:** Features a business-oriented design with luxurious diamond and Roman numeral hour markers, complemented by double date windows for enhanced functionality and style.
- **Stainless Steel Construction:** The watch strap is crafted from durable, hand-polished stainless steel, providing a smooth and shiny finish. It includes a double-press folding safety buckle for a secure and comfortable fit.
- **Water Resistance:** Rated 3ATM (89ft) waterproof, offering protection against daily activities such as handwashing and accidental splashes. *Note: Avoid hot water to prevent water vapor from entering the watch lens.*
- **Luminous Display:** Equipped with luminous elements for visibility in low-light conditions.



Figure 2.1: The watch demonstrating its 30-meter water resistance against splashes.

3. SETUP

3.1 Initial Setup and Time/Date Adjustment

Your OLEVS watch comes pre-set, but you may need to adjust the time and date upon first use or after a period of inactivity.

1. **Setting the Time:** Gently pull the crown (the knob on the side of the watch) out to the furthest position. Rotate the crown to move the hands clockwise until the desired time is displayed. Push the crown back in to secure the time.
2. **Setting the Date/Day:** Pull the crown out to the first click position. Rotate the crown to adjust the date and day. Be careful not to adjust the date between 9 PM and 3 AM, as this can damage the movement. Push the crown back in once set.

3.2 Adjusting the Watch Band

The stainless steel band can be adjusted to fit your wrist. The watch typically comes with tools for this purpose. It is recommended to perform this adjustment on a stable surface with good lighting.

1. Identify the removable links on the watch band. These usually have small arrows indicating the direction to push the pins out.
2. Use the provided tool to push the pins out in the direction of the arrows. Remove the necessary number of links to achieve a comfortable fit.
3. Reassemble the band by inserting the pins back into the links, ensuring they are securely in place.

Your browser does not support the video tag.

Video 3.1: Demonstration of the OLEVS watch on a wrist and a close-up of the clasp mechanism, which is relevant for band adjustment.



Figure 3.1: The OLEVS watch comfortably fitted on a wrist.

4. OPERATING INSTRUCTIONS

4.1 Timekeeping

The watch operates continuously once the time is set and the crown is fully pushed in. The quartz movement ensures precise timekeeping.

4.2 Day and Date Display

The watch features a double date window displaying both the day of the week and the numerical date. These can be adjusted as described in Section 3.1.



Figure 4.1: The OLEVS watch in use, displaying its day and date features.

5. MAINTENANCE

- **Cleaning:** Wipe the watch regularly with a soft, dry cloth to remove dust and smudges. For the stainless steel band, a slightly damp cloth can be used, followed by immediate drying.
- **Water Resistance Care:** While the watch is 3ATM waterproof, it is not suitable for swimming, diving, or showering with hot water. Always ensure the crown is fully pushed in before any contact with water.
- **Battery Replacement:** As a quartz watch, it requires battery replacement periodically. When the watch stops or runs inconsistently, it may be time for a new battery. It is recommended to have this done by a professional watch repair service to maintain water resistance.
- **Storage:** When not in use for extended periods, store the watch in a cool, dry place away from direct sunlight and strong magnetic fields.

6. TROUBLESHOOTING

- **Watch Not Running:**

- Check if the crown is fully pushed in.
- The battery may need replacement. Consult a professional watch repair service.

- **Incorrect Time/Date:**

- Refer to Section 3.1 for instructions on setting the time and date.

- **Condensation Inside Crystal:**

- This indicates moisture ingress. Stop using the watch immediately and take it to a professional for inspection and repair to prevent further damage.

7. SPECIFICATIONS



WATCH PARAMETERS

Movement: quartz movement

Waterproof: 30 meters waterproof

Strap: Precision steel watch chain

Watch mirror: high hardness coated mirror.

Watch buckle: folding buckle

Case thickness: 10mm

Strap width: 20mm

Dial diameter: 39mm

Strap circumference: 22.5cm

Weight: 108g

Note, all dimensions are measured by hand, there will be some errors, please refer to the actual product

Figure 7.1: Detailed watch parameters including dimensions and materials.

OLEVS Men's Diamond Watch - Key Specifications

Feature	Detail
Movement Type	Quartz Movement
Case Material	Stainless Steel
Band Material	Stainless Steel
Water Resistance	3ATM (89ft)
Dial Features	Diamond and Roman Numeral Hour Markers, Day/Date Windows, Luminous Hands
Case Thickness	10mm (approx.)
Dial Diameter	39mm (approx.)
Strap Width	20mm (approx.)
Strap Circumference	22.5cm (approx.)
Weight	108g (approx.)
Item Model Number (ASIN)	B0CDBWMSQB
Date First Available	August 1, 2023

8. WARRANTY AND SUPPORT

OLEVS offers a **1-year warranty** for this watch, covering manufacturing defects from the date of purchase. Additionally, a **30-day free return** policy is available.

For warranty claims, technical support, or any inquiries regarding your OLEVS watch, please contact the seller or manufacturer directly through the platform where the purchase was made. Please retain your proof of purchase for warranty validation.

Note: Damage caused by improper use, unauthorized repairs, or failure to follow maintenance guidelines is not covered under warranty.