

Manuals.plus /

› Braun /

› Braun CareStyle 1 Pro IS 1511 WH Steam Generator Iron User Manual

Braun IS 1511 WH

Braun CareStyle 1 Pro IS 1511 WH Steam Generator Iron User Manual

Model: IS 1511 WH

1. INTRODUCTION AND SAFETY INFORMATION

Thank you for choosing the Braun CareStyle 1 Pro IS 1511 WH Steam Generator Iron. This manual provides essential information for safe and efficient use of your appliance. Please read all instructions carefully before first use and keep them for future reference.

Important Safety Instructions:

- Always ensure the voltage matches your power supply.
- Do not leave the iron unattended while it is switched on or connected to the mains.
- Keep the appliance out of reach of children.
- Never immerse the iron or base unit in water or other liquids.
- Do not touch the hot soleplate.
- Unplug the appliance before filling the water tank, cleaning, or when not in use.

2. PRODUCT OVERVIEW

The Braun CareStyle 1 Pro IS 1511 WH is a powerful steam generator iron designed for efficient and effective garment care. It features advanced technologies for superior ironing results.



Figure 2.1: Main unit of the Braun CareStyle 1 Pro IS 1511 WH Steam Generator Iron, showing the iron resting on its base with the removable water tank.

Key Components:

- **Iron Unit:** Lightweight and ergonomically designed for comfortable handling.
- **SuperCeramic FreeGlide 3D Soleplate:** Features an upwardly curved design for 360° glide, effortlessly moving over buttons and pockets.
- **Base Unit:** Houses the steam generator and removable water tank.
- **1.7 L Removable Water Tank:** Large capacity for extended ironing sessions without frequent refilling.
- **Precision Thermostat Dial:** Allows selection of four temperature settings suitable for various fabric types.
- **Steam Button:** Activates powerful steam output.



Figure 2.2: Close-up view of the SuperCeramic FreeGlide 3D soleplate, highlighting its unique curved design for smooth gliding.

3. SETUP AND FIRST USE

3.1 Unpacking

Carefully remove all packaging materials and ensure all components are present. Retain packaging for storage or transport if needed.

3.2 Filling the Water Tank

1. Ensure the appliance is unplugged from the power outlet.
2. Remove the 1.7-liter water tank from the base unit.
3. Fill the tank with tap water up to the 'MAX' indicator. For areas with very hard water, a mixture of 50% tap water and 50% distilled water is recommended. Do not use perfumed water or additives.
4. Replace the water tank securely into the base unit.



Figure 3.1: Demonstrating the removal and refilling of the 1.7L water tank.

3.3 First Use

During the first few minutes of use, a slight odor may be noticeable. This is normal and will disappear quickly. It is recommended to iron an old piece of fabric first to ensure no residue is transferred to your garments.

4. OPERATING INSTRUCTIONS

4.1 Powering On and Temperature Selection

1. Place the steam generator iron on a stable, heat-resistant surface.
2. Plug the power cord into a suitable electrical outlet.
3. Turn the precision thermostat dial to select the desired temperature setting for your fabric type. Refer to the garment care label for guidance.
4. Wait for the indicator light to signal that the iron has reached the selected temperature.

4.2 Steam Generation and Ironing

The CareStyle 1 Pro features **DoubleSteam Technology**, producing powerful continuous steam (up to 360 g/min, 5.5 bar pressure) to cut ironing time by half.

- Press and hold the steam button on the iron handle to release steam. Release the button to stop steaming.
- The **FreeGlide 3D Soleplate** allows for effortless gliding in all directions, even backward over obstacles like buttons and zippers, preventing snagging.
- The digital anti-drip system prevents water stains on your garments.



Figure 4.1: A user demonstrating the ironing process with the Braun CareStyle 1 Pro, showing steam being applied to a garment.

4.3 Vertical Steaming

For quick refreshing of hanging garments, curtains, or delicate fabrics, use the vertical steaming function:

1. Hang the garment on a hanger.
2. Set the iron to a high temperature setting.
3. Hold the iron vertically a few centimeters away from the fabric and press the steam button. Move the iron up and down the garment.

4.4 Automatic Shut-off

For safety and energy saving, the appliance features an automatic shut-off function. If left unused for 10 minutes, the iron will automatically turn off.

5. MAINTENANCE AND STORAGE

5.1 Cleaning the Soleplate

To clean the soleplate, ensure the iron is unplugged and cool. Wipe the soleplate with a damp cloth and a non-abrasive liquid cleaner if necessary. Do not use abrasive pads or harsh chemicals.

5.2 Easy CalcClean System

The **Easy CalcClean system** with a reminder function helps maintain optimal steam performance and prolong the life of your appliance by removing limescale buildup. Follow the instructions in the dedicated CalcClean section of the full manual (not included here) when the reminder light illuminates.

5.3 Storage

After use, unplug the iron and allow it to cool completely. Empty any remaining water from the tank. Store the iron securely on its base unit in a dry, safe place.

6. TROUBLESHOOTING

If you encounter issues with your Braun CareStyle 1 Pro, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No steam is produced.	Water tank is empty. Iron not hot enough. Steam button not pressed.	Fill the water tank. Wait for the iron to heat up. Press the steam button firmly.
Water drips from the soleplate.	Temperature setting is too low for steam.	Increase the temperature setting. Wait for the iron to reach the correct temperature before using steam.
Iron does not heat up.	Appliance not plugged in. Automatic shut-off activated.	Check power connection. Turn the iron off and on again, or move it to reactivate.

If the problem persists after trying these solutions, please contact customer support.

7. SPECIFICATIONS

- **Model:** IS 1511 WH
- **Power:** 2200 Watts
- **Voltage:** 240 Volts
- **Steam Pressure:** 5.5 bar
- **Steam Output:** Up to 360 g/min (based on product description)
- **Water Tank Capacity:** 1.7 Liters (removable)
- **Soleplate Material:** SuperCeramic FreeGlide 3D
- **Product Dimensions (L x W x H):** 36 x 18 x 25 cm
- **Item Weight:** 2.8 Kilograms
- **Special Features:** Automatic Shut-off, Precision Thermostat with 4 settings, Easy CalcClean System, Anti-drip function, Vertical Steam.
- **Country of Origin:** China

8. WARRANTY AND SUPPORT

Braun products are manufactured to the highest quality standards. This product is covered by a manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions, including warranty duration and coverage details.

For technical assistance, spare parts, or service, please visit the official Braun website or contact your local Braun customer service center. Contact information can typically be found in the full product manual or on the Braun website.

