



Manuals.plus /

› Amgico /

› Amgico Digital Alarm Clock (Model: GH0717) Instruction Manual

## Amgico GH0717

# Amgico Digital Alarm Clock (Model: GH0717) Instruction Manual

Your comprehensive guide to setup, operation, and maintenance.

## INTRODUCTION

---

Thank you for choosing the Amgico Digital Alarm Clock, Model GH0717. This device features an 11.5-inch large LED display, showing time, date, calendar, and indoor temperature. Designed for versatility, it can be used as a desk or wall clock. This manual provides detailed instructions to help you set up and operate your new clock effectively.

## PACKAGE CONTENTS

---

Please verify that all items are present in your package:

- 1 x Amgico Digital Wall Clock (Model: GH0717)
- 1 x 5V DC Power Cord
- 1 x 5V 1A Power Adapter
- 1 x Wireless Remote Control
- 2 x CR2032 Batteries (for backup)
- 1 x Product Manual
- Mounting accessories (e.g., stands, hooks, screws)



Image: Amgico Digital Alarm Clock with included accessories: power adapter, USB cable, remote control, CR2032 battery, and mounting hardware.

## SETUP

### Power Connection

1. Insert the 5V DC power cord into the designated input port on the back of the clock.
2. Connect the power adapter to the power cord.
3. Plug the power adapter into a standard electrical outlet. The clock is designed for external power and is not battery-powered for primary operation.
4. Install the included CR2032 backup battery into the battery compartment on the back of the clock. This battery retains time and settings during a power outage but does not power the display.



Image: The Amgico Digital Alarm Clock displaying time, date, and temperature, shown with its remote control and power adapter.

## Mounting Options

The clock can be placed on a desk or mounted on a wall:

- **Desk Placement:** Attach the two sturdy stands to the bottom of the clock for stable placement on any flat surface.
- **Wall Mounting:** Use the integrated hanging holes on the back of the clock. Securely fasten the clock to a wall using appropriate screws or hooks (included).



Image: The Amgico Digital Alarm Clock displayed in different environments, including a bedroom, living room, office, and for seniors, illustrating its versatility as a desk or wall clock.

## OPERATING INSTRUCTIONS

### Using the Remote Control

The wireless remote control allows for convenient adjustment of settings from up to 30 feet away.

# 30 Feet Remote Control

## Wireless Control for Snooze




Image: A hand holding the wireless remote control, demonstrating its use to adjust the Amgico Digital Alarm Clock from a distance.

### Setting Time and Date

1. Press the "SET" button on the remote control or the corresponding button on the back of the clock.
2. Use the "+" and "-" buttons to adjust the hour, then press "OK" or "SET" to confirm and move to minutes.
3. Repeat the process for minutes, year, month, and day.
4. Select 12-hour or 24-hour format using the "12/24H" button.
5. Choose between Fahrenheit (°F) or Celsius (°C) for temperature display using the "°C/°F" button.

# 4 Level Dimmer

Choose Your Suitable Brightness for Day/Night



L4

L3

L2

L1



Image: The Amgico Digital Alarm Clock showing the time, date, day of the week, and indoor temperature clearly on its large LED display.

## Alarm Settings

The clock features a loud alarm suitable for heavy sleepers and a snooze function.

1. Press the "ALARM" button on the remote or the back of the clock to enter alarm setting mode.
2. Use the "+" and "-" buttons to set the desired alarm time.
3. Press "OK" or "SET" to confirm.
4. To activate the snooze function, press the "SNOOZE" button on top of the clock or the remote when the alarm sounds.
5. To turn off the alarm, press the "ALARM OFF" button on the remote.

# Loud Alarm Clock for Heavy Sleepers



Image: The Amgico Digital Alarm Clock on a nightstand, illustrating its alarm function with musical notes emanating from the display, indicating a loud alarm suitable for heavy sleepers.

## Brightness Adjustment

The clock offers 4 levels of brightness and an auto-dimming feature to suit various lighting conditions and preferences.

1. Press the "LIGHT" button on the remote control or the corresponding button on the back of the clock to cycle through the 4 brightness levels.
2. The auto-dimming feature adjusts the display brightness automatically based on ambient light, ensuring optimal visibility without disturbing sleep.

# Large Display Digital Clock



Traditional Clock



Digital Clock



Amgico Large Clock



Image: A visual representation of the Amgico Digital Alarm Clock's 4-level dimmer function, showing different brightness settings for day and night use.

## Language Selection

The clock supports 7 languages for the day of the week display: English, German, French, Spanish, Italian, Dutch, and DR.

1. Refer to the detailed product manual for specific instructions on how to change the display language.

## MAINTENANCE

- Clean the clock's display and body with a soft, dry cloth. Avoid using abrasive cleaners or solvents.
- Ensure the clock is always connected to its external power supply for continuous operation. The CR2032 battery is for backup only.

- Replace the CR2032 backup battery annually or as needed to ensure settings are retained during power interruptions.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Clock display is off.	No power supply.	Ensure the power cord and adapter are securely connected to the clock and a working electrical outlet.
Settings are lost after power outage.	Backup battery is dead or missing.	Replace the CR2032 backup battery.
Remote control not working.	Remote battery is dead or obstruction.	Ensure there are no obstructions between the remote and the clock. Replace the remote control batteries.
Alarm is not loud enough.	Volume setting is low.	Adjust the alarm volume using the controls on the back of the clock or the remote.

## SPECIFICATIONS

Feature	Detail
Brand	Amgico
Model Number	GH0717
Display Type	Digital LED
Screen Size	11.5 inches
Product Dimensions	9.8"W x 6.3"H
Power Source	Corded Electric (5V 1A adapter)
Backup Battery	1 x CR2032 (included)
Special Features	Adjustable Brightness, Calendar Display, Large Display, Loud Alarm, Snooze, Indoor Temperature, 7 Languages
Mounting Type	Desk Stand / Wall Mount
Material	Polycarbonate (PC)
Item Weight	1.28 pounds

## OFFICIAL PRODUCT VIDEOS

---

### Amgico Digital Wall Clock Features

Your browser does not support the video tag.

Video: This video demonstrates the various features of the Amgico Digital Wall Clock, including its RGB color modes, pure color modes, and the requirement for external power. It highlights the different display options and how to freeze a favorite color.

## WARRANTY AND SUPPORT

---

The Amgico Digital Alarm Clock comes with a 12-month warranty.

For any questions or support regarding your product, please contact Amgico customer service. Refer to the product packaging or the official Amgico website for contact details.