

Teka 112540010

TEKA Vitroceramic Hob User Manual

Model: TCC 64310 TTC BK (112540010)

Brand: Teka

PRODUCT OVERVIEW

The TEKA TCC 64310 TTC BK Vitroceramic Hob is designed for modern kitchens, offering intuitive control and efficient cooking. It features Touch Control technology with acoustic sensors for precise operation, a safety lock to prevent accidental changes, and a programmable timer for all cooking zones. The Power Plus function provides an extra boost for rapid heating, while its four High Light cooking zones accommodate various pot and pan sizes. The sleek ceramic glass surface ensures easy cleaning and adds a sophisticated touch to your countertop.




Image: Top-down view of the TEKA TCC 64310 TTC BK Vitroceramic Hob with its four heating zones illuminated, indicating active operation. The touch control panel is visible at the bottom center.

SAFETY INSTRUCTIONS

- Read all instructions carefully before installation and use.
- Ensure the appliance is installed by a qualified technician in accordance with local regulations.
- Do not touch hot surfaces. Always use oven mitts or pot holders.
- Supervise children closely when the appliance is in use.
- Never leave cooking unattended, especially when using high heat settings.
- Do not store flammable materials on or near the hob.
- Disconnect the appliance from the power supply before cleaning or maintenance.
- Avoid placing metal objects like knives, forks, spoons, and lids on the hob surface as they can get hot.

SETUP AND INSTALLATION

Unpacking

Carefully remove the hob from its packaging. Inspect for any damage during transit. Keep packaging materials for

future transport or disposal.

Electrical Connection

The appliance must be connected to the mains electricity supply by a qualified electrician. Ensure the voltage and frequency match the specifications on the rating plate. The hob requires a dedicated circuit with appropriate fusing.

Mounting into Countertop

Ensure the countertop opening dimensions are accurate. Refer to the diagram below for precise measurements. The hob should be securely fitted and sealed to prevent moisture ingress.




Image: Detailed technical drawing illustrating the precise dimensions (in centimeters) required for cutting the countertop opening for the TEKA TCC 64310 TTC BK Vitroceramic Hob. Key measurements include 590mm width, 510mm depth, and corner radii of R140.

OPERATING INSTRUCTIONS

Touch Control Panel

The hob is operated via a sensitive touch control panel. Lightly touch the desired symbols to activate functions. An acoustic signal confirms each touch.



Conoce las distintas gamas de electrodomésticos TEKA

Image: A detailed view of the touch control panel on the TEKA TCC 64310 TTC BK Vitroceramic Hob, showing various symbols for power levels, timer, and special functions like Power Plus and safety lock.

Turning On/Off

- To turn on: Touch the power symbol (I).
- To turn off: Touch the power symbol again.

Selecting a Cooking Zone and Power Level

- Touch the symbol corresponding to the desired cooking zone.
- Use the '+' and '-' symbols to adjust the power level from 1 (low) to 9 (high).

Power Plus Function

The Power Plus function provides an immediate boost of power to a selected cooking zone for rapid heating, ideal for boiling water quickly. To activate, select a cooking zone and then touch the Power Plus symbol (P).




Image: A cooking pot on the TEKA TCC 64310 TTC BK Vitroceramic Hob, with steam visibly rising, demonstrating the rapid heating capability, likely due to the Power Plus function.

Timer Function

The integrated timer allows you to set cooking durations up to 99 minutes for individual zones or all zones simultaneously. An acoustic alarm will sound when the set time expires.

- To set: Select a cooking zone, then touch the timer symbol (). Use '+' and '-' to adjust the time.
- To cancel: Set the timer to '00' or turn off the cooking zone.

Safety Lock

The safety lock prevents accidental operation or changes to settings, especially useful in households with children. To activate, touch and hold the lock symbol () until the indicator light appears. To deactivate, touch and hold the lock symbol again.

MAINTENANCE AND CLEANING

Regular cleaning and maintenance will ensure the longevity and optimal performance of your hob.

Daily Cleaning

- After each use, allow the hob to cool down.
- Wipe the ceramic glass surface with a damp cloth and a small amount of mild dish soap.
- Rinse with a clean damp cloth and dry thoroughly with a soft, clean cloth to prevent water spots.

Removing Stubborn Stains

- For burnt-on food or stubborn stains, use a specialized ceramic hob cleaner and a scraper designed for glass hobs.
- Apply the cleaner as per its instructions, then gently scrape off residues.
- Never use abrasive sponges, scouring pads, or harsh chemical cleaners as they can scratch or damage the surface.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Hob does not turn on.	No power supply; Safety lock activated.	Check circuit breaker/fuse; Deactivate safety lock by touching and holding the lock symbol.
Cooking zone not heating.	Incorrect pot/pan size; Zone not selected or power level too low.	Ensure cookware covers the zone; Select zone and increase power level.
Display shows "E" or error code.	Internal error; Overheating.	Turn off the hob, wait a few minutes, then restart. If error persists, contact customer support.
Hob makes unusual noises.	Normal operation (e.g., fan noise); Loose cookware.	Some noise is normal. Ensure cookware is stable on the surface.

If the problem persists after attempting these solutions, please contact Teka customer support.

SPECIFICATIONS

Feature	Detail
Brand	Teka
Model Number	112540010
Color	Black
Product Dimensions	51 x 59 x 6 cm
Weight	7.9 kg
Power	6500 watts
Voltage	230 Volts
Material	Ceramic
Special Features	Automatic, Touch Control, Power Plus, Safety Lock
Number of Heating Elements	4
Burner Type	Radiant

WARRANTY AND SUPPORT

This TEKA product comes with a standard manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions, including warranty period and coverage details.

For technical assistance, spare parts, or to schedule a service appointment, please contact Teka customer support. You can find contact information on the Teka official website or in the documentation provided with your appliance.

When contacting support, please have your model number (TCC 64310 TTC BK) and serial number ready. The serial number is typically located on a label on the underside of the hob or within the appliance compartment.

© 2024 Teka. All rights reserved.
For more information, visit the official [Teka Brand Store](#).




[pdf] Catalog

DirectSense Zona FullFlex TEKA HOME Cemevisa TOTAL TCC 64310 Ref 112540010 EAN 8434778026368 PRECIO 430 00 € Cristal redondeado Ancho 59 cm Touch Control con programador 4 zonas 1 Ø145 03 Catalogo Teka 2024 Placas cemevisa files fabricantes |||

PLACAS PLACAS TEKA HOME Bienvenido a la cocina inteligente Desde la app Teka Home, consulta sobre la ... mm Funcin golpe de coccin Funcin cronmetro con avisador Potencia 6.200 W TOTAL TCC 64310 Ref. **112540010** EAN: 8434778026368 PRECIO 430,00 Cristal redondeado Ancho 59 cm Touch Control con pr...

lang:es score:23 filesize: 8.23 M page_count: 18 document date: 2024-04-18




[pdf]

Placa vitrocerámica Teka TCC 64310 TTC BK Negro Integrado 59 cm 4 zona s mmo 117194186 1699527685 6931 30300 electromueble es img objects |||

TOTAL TCC 64310 TTC BK Placa vitrocermica redondeada 4 fuegos Tctil REFERENCIA REF: **112540010** EAN: 8434778026368 Seguridad por Termopar integrada Easy installation Funcin Power Plus CARACTERSTICAS Placa Vitrocermica Acabado cristal redondeado Superficie de vidrio cermico Touch Control con sen...

lang:es score:17 filesize: 1.98 M page_count: 1 document date: 2023-11-09



[pdf]

TCC 64310 TTC BK cloudfront net pries 1 diena — Ø 145 mm 160 180 210 Função golpe de ebulição Bloqueio segurança para crianças Stop Go PreviewPdf.aspx ID 37751769 r tien21 pt ASPX PreviewIMG |||

TCC 64310 TTC BK Caracterstics gerais Placa vitrocermica Touch Control com bloqueio de segurana ... as de encastr 490 mm 570 mm Medidas exteriores 510 mm 590 mm Desenho tcnico Cor Vidro Cdigo **112540010** Dados tcnicos Tenso Frequncia Potncia mxima total Desligar automtico de segurana EA...

lang:pt score:17 filesize: 202.85 K page_count: 1 document date: 2025-01-08



[\[pdf\]](#) Catalog

Catálogo Encastre 31 lug 2024 — Teka Home eletrodomésticos inteligentes c ligação Wi fi Hob To Hood automática da chaminé durante o cozinhado DirectSense Full Flex CATALOGO TEKA WEB teka pt sites 8 07 |||

Catlogo Encastre 2024 Descubra a nova gama Full Black Teka Eletrodomsticos de encastre 100 ANOS ... lpe de ebulio rpida Funo cronmetro com avisador acstico Potncia 5.400 W TOTAL TCC 64310 TTC Cd.: **112540010** EAN: 8434778026368 Modelo sem aro exterior, 59 cm largura Touch Control c/ bloqueio 4...
lang:pt **score:15** filesize: 57.97 M page_count: 76 document date: 2024-07-31



[\[pdf\]](#) Catalog

Ver catálogo geral 2024Catálogos 2024 de Cocina y Baño Teka PortugalCATALOGO TEKA Encastre Precos MRteka pt sites 8 07 CATALOGO MR |||

Catlogo Encastre 2024 Descubra a nova gama Full Black Teka Eletrodomsticos de encastre 100 ANOS ... lpe de ebulio rpida Funo cronmetro com avisador acstico Potncia 5.400 W TOTAL TCC 64310 TTC Cd.: **112540010** EAN: 8434778026368 Preo: 440,00 Modelo sem aro exterior, 59 cm largura Touch Control ...
lang:pt **score:14** filesize: 8.86 M page_count: 76 document date: 2024-08-28



[\[pdf\]](#) Catalog

CatÁlogo Teka teka âº sites 2024 04 Catalogo Marzo ES es 2 |||

Catlogo Marzo 2024 Teka Electrodomsticos de Cocina 100 AOS DE MOMENTOS INOLVIDABLES 02 ENTRA EN ... mm Funcin golpe de coccin Funcin cronmetro con avisador Potencia 6.200 W TOTAL TCC 64310 Ref. **112540010** EAN: 8434778026368 PRECIO 430,00 Cristal redondeado Ancho 59 cm Touch Control con pr...
lang:es **score:14** filesize: 33.58 M page_count: 154 document date: 2024-04-16



[\[pdf\]](#) Catalog

Catálogo Teka ABR25 indb Catálogo Sistema de limpieza ss ECO Multifunción SurroundTemp Micro 11 ML 8210 BIS NEO MS 6200 BIH MB BI 380 382 392 CATALOGO TEKA MAYO2025 teka es sites 2 2022 03 |||

Teka Electrodomesticos de Cocina 100 AOS DE MOMENTOS INOLVIDABLES 02 INFINITY DESIGN G1 06 VAN ... mm Funcin golpe de coccin Funcin cronmetro con avisador Potencia 6.200 W TOTAL TCC 64310 Ref. **112540010** EAN: 8434778026368 PRECIO 430,00 Ancho 59 cm Cristal redondeado Touch Control con pr...

lang:es score:13 filesize: 53.78 M page_count: 164 document date: 2025-06-04



[\[pdf\]](#)

leaflet AT SECADORA BOMBA CALOR TEKA SHK 70840 114060008 8KG A BCA comercialprieto WebRoot Store Shops ComercialPrieto 6700 0A07 8661 C993 4E68 0A6E 2802 C203 DOCS ||| Catlogo Septiembre 2024 TARIFA N 54 Los precios no incluyen instalacin, puesta en funcionamiento n ... mm Funcin golpe de coccin Funcin cronmetro con avisador Potencia 6.200 W TOTAL TCC 64310 Ref. **112540010** EAN: 8434778026368 PRECIO 430,00 Ancho 59 cm Cristal redondeado Touch Control con pr...

lang:es score:11 filesize: 51.13 M page_count: 155 document date: 2024-10-22