

[Manuals.plus](#) /

> [Bissell](#) /

> BISSELL TurboClean Pet XL Upright Carpet Cleaner, Upholstery Tough Stain Tool & Formula included, 3746

## Bissell 3746

# BISSELL TurboClean Pet XL Upright Carpet Cleaner

MODEL: 3746

## About Your BISSELL TurboClean Pet XL

The BISSELL TurboClean Pet XL Upright Carpet Cleaner is a powerful solution for deep cleaning carpets and upholstery, especially designed for pet owners. It features a 10-inch clean path for wide coverage, a 1-gallon clean tank for fewer refills, and a 4-Row DeepReach PowerBrush to effectively remove tough pet stains and dander allergens. Included accessories like the 3-inch Tough Stain Tool and Spraying Crevice Tool allow for versatile cleaning of hard-to-reach areas like baseboards, stairs, and upholstery. This machine is designed to save cleaning time and help you get back to your everyday life faster.



The BISSELL TurboClean Pet XL in action, demonstrating its wide cleaning path on a carpeted area.

## Setup Instructions

Your BISSELL TurboClean Pet XL comes with minimal assembly required. Simply attach the handle to the main body of the cleaner. Ensure all components click securely into place before use.



The main unit and its accessories, including the clean and dirty water tanks, upholstery tools, and cleaning formulas.

## Operating Instructions

### Filling the Clean Water Tank

To prepare your cleaner for use, remove the clean water tank located at the top of the unit. Unscrew the yellow cap and fill the tank with hot tap water (up to 140°F/60°C MAX) to the indicated 'WATER' line. Then, add the recommended BISSELL cleaning formula up to the 'FORMULA' line. Securely replace the cap and reinsert the tank into the cleaner until it clicks into place.



## Fewer Refills While Cleaning

1 gallon clean tank capacity

Properly filling the clean water tank with water and BISSELL cleaning formula.

### Deep Cleaning Carpets

Plug the cleaner into a grounded outlet. Press the power button located at the base of the unit. Recline the handle by pressing the foot release pedal. To apply cleaning solution, press the spray trigger while making a slow forward and backward pass over the carpet. Release the trigger and make another slow forward and backward pass over the same area to suction up the dirty solution. For heavily soiled areas, repeat the process. The 10-inch cleaning path ensures efficient coverage.



## Clean More Carpet with a 10" Cleaning Path

The wide 10-inch cleaning path allows for efficient deep cleaning of large carpeted areas. For targeted cleaning of upholstery, stairs, or tight spaces, attach the 3-inch Tough Stain Tool or the Spraying Crevice Tool to the hose. Follow the same spray and suction method for effective spot cleaning.



## **3" Tough Stain Tool**

Quickly tackle spots & stains or give a full deep clean to your furniture.

The 3-inch Tough Stain Tool effectively tackles spots and stains on upholstery.



## **Spraying Crevice Tool**

Clean baseboards, stairs, pet beds  
& more hard to reach areas.

The Spraying Crevice Tool is ideal for cleaning baseboards, stairs, and other hard-to-reach areas.

### **Maintenance**

#### **Emptying the Dirty Water Tank**

When the dirty water tank reaches the 'FULL' line, or when you notice a decrease in suction, it's time to empty it. Remove the dirty water tank from the lower part of the cleaner. Unlatch the grey stopper and pour out the dirty water. Rinse the tank thoroughly with clean water.



## Every Purchase Saves Pets™

BISSELL proudly supports BISSELL Pet Foundation® and its mission to help save homeless pets.

Emptying the dirty water tank after cleaning, revealing the extracted grime.

### Cleaning the Brush Roll and Nozzle

For optimal performance, regularly clean the brush roll and nozzle. The nozzle is removable for easy rinsing. The 4-Row DeepReach PowerBrush can also be accessed and cleaned to remove any trapped hair or debris. Refer to the user manual for detailed instructions on removing and reattaching these components.

### Troubleshooting

#### Common Issues and Solutions

- **Tank fills up quickly:** This is normal, especially on heavily soiled carpets. Empty the dirty water tank frequently to maintain optimal suction.
- **Cord needs to be longer:** If the included cord length is insufficient for your cleaning area, a suitable extension cord can be used. Always ensure the extension cord is rated for the appliance's power requirements and is used safely.
- **Hair gets stuck in brush:** Always vacuum the carpet thoroughly before using the deep cleaner to remove loose hair and debris. Regularly clean the brush roll as per maintenance instructions.
- **Suction isn't great:** Check both the clean and dirty water tanks to ensure they are properly seated and not full. Inspect the nozzle and brush roll for any clogs or blockages.

- **Strange smell during operation:** This could indicate residue buildup in the dirty water tank or hose. Ensure all tanks and removable parts are thoroughly cleaned after each use.
- **Tank hard to remove:** Ensure you are pressing the release latches firmly and correctly. If the tank is full, it might be heavier and require a bit more effort.

## Product Specifications

Feature	Detail
Brand	Bissell
Model Name	TurboClean Pet Pro Fusion
Item Model Number	3746
Item Weight	23.3 pounds
Product Dimensions	12.83 x 17.71 x 25.04 inches
Capacity	1 Gallons
Power Source	Corded Electric
Included Components	Crevice Tool, 3-inch Tough Stain Tool

## Warranty & Support

BISSELL offers various protection plans for your TurboClean Pet XL, including 2-Year and 3-Year Protection Plans, as well as a Complete Protect monthly plan. These plans provide extended coverage beyond the standard manufacturer's warranty.

For further assistance, troubleshooting, or to learn more about your product's warranty, please visit the official Bissell website or contact their customer support.