

[Manuals.plus](#) /

› [Bernini Fountains](#) /

› Bernini Lago Cordless Pond Fountain (Model LG7030) - Instruction Manual

## Bernini Fountains LG7030

# Bernini Lago Cordless Pond Fountain

Model: LG7030 | Brand: Bernini Fountains

## INTRODUCTION

---

The Bernini Lago Pond Fountain is designed to provide a soothing water feature for your indoor or outdoor environment. This cordless fountain offers a calming movement of water and can be customized with various adornments. It operates on D-cell batteries, eliminating the need for plumbing or power cords, and features a daily timer for convenient operation.

## SAFETY INFORMATION

---

- Always ensure the fountain is placed on a stable, level surface to prevent tipping.
- Do not operate the fountain without water. This can damage the pump.
- Keep children and pets away from the fountain during operation to prevent accidents.
- Use only the specified 4 D-cell batteries. Do not mix old and new batteries or different types of batteries.
- Dispose of used batteries responsibly according to local regulations.
- Do not attempt to modify or repair the fountain or pump. Contact customer support for assistance.
- Protect the fountain from freezing temperatures by draining and storing it indoors during winter months.

## PACKAGE CONTENTS

---

Verify that all components are present before beginning assembly:

- Lago Pond Fountain Bowl
- Battery-Powered Pump Assembly
- Three Interchangeable Spray Tips
- Instruction Manual

## SETUP

1. **Unpack Components:** Carefully remove all items from the packaging.
2. **Install Batteries:** Locate the battery compartment on the underside of the pump assembly. Insert 4 D-cell batteries (not included), ensuring correct polarity. Securely close the compartment.
3. **Assemble Pump:** Place the pump assembly into the designated area within the fountain bowl. Ensure it is seated correctly.
4. **Select Spray Tip:** Choose one of the three provided spray tips and attach it firmly to the top of the pump nozzle.
5. **Position Fountain:** Place the fountain on a firm, level surface in your desired location. The cordless design allows for flexible placement on a patio, deck, or lawn. For a recessed look, you can dig a hole or cut an opening in a deck to integrate the fountain flush with the surface.
6. **Fill with Water:** Fill the fountain bowl with clean water until the pump is fully submerged and the water level reaches the recommended fill line. Do not overfill.



The Bernini Lago Pond Fountain, featuring a white stone finish, provides a serene water feature for outdoor spaces.



CREATE A POND FOUNTAIN INSTANTLY

This image illustrates the dimensions of the Lago fountain (21.5 inches diameter, 9 inches height) and the three included spray tip options for varied water patterns.

## OPERATING INSTRUCTIONS

---

1. **Power On:** Once batteries are installed and the fountain is filled with water, press the power button on the pump assembly to turn on the fountain.
2. **Set Timer:** The fountain features a daily timer that allows it to run for 1, 2, 3, or 4 hours. Press the timer button repeatedly to cycle through the desired duration. The fountain will then run for the selected time each day at the same time it was initially activated.
3. **Battery Life:** A single set of 4 D-cell batteries can last up to 200 days with average use (e.g., 1-hour daily timer setting). Actual battery life may vary based on usage and battery quality.
4. **Power Off:** To turn off the fountain manually, press the power button.

Your browser does not support the video tag.

This video demonstrates the features and operation of the Bernini Lago Pond Fountain, including its cordless design and customizable elements.

## MAINTENANCE

---

- **Water Level:** Regularly check the water level and refill as needed to ensure the pump remains submerged. Evaporation will reduce water levels over time.
- **Water Quality:** The fountain's circulation helps keep water fresh. However, it is recommended to periodically drain and clean the fountain bowl to prevent algae buildup and maintain water clarity.
- **Pump Cleaning:** Over time, debris can accumulate in the pump, affecting its performance. Disconnect the pump and clean any visible debris from the intake screen and impeller.
- **Battery Replacement:** When the water flow weakens or the fountain stops operating, it is time to replace the D-cell batteries. Ensure the fountain is off before replacing batteries.
- **Winter Storage:** During freezing temperatures, drain all water from the fountain and pump. Clean and dry all components thoroughly, then store them in a dry, frost-free location.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Fountain not running	Dead or incorrectly installed batteries; Low water level; Pump clogged.	Check and replace batteries, ensuring correct polarity. Add water to the recommended level. Clean the pump intake and impeller.
Weak water flow	Low battery power; Pump partially clogged; Insufficient water.	Replace batteries. Clean the pump. Add water.
Water not circulating	Pump not operating; Obstruction in water path.	Refer to "Fountain not running" solutions. Ensure spray tip is clear of debris.
Algae buildup	Exposure to sunlight; Infrequent cleaning.	Regularly clean the fountain bowl and change water. Consider placing the fountain in a shaded area if possible.

## SPECIFICATIONS

- **Model Number:** LG7030
- **Product Dimensions:** 22.5"L x 22.5"W x 8.5"H
- **Item Weight:** 11.9 Pounds
- **Material:** Polycarbonate
- **Color:** White Stone
- **Power Source:** 4 x D-Cell Batteries (not included)
- **Special Features:** Cordless, Fade Resistant, Lightweight, UV Resistant, Weather Resistant

## WARRANTY INFORMATION

For detailed warranty information, please refer to the documentation included with your purchase or visit the official Bernini Fountains website. Keep your proof of purchase for any warranty claims.

## CUSTOMER SUPPORT

If you encounter any issues or have questions regarding your Bernini Lago Pond Fountain, please contact Bernini Fountains customer service. Contact details can typically be found on the product packaging or the official Bernini Fountains website.