

[Manuals.plus](#) /

› [Lifelines](#) /

› Lifelines Waves Ultrasonic Essential Oil Diffuser User Manual

Lifelines Waves Ultrasonic

Lifelines Waves Ultrasonic Essential Oil Diffuser User Manual

Model: Waves Ultrasonic | Brand: Lifelines

INTRODUCTION

The Lifelines Waves Ultrasonic Essential Oil Diffuser is designed to enhance your well-being by creating a serene atmosphere. It features a cascading mist, customizable colored lights, and an auto-shutoff function for safe and effortless aromatherapy. This manual provides detailed instructions for setting up, operating, and maintaining your diffuser.



Image: The Lifelines Waves Ultrasonic Diffuser creating a calming mist, accompanied by a bottle of Citrus Grove Essential Oil Blend.

PACKAGE CONTENTS

- Lifelines Waves Ultrasonic Diffuser (200ml capacity)
- Citrus Grove Essential Oil Blend (3ml)
- Power Adapter
- User Manual

SETUP INSTRUCTIONS

1. **Place the Diffuser:** Position the diffuser on a flat, stable surface away from direct sunlight or heat sources.

2. **Remove the Cover:** Gently lift the top cover of the diffuser to expose the water tank.
3. **Add Water:** Fill the water tank with clean, cool tap water up to the 'MAX' fill line **Do not overfill.**
4. **Add Essential Oil:** Add 5-8 drops of the included Lifelines Citrus Grove Essential Oil Blend directly into the water tank. Adjust the number of drops based on desired scent intensity and room size.
5. **Replace the Cover:** Securely place the top cover back onto the diffuser.
6. **Connect Power:** Plug the power adapter into the diffuser's power port and then into a standard electrical outlet.

ESSENTIAL OILS BLENDS

Mess-free Precision Pump™



Dispense the
Perfect Amount Every Time
with No Guesswork

Image: A hand using the precision pump to add essential oil into the diffuser's water reservoir, highlighting the mess-free design.

Your browser does not support the video tag.

Video: A demonstration of how to set up and use the Lifelines Waves Ultrasonic Diffuser, including adding water and essential oil.

OPERATING INSTRUCTIONS

Once set up, operate your diffuser using the control buttons located at the base.

- **Power Button:** Press once to turn on the diffuser. Press again to cycle through mist modes (continuous, intermittent). Hold to turn off.
- **Light Button:** Press to cycle through 5 different light colors or activate the automatic color rotation mode. Hold to turn off the light.
- **Timer Button:** Press to set the operating timer for 1, 4, or 8 hours. The diffuser will automatically shut off when the timer expires or when water runs out.
- **Aroma Level:** The diffuser offers two levels of aroma intensity. This is typically controlled by the mist output setting or by adding more/few drops of essential oil.



Image: Visual representation of the diffuser's features, including its 200ml capacity, two aroma levels, multiple timer options, and five distinct light colors.

MAINTENANCE

Regular cleaning ensures optimal performance and longevity of your diffuser.

1. **Empty Water:** Always unplug the diffuser and empty any remaining water from the tank after each use.

- 2. **Clean the Tank:** Wipe the inside of the water tank with a soft cloth. For deeper cleaning, use a cotton swab dipped in white vinegar to gently clean the ultrasonic plate. Rinse thoroughly with clean water.
- 3. **Exterior Cleaning:** Wipe the exterior of the diffuser with a soft, damp cloth. Do not use abrasive cleaners.
- 4. **Storage:** If not in use for an extended period, ensure the diffuser is clean and dry before storing it in a cool, dry place.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No Mist Output	Low water level; Diffuser not plugged in; Ultrasonic plate dirty.	Add water; Ensure power connection; Clean ultrasonic plate.
Weak Scent	Insufficient essential oil; Large room size.	Add more drops of essential oil; Use in a smaller area.
Diffuser Leaking	Overfilled water tank; Cover not properly secured.	Do not exceed MAX fill line; Ensure cover is tightly closed.
Lights Not Working	Light function turned off; Power issue.	Press the Light button; Check power connection.

SPECIFICATIONS

- **Brand:** Lifelines
- **Model Name:** Waves Ultrasonic
- **Model Number:** Waves Ultrasonic
- **Capacity:** 200 Milliliters
- **Runtime:** Up to 8 hours
- **Power Source:** Corded Electric (10 watts)
- **Light Source:** LED (5 colors + rotation)
- **Automatic Shutoff:** Yes
- **Material:** Plastic
- **Item Dimensions (L x W x H):** 4.76"L x 4.76"W x 7.2"H
- **Included Components:** Diffuser and Essential Oil Blends

SAFETY INFORMATION

- Avoid direct skin contact with undiluted essential oils.
- Keep out of reach of children and pets.
- Ensure proper ventilation during use.
- Always use the auto-shutoff feature to prevent overheating.
- Use only the provided power adapter.

WARRANTY & SUPPORT

Lifelines is committed to your satisfaction. If you are not satisfied with your product for any reason, please contact us. We are dedicated to ensuring your well-being and will make it right.

For support, please visit the [Lifelines Store on Amazon](#).

Your browser does not support the video tag.

Video: Learn more about Lifelines' commitment to quality ingredients and customer care.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question