

[Manuals.plus](#) /

› [Sweetcrispy](#) /

› Sweetcrispy Home Office Chair C-2892-1A-BK Instruction Manual

Sweetcrispy C-2892-1A-BK

Sweetcrispy Home Office Chair Instruction Manual

Model: C-2892-1A-BK

1. INTRODUCTION AND OVERVIEW

This manual provides detailed instructions for the assembly, operation, and maintenance of your Sweetcrispy Home Office Chair, Model C-2892-1A-BK. Designed for comfort and support, this chair features an ergonomic backrest, high-grade leather upholstery, and multi-adjustment capabilities to enhance your sitting experience. Please read this manual thoroughly before assembly and use to ensure proper function and safety.



Image: Front view of the Sweetcrispy Home Office Chair.

2. PRODUCT FEATURES

- **Ergonomic Backrest:** Curved design to adapt to your spine, reduce hunchback, and correct sitting posture, providing lumbar support.
- **High-Grade Leather Upholstery:** Made with upholstered leather, springs, and foam cushions for comfort and a premium appearance.
- **Multi-Adjustment Gas Lift:** Smooth height adjustment via a lever under the seat.
- **Tilt Function:** Adjustable tilt for personalized comfort and relaxation.
- **Safety Guarantee:** Heavy-duty durable nylon painted base meeting BIFMA standards, safe gas lift, and rolling nylon silent casters.
- **Weight Capacity:** Supports adults up to 300 lbs.
- **Padded Armrests:** Provides all-day comfort and support.

ERGONOMIC DESIGN



Cushioned Headrest Designed



Thickened Seat Cushion



Padded Armrests

Image: Detailed view highlighting the ergonomic design of the chair, including the cushioned headrest, thickened seat cushion, and padded armrests.

3. SAFETY INFORMATION

Please observe the following safety guidelines:

- Exceeding the maximum weight capacity of 300 lbs may cause damage to the chair or personal injury.
- Ensure proper assembly of all components before use to maintain stability.
- Use the chair only in intended indoor environments.
- Keep hands and fingers clear of moving parts during adjustment.

4. PACKAGE CONTENTS

Verify that all components are present before beginning assembly:

No.	Part	Quantity
1	Backrest	1
2	Seat Cushion	1
3	Armrests (1L, 1R)	2
4	Mechanism	1
5	Gas Lift	1
6	Base	1
7	Legs	5
8	Casters	5
9	Bolts (for Mechanism)	4
10	Bolts (for Armrests)	8
11	Bolts (for Legs)	10
12	Caps	8
13	Wrench	1

5. ASSEMBLY INSTRUCTIONS

Follow these steps to assemble your Sweetcrispy Home Office Chair. An installation video is provided for visual guidance.

Video: Sweetcrispy Home Office Chair - Fixed Armrests Installation Guide. This video demonstrates the step-by-step assembly process for the chair.

- 1. Assemble the Base:** Turn the Base (6) upside down. Install the 5 Legs (7) to the Base (6) using 10 Bolts (11).
- 2. Attach Casters:** Press the 5 Casters (8) into the holes at the end of each Leg (7).
- 3. Insert Gas Lift:** Turn the assembled Base back upright and insert the Gas Lift (5) into the center hole of the Base.
- 4. Attach Mechanism to Seat Cushion:** Ensure the "FRONT" direction of the Mechanism (4) and Seat Cushion (2) are aligned. Attach the Mechanism (4) to the Seat Cushion (2) using 4 Bolts (9).
- 5. Attach Armrests to Seat Cushion:** Align the center hole of the Seat Mechanism with the Gas Lift (5) and press the Seat Cushion down until it is fully secured. Attach the Armrests (3) (1L, 1R) to both sides of the Seat Cushion (2) using 4 Bolts (10). *Note: Bolts are only tightened 30% at this stage.*
- 6. Attach Backrest to Armrests:** Tilt the Backrest (1) down. Attach the Armrests (3) (1L, 1R) to the screw holes on the lower side of the Backrest (1) using 2 Bolts (10). *Note: Bolts are only tightened 30% at this stage.*
- 7. Secure Backrest:** Rotate the Backrest (1) up. Attach the Armrests (3) (1L, 1R) to the screw holes on the upper side of the Backrest (1) using 2 Bolts (10). *Note: Bolts are only tightened 30% at this stage.*
- 8. Final Tightening and Caps:** Adjust the balance on each side of the chair, and then fully tighten all 8 Bolts (10) on both sides of the Armrests to 100%. Finally, press the 8 Caps (12) into the screw holes on each side.

6. OPERATING INSTRUCTIONS

Your Sweetcrispy Home Office Chair offers several adjustments for personalized comfort:

- **Height Adjustment:** To adjust the seat height, pull the lever located under the right side of the seat upwards. While holding the lever, stand up to raise the seat or remain seated to lower it. Release the lever to lock the height.
- **Tilt/Rocking Function:** The chair features a tilt mechanism. Pull the lever located under the left side of the seat outwards to enable the rocking function. Push the lever inwards to lock the chair in an upright position.

Video: Sweetcrispy Desk Chair Features. This video demonstrates the chair's height adjustment, tilt function, and overall ergonomic design.

ROCKING MODE



Image: Side view illustrating the chair's rocking mode, solid base, gas lift, and 360-degree swivel casters.

7. MAINTENANCE

To ensure the longevity and appearance of your Sweetcrispy Home Office Chair, follow these maintenance guidelines:

- **Cleaning:** Wipe clean with a damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the leather upholstery.

- **Regular Inspection:** Periodically check all bolts and screws to ensure they are tight. Re-tighten if necessary.
- **Caster Care:** Keep casters free of debris (hair, dust, etc.) to ensure smooth rolling.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause the leather to fade or crack.

8. TROUBLESHOOTING

If you encounter any issues with your chair, refer to the following common problems and solutions:

- **Chair Squeaks:** Ensure all bolts are securely tightened. Applying a small amount of silicone lubricant to moving parts (e.g., mechanism, gas lift connections) may help.
- **Gas Lift Not Adjusting:** Check if the height adjustment lever is fully engaged or disengaged. Ensure the gas lift is properly seated in the base and mechanism.
- **Casters Not Rolling Smoothly:** Inspect casters for trapped debris (hair, lint) and remove them. Ensure casters are fully inserted into the leg holes.
- **Chair Feels Unstable:** Verify that all assembly steps have been followed correctly and all bolts are tightened. Ensure the chair is on a flat, even surface.

If problems persist, please contact customer support for further assistance.

9. SPECIFICATIONS

Specification	Detail
Brand	Sweetcrispy
Model Number	C-2892-1A-BK
Color	Black
Material	Metal (Frame), Foam (Seat/Fill), Leather (Finish)
Product Dimensions (D x W x H)	26.38" x 29.53" x 45"
Item Weight	34.62 Pounds
Seat Height	21.85 Inches
Seat Depth	20 Inches
Chair Backrest Width	20.86 Inches
Maximum Weight Recommendation	300 Pounds
Required Assembly	Yes
Surface Recommendation	Hard Floor
Included Components	Caster

10. WARRANTY AND SUPPORT

Sweetcrispy is committed to providing a great experience for all customers. For any questions regarding your chair, including warranty information, missing parts, or assembly assistance, please contact Sweetcrispy customer support. We are dedicated to resolving any issues you may encounter.

Please refer to your purchase documentation for specific warranty terms and contact details.

© 2024 Sweetcrispy. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question