

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Beko](#) /
- › [Beko B7RMLNE445ZXP Single Door Refrigerator User Manual](#)

Beko B7RMLNE445ZXP

Beko B7RMLNE445ZXP Single Door Refrigerator User Manual

PRODUCT OVERVIEW

This manual provides essential information for the safe and efficient operation of your Beko B7RMLNE445ZXP single-door refrigerator. Designed with a generous 365-liter net capacity and No-frost technology, this appliance ensures optimal food preservation. It features an intuitive LED display for temperature control and is rated Class D for energy efficiency. Please read these instructions thoroughly before using your appliance.







Image: Front view of the Beko B7RMLNE445ZXP single-door refrigerator, showcasing its sleek Inox finish and integrated LED display.

INSTALLATION AND SETUP

Unpacking and Placement

- Remove all packaging materials and protective films.
- Place the refrigerator on a flat, stable surface, away from direct sunlight, heat sources (like ovens or radiators), and extreme cold.
- Ensure adequate ventilation around the appliance. Leave at least 5 cm of space on the sides and back, and 10 cm above.
- Adjust the leveling feet to ensure the appliance is stable and slightly tilted backward to allow the door to close automatically.

Electrical Connection

- Before plugging in, allow the refrigerator to stand upright for at least 4 hours to allow the refrigerant to settle.
- Connect the appliance to a grounded power outlet (230 Volt). Do not use extension cords or multiple sockets.
- Ensure the power cord is not trapped or damaged.

Door Reversibility

The door hinge is set to the right by default. If you need to reverse the door opening direction, please refer to the detailed instructions in the separate installation guide or contact qualified service personnel.

OPERATING INSTRUCTIONS

Initial Operation

After connecting the refrigerator to power, the internal light will turn on, and the display will show the default

temperature setting. Allow the appliance to run for several hours before placing food inside to ensure it reaches the optimal operating temperature.

Temperature Control (LED Display)

Your Beko refrigerator is equipped with an LED display that allows you to easily monitor and adjust the internal temperature. Use the control buttons adjacent to the display to set your desired temperature. Refer to the display icons for specific functions such as quick cooling or holiday mode.

No-Frost System

The No-frost system prevents ice build-up in the refrigerator compartment, eliminating the need for manual defrosting. This technology circulates cold air evenly, maintaining consistent temperatures and humidity levels to keep food fresh longer.

HarvestFresh Technology

The HarvestFresh technology utilizes a unique three-color light system (blue, green, red) that simulates the 24-hour sun cycle within the crisper drawer. This innovative feature helps to preserve the vitamins and freshness of fruits and vegetables for longer periods, mimicking natural growing conditions.

Storage Compartments

- **Shelves:** The refrigerator includes 6 adjustable shelves for flexible storage.
- **Crisper Drawers:** Two dedicated crisper drawers are provided for fruits and vegetables, utilizing the HarvestFresh technology.
- **Door Racks:** Multiple door racks offer convenient storage for bottles, jars, and smaller items.

CARE AND MAINTENANCE

Cleaning the Interior

- Always unplug the appliance before cleaning.
- Clean the interior regularly with a solution of warm water and a mild, non-abrasive detergent.
- Wipe dry thoroughly to prevent mold and odors.
- Remove and clean shelves, drawers, and door racks separately.

Cleaning the Exterior

- Wipe the exterior surfaces with a soft, damp cloth. For stainless steel (Inox) finishes, use a specialized stainless steel cleaner to avoid streaks.
- Clean the condenser coils at the back of the refrigerator periodically to ensure efficient operation.

Light Bulb Replacement

The internal lighting uses LED lamps. If the LED lighting requires replacement, please contact authorized service personnel. Do not attempt to replace it yourself.

TROUBLESHOOTING

Before contacting customer service, please check the following common issues and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Refrigerator does not operate.	No power supply.	Check if the power plug is correctly inserted into the socket. Check the fuse or circuit breaker.
Temperature inside is not cold enough.	Door opened too frequently or for too long; too much food inside; appliance near a heat source; incorrect temperature setting.	Ensure the door is closed properly. Avoid opening the door unnecessarily. Reduce the amount of food. Move the appliance away from heat sources. Adjust the temperature setting to a colder level.
Unusual noises.	Appliance not level; objects touching the back wall; normal operating sounds.	Adjust the leveling feet. Ensure nothing is touching the back of the appliance. Gurgling, humming, or cracking sounds are normal during operation.
Water on the bottom of the refrigerator compartment.	Drain hole is blocked.	Clear the drain hole at the back of the refrigerator compartment with a small, soft tool.

TECHNICAL SPECIFICATIONS

Feature	Value
Brand	Beko
Model Number	B7RMLNE445ZXP
Net Refrigerator Capacity	365 Liters
No-Frost System	Yes
Climate Class	SN-T
Acoustic Emission	35 dB
Display Type	LED
Number of Refrigerator Shelves	6
Number of Vegetable Drawers	2
Lamp Type	LED
Door Hinge	Right (Reversible)
Annual Energy Consumption	113.9 kWh
Energy Efficiency Class	D
Weight	66 kg
Product Color	Stainless Steel (Inox)
Voltage	230 Volt
Refrigerant	R-32

WARRANTY AND CUSTOMER SUPPORT

Your Beko refrigerator comes with a manufacturer's warranty. Please refer to the warranty card included with your appliance for specific terms and conditions. For technical assistance, spare parts, or any questions regarding your product, please contact Beko customer support through their official website or the contact information provided in your warranty documentation.

Online Support: Visit the official Beko website for FAQs, troubleshooting guides, and service request forms.

Service Center: Locate your nearest authorized Beko service center for professional repairs and maintenance.