

EarFun UBOOM Slim

EarFun UBOOM Slim Bluetooth Speaker User Manual

Model: UBOOM Slim (SP100B)

INTRODUCTION

This manual provides detailed instructions for the proper use and maintenance of your EarFun UBOOM Slim Bluetooth Speaker. Please read this manual thoroughly before operating the device to ensure optimal performance and longevity.



Image: The EarFun UBOOM Slim Bluetooth Speaker, showcasing its waterproof design with water splashing around it.

PACKAGE CONTENTS

Verify that all items are present in your package:

- 1 × EarFun UBOOM Slim Bluetooth Speaker (Dimensions: 180mm*65mm*65mm; Weight: 560g)
- 1 × Metal Buckle
- 1 × User Manual (this document)
- 1 × USB Type-C Charging Cable

PRODUCT OVERVIEW

Familiarize yourself with the speaker's components and controls.




Image: A detailed view of the EarFun UBOOM Slim speaker's side panel, highlighting the USB-C charging port, AUX input, and the protective waterproof cover.

Controls and Indicators:

- **Power Button:** Press and hold to power on/off.
- **Volume Up (+):** Increase playback volume.
- **Volume Down (-):** Decrease playback volume.
- **Multi-Function Button:** Play/pause, answer/end calls, activate voice assistant.
- **Bluetooth Button:** Initiate Bluetooth pairing mode.
- **LED Indicator:** Displays power, charging, and Bluetooth status.
- **USB-C Port:** For charging the speaker.
- **AUX Input:** For wired audio connection.
- **Waterproof Cover:** Protects ports from water and dust.

SETUP

1. Charging the Speaker

Before first use, fully charge the speaker. Use the provided USB Type-C cable to connect the speaker to a power source. The LED indicator will show charging status and turn off when fully charged.

- **Charging Time:** Approximately 4 hours.
- **Battery Life:** Up to 18 hours of continuous play at normal volume.

18H LONG BATTERY LIFE

Built-in 4000 mAh large-capacity battery, it can play for 18 hours at normal volume and 6 hours at maximum volume.



Charging Time: **about 4 hours**

Battery Life: **Up to 18 hours**

Charging Type: **USB Type-C**

Image: A visual representation of the EarFun UBOOM Slim speaker's 18-hour battery life, showing it in use during daytime outdoor activities and nighttime gatherings.

2. Power On/Off

- To power on: Press and hold the Power button until the LED indicator lights up.
- To power off: Press and hold the Power button until the LED indicator turns off.

3. Bluetooth Pairing

The EarFun UBOOM Slim uses Bluetooth 5.2 for a stable connection.

1. Ensure the speaker is powered on and in pairing mode (LED indicator will flash blue). If not, press the

Bluetooth button.

2. Enable Bluetooth on your device (smartphone, tablet, computer).
3. Select "EarFun UBOOM Slim" from the list of available devices.
4. Once connected, the LED indicator will turn solid blue.




Image: A graphic illustrating the advantages of Bluetooth 5.2 connectivity, including longer distance, faster connection, increased stability, and lower power consumption.

4. Stereo Pairing (True Wireless Stereo)

Connect two UBOOM Slim speakers for an immersive 360° stereo sound experience.

1. Turn on both UBOOM Slim speakers.

2. Connect one speaker (Speaker A) to your device via Bluetooth.
3. On Speaker A, double-click the Multi-Function Button to enter Stereo Link pairing mode.
4. The two speakers will automatically connect to each other, creating a stereo pair.

STEREO PAIRING & 360° IMMERSIVE SOUND

Connect two speakers via Bluetooth to create a true stereo field and enjoy 360° stereo sound.



How to Do Stereo Pairing




Image: A step-by-step diagram demonstrating the process of stereo pairing two EarFun UBOOM Slim speakers for a synchronized audio experience.

OPERATING

1. Basic Controls

- **Play/Pause:** Press the Multi-Function Button once.

- **Next Track:** Press and hold the Volume Up (+) button.
- **Previous Track:** Press and hold the Volume Down (-) button.
- **Answer/End Call:** Press the Multi-Function Button once.
- **Reject Call:** Press and hold the Multi-Function Button.

2. Voice Assistant

Activate your device's voice assistant (Siri, Google Assistant, etc.) by pressing the Multi-Function Button twice.

3. Waterproof Functionality (IPX7)

The UBOOM Slim is designed with IPX7 waterproof performance, allowing it to be immersed in water up to 3 feet (1 meter) deep for up to 30 minutes. Ensure the waterproof cover for the ports is securely closed before exposing the speaker to water.

100% WATERPROOF

Fully sealed waterproof and dustproof design, suitable for outdoor beach and riding environments.

IPX7 waterproof allows the speaker to be immersed in water as deep as 3 feet for up to 30 minutes.



**High-quality
Fabric Material**

Image: The EarFun UBOOM Slim speaker partially submerged in water, illustrating its IPX7 waterproof capability and durable fabric material.

MAINTENANCE

1. Cleaning

- Wipe the speaker with a soft, damp cloth.
- Do not use abrasive cleaners, alcohol, or chemical solvents.
- Ensure the speaker is dry before charging.

2. Storage

- Store the speaker in a cool, dry place away from extreme temperatures.
- Avoid prolonged exposure to direct sunlight.
- If storing for an extended period, charge the battery every three months to maintain its health.

TROUBLESHOOTING

If you encounter issues with your EarFun UBOOM Slim speaker, refer to the following common solutions:

Problem	Possible Solution
Speaker does not power on	Ensure the battery is charged. Connect to a power source and try again.
Cannot pair via Bluetooth	Make sure the speaker is in pairing mode (flashing blue LED). Disable and re-enable Bluetooth on your device. Move the speaker closer to your device. Clear previous Bluetooth connections on your device.
No sound or low volume	Increase the volume on both the speaker and your connected device. Ensure the speaker is properly connected. Check if the audio source is playing.
Stereo pairing fails	Ensure both speakers are UBOOM Slim models. Follow the stereo pairing instructions carefully. Keep speakers within close proximity during pairing.
Audio distortion	Reduce the volume on both the speaker and your device. Ensure the audio file quality is good.
Speaker unresponsive	Perform a soft reset by pressing and holding the Power button for 10 seconds.

SPECIFICATIONS

Detailed technical specifications for the EarFun UBOOM Slim Bluetooth Speaker:

- **Model Name:** UBOOM Slim
- **Item Model Number:** SP100B
- **Brand:** EarFun
- **Material:** Metal
- **Speaker Type:** Subwoofer
- **Speaker Maximum Output Power:** 10 Watts (per driver, total 20W)
- **Connectivity Technology:** Bluetooth 5.2
- **Wireless Communication Technology:** Bluetooth
- **Audio Output Mode:** Stereo
- **Surround Sound Channel Configuration:** 2
- **Power Source:** Battery Powered
- **Battery Life:** Up to 18 hours
- **Charging Type:** USB-C
- **Waterproof Rating:** IPX7 (immersible in 1m of water for 30 minutes)

- **Product Dimensions:** 18D x 6.5W x 6.5H Centimeters
- **Item Weight:** 0.69 Kilograms (690g)
- **Control Method:** Voice
- **Recommended Uses:** For Smartphones or Tablets
- **Compatible Devices:** Mobile phones, computers, TVs, car Bluetooth, etc.
- **Country of Origin:** China

LOSSLESS SOUND, POWERFUL BASS

Equipped with 10W+10W high-performance drivers & latest DSP sound processing technology, delivers powerful bass, delicate treble and mellow vocals.

**45mm Bass Diaphragm
Dual Drivers**



Image: An exploded view of the EarFun UBOOM Slim speaker, highlighting its dual 10W high-performance drivers, 45mm bass diaphragm, and advanced DSP technology for powerful bass and clear sound.

WARRANTY AND SUPPORT

Warranty Information



EarFun provides an **18-month worry-free warranty** from the date of purchase. If the product fails during normal use within this period and cannot be resolved through standard measures, EarFun will provide solutions such as product replacement, repair, or refund.


Customer Support

For any inquiries, technical assistance, or warranty claims, please contact EarFun customer service:


- **Email:** service@myearfun.com
- **Manufacturer:** Earfun Technology (HK) Limited
- **Importer (India):** VALUECART PRIVATE LIMITED

Related Documents - UBOOM Slim

 EarFun UBOOM L - Manuel d'utilisation et spécifications	EarFun UBOOM L - Manuel d'utilisation et spécifications Découvrez le manuel d'utilisation complet pour l'enceinte Bluetooth portable EarFun UBOOM L (modèle SP300). Apprenez à utiliser ses fonctions, à le connecter et à le configurer.
 EarFun UBOOM Slim Portable Bluetooth Speaker Quick Start Guide	EarFun UBOOM Slim Portable Bluetooth Speaker Quick Start Guide Concise guide to setting up and using the EarFun UBOOM Slim portable Bluetooth speaker, including connection, stereo pairing, and controls.
 EarFun UBOOM Slim SP100 Stručný Návod k Použití	EarFun UBOOM Slim SP100 Stručný Návod k Použití Stručný návod k použití bezdrátového reproduktoru EarFun UBOOM Slim SP100, pokrývající připojení, stereo párování, ovládání, nabíjení a technické údaje.
 Bluetooth vezeték nélküli hangszóró EarFun UBOOM X	EarFun UBOOM X Bluetooth Vezeték Nélküli Hangszóró Használati Utasítás Részletes használati útmutató az EarFun UBOOM X Bluetooth vezeték nélküli hangszóróhoz. Ismerje meg a termék funkcióit, párosítását, töltését, karbantartását és jótállási feltételeit.

	EarFun UBOOM L Přenosný Bluetooth Reproduktor - Návod k Použití Podrobný návod k použití pro přenosný Bluetooth reproduktor EarFun UBOOM L. Obsahuje informace o součástkách, nabíjení, technických údajích, párování Bluetooth, TWS, funkcích a postupech pro resetování. Optimalizováno pro vyhledávače.
	EarFun UBOOM Slim Quickstart Guide Get started quickly with your EarFun UBOOM Slim wireless speaker. This guide covers connecting to your device, pairing two speakers for stereo sound, understanding the controls, and important FCC compliance information.

Documents - EarFun – UBOOM Slim



[EarFun UBOOM Slim SP100 Stručný Návod k Použití](#)

Stručný návod k použití bezdrátového reproduktoru EarFun UBOOM Slim SP100, pokrývající připojení, stereo párování, ovládání, nabíjení a technické údaje.
lang:hr score:56 filesize: 642.54 K page_count: 2 document date: 2023-11-12



[\[pdf\]](#)

6974173980244 SP100 PL Instrukcja obsługi pol EarFun UBOOM Slim Bluetooth vezeték nélküli hangszóró 53034 32519 e4dcb5f814c091b96f0d137be07b7aff puputeve hu media wysiwyg attachments
|||
INSTRUKCJA OBSŁUGI OBSŁUGA Przycisk włączania Przycisk regulacji głośności
Przycisk włączania Przy ... HK Limited niniejszym oświadcza, że typ urządzenia radiowego Głonik bezprzewodowy Bluetooth EarFun UBOOM Slim jest zgodny z dyrektywa 2014/53/UE. Pełny tekst deklaracji zgodności UE jest dostępny pod...
lang:id score:41 filesize: 3.93 M page_count: 8 document date: 2024-05-27



[pdf]

6974173980244 SP100 PL INSTRUKCJA OBSŁUGI Max ElektroGłośnik bezprzewodowy Bluetooth EarFun UBOOM Slim jest zgodny z dyrektywa 2014 53 UE Pełny tekst deklaracji zgodności dostępny pod gproxymaxeлектро pl storage file pimcore import 2024 12 18 87ed98d8610571b74b12e1f837049cf0 głośnik bluetooth earfun uboom s instrukcja obsługi |||

INSTRUKCJA OBSŁUGI OBSŁUGA Przycisk włączania Przycisk regulacji głośności Przycisk włączania Przy ... HK Limited niniejszym oświadcza, że typ urządzenia radiowego Głośnik bezprzewodowy Bluetooth EarFun UBOOM Slim jest zgodny z dyrektywą 2014/53/UE. Pełny tekst deklaracji zgodności UE jest dostępny pod... lang:id score:38 filesize: 3.93 M page_count: 8 document date: 2024-05-27

[pdf]



EarFun SP100 V1 20230512 UBOOM Slim 0628 7ReVrrOB api myearfun goods attachment gl 1*I298v* ga*MT11NTU2MDE4NC4xNjg5NjU4Njg2* ga 7G365S8Z0N*MTY4OTgwOTk1My4yLjEuMTY4OTgxMTQ 7G365S8Z0N*MTY4OTgwOTk1My4yLjEuMTY4OTgxMTQxMC42MC4wLjA EarFun 5000 Bluetooth UBOOM L Slim 20W mitsu blog EarFun Slim USB A to USB C ||| ... lang:id score:11 filesize: 1.92 M page_count: 1 document date: 2023-05-12