



[Manuals.plus](#) /

› [Esright](#) /

› [Esright Cream Sofa Couch \(Model B0CDKP786Z\) - User Manual](#)

Esright B0CDKP786Z

Esright Cream Sofa Couch User Manual

Model: B0CDKP786Z

[Introduction](#)

[Setup](#)

[Operating](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Warranty & Support](#)

1. INTRODUCTION

Thank you for choosing the Esright Cream Sofa Couch. This manual provides essential information for the safe and efficient assembly, operation, and maintenance of your new sofa. Please read it thoroughly before use and retain it for future reference.

This 2-seat sofa, with its 79-inch wide design, is crafted to provide comfort and style in your living room or bedroom. It features a durable construction and a soft polyester fabric upholstery in a cream color.



Image: The Esright Cream Sofa Couch, a two-seater, presented in a modern living room environment, showcasing its design and cream upholstery.

2. SETUP AND ASSEMBLY

Carefully unpack all components and ensure all parts are present before beginning assembly. It is recommended to assemble the sofa in the room where it will be used.

2.1 Unpacking

1. Open the packaging carefully, avoiding the use of sharp objects that could damage the upholstery.
2. Remove all components and protective materials.
3. Verify that all parts listed in the hardware and parts list (not provided in this general manual, refer to specific packaging insert) are accounted for.

2.2 Assembly Steps (General)

While specific assembly instructions may vary, typical sofa assembly involves the following steps:

1. Attach the legs to the base of the sofa. Ensure they are securely tightened.
2. Connect any modular sections if applicable, using the provided connectors.
3. Place the seat cushions and back cushions onto the sofa frame.

4. Ensure the sofa is stable and level before use.



Image: An angled view of the Esright Cream Sofa Couch, showing its full profile and how it fits into a living space.

3. OPERATING INSTRUCTIONS

The Esright Cream Sofa Couch is designed for comfortable seating for up to two individuals. Its ergonomic design provides support for the neck, lumbar, hips, and legs, promoting relaxation.

3.1 General Use

- Ensure the sofa is placed on a flat, stable surface.
- Avoid standing or jumping on the sofa.
- Distribute weight evenly when sitting to maintain the sofa's structural integrity.

Streamline Ergonomic Design

Fully relax your back, lumbar, and legs



Image: A diagram highlighting the ergonomic design of the sofa, indicating support for the neck, lumbar, hips, and legs.

3.2 Product Video

Your browser does not support the video tag.

Video: A short video showcasing the Esright Cream Sofa Couch in a cozy home environment, demonstrating its aesthetic appeal and suitability for everyday use.

4. MAINTENANCE AND CARE

Proper care will extend the life and appearance of your Esright sofa. The polyester fabric is designed for durability and ease of cleaning.

4.1 Cleaning Instructions

- **Regular Cleaning:** Vacuum the sofa regularly using an upholstery attachment to remove dust and loose debris.
- **Spot Cleaning:** For spills, blot immediately with a clean, dry cloth. Do not rub, as this can spread the stain. For stubborn stains, use a mild fabric cleaner specifically designed for polyester, testing on an inconspicuous area first.
- **Removable Covers:** The sofa features removable cushion covers for easier cleaning. Follow the care label instructions on the covers for washing. Typically, machine wash cold on a gentle cycle and

air dry.




Image: A close-up view of the sofa's breathable polyester fabric, emphasizing its texture and the benefit of removable covers for cleaning.

4.2 General Care Tips

- Avoid placing the sofa in direct sunlight to prevent fading.
- Keep sharp objects away from the upholstery to prevent tears or snags.
- Rotate cushions periodically to ensure even wear.

5. TROUBLESHOOTING

This section addresses common issues you might encounter with your sofa.

5.1 Loose Legs

- **Issue:** Sofa legs feel wobbly or loose.
- **Solution:** Periodically check and tighten all leg screws. Do not overtighten.

5.2 Slipping Seat Cushions

- **Issue:** Seat cushions tend to slide forward.

- **Solution:** Place a non-slip rug grip pad or similar material between the cushion and the sofa base to increase friction and prevent movement.

5.3 Minor Stains

- **Issue:** Small spills or marks on the fabric.
- **Solution:** Refer to the spot cleaning instructions in Section 4.1. Act quickly to prevent the stain from setting.

6. SPECIFICATIONS

Below are the key specifications for the Esright Cream Sofa Couch (Model B0CDKP786Z).



Image: A detailed diagram showing the dimensions of the sofa, including overall width (79.0"), height (34.3"), depth (31.5"), arm width (5.7"), seat depth (27"), seat height (17.7"), and a weight capacity of 800 lbs.

Feature	Detail
Brand	Esright
Model Number	B0CDKP786Z

Feature	Detail
Seating Capacity	2
Type	Futon (Sofa Couch)
Color	Cream
Upholstery Fabric Type	Polyester
Room Type	Bedroom, Living Room
Shape	Rectangular
Arm Style	Track
Pattern	Solid
Item Dimensions (W x D x H)	79 x 31.5 x 34.3 inches
Material Type	Alloy Steel, Polyester, Wood
Weight Capacity	800 lbs

7. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation included with your purchase or contact Esright customer service directly. Keep your purchase receipt for warranty claims.

Contact Information: Please visit the official Esright website or refer to your product packaging for the most up-to-date contact details.