

[Manuals.plus](#) /

› [EAGLE PEAK](#) /

› EAGLE PEAK 12x8 Pop Up Greenhouse Instruction Manual

EAGLE PEAK GH96EPT-WHT-AZ

EAGLE PEAK 12x8 Pop Up Greenhouse

MODEL: GH96EPT-WHT-AZ

Your guide to easy setup, operation, and maintenance.

Introduction

Thank you for choosing the EAGLE PEAK 12x8 Pop Up Greenhouse. This manual provides essential information for the safe and efficient assembly, operation, and care of your greenhouse. Please read all instructions carefully before beginning assembly and retain this manual for future reference.



Image: The EAGLE PEAK 12x8 Pop Up Greenhouse, providing a spacious environment for plants.

Safety Information

For your safety and to prevent damage to the product, observe the following guidelines:

- This greenhouse is designed for external use only. Do not use indoors.
- Ensure the greenhouse is securely anchored to the ground using the provided stakes and ropes to prevent wind damage.
- Regularly clear any snow accumulation from the roof to prevent collapse. Heavy snow loads can damage the frame.
- Avoid placing the greenhouse near open flames or heat sources.
- Keep children and pets away during assembly and disassembly.

Package Contents

Verify that all components are present before beginning assembly:

- Pre-assembled Steel Frame
- PE Greenhouse Cover
- Adjustable Winter Support Pole
- Ground Stakes (16 pieces)
- Wind Ropes (4 pieces)
- Carry Bag

PACKAGE INCLUDES



x 16



x 4



x 1

Image: All components included in the package, such as the frame, cover, support pole, stakes, ropes, and carry bag.

Setup Instructions

The EAGLE PEAK greenhouse features a patented center lock system for quick and easy assembly. No tools are required.

1. **Step 1: Open the Canopy Frame.** Carefully pull the legs of the folded frame outwards to begin expanding it.

EASY SETUP



STEP 01

Open the canopy frame



STEP 02

Attach the top and push up on the Easy Peak Center-Push mechanism to lock the frame



STEP 03

Adjust the height for preferred shade coverage


Image: The initial step of unfolding the greenhouse frame.

- Step 2: Attach the Cover and Lock the Frame.** Place the PE greenhouse cover over the partially opened frame. Once the cover is in place, push up on the Easy Peak Center-Push mechanism located at the center of the frame until it locks into position. This secures the frame.



LIFT. LOCK. DONE.

One-person setup
in seconds
No tools. No
hassle. No pinched
fingers




Powered by our patented PeakPush™ Center Lock

Image: Detail of the Peak Push center lock mechanism for quick frame locking.

- Step 3: Adjust Height and Secure.** Adjust the height of the greenhouse legs to your preferred setting using the push-button adjusters. Once the desired height is set, secure the greenhouse to the ground using the provided stakes and wind ropes. Ensure the skirt of the cover is properly sealed around the base.

WALK-IN DESIGN

provides growing space and ventilation for plants.



Double layer reinforcement at corners and peak




2 Large Roll Up doors for walk-in access and cross ventilation.



2 Large windows (list size) for ventilation.



Hook



Three-layer UV Resistant PE film with tear-resistant reinforcement.



Skirt for ground seal

Image: The greenhouse fully assembled, showing the roll-up doors and windows, and the skirt for ground seal.

- Step 4: Install Winter Support Pole (Optional).** For added stability, especially in winter conditions, install the adjustable support pole inside the greenhouse. Position it centrally to support the roof structure.

UNIQUE ADJUSTABLE SUPPORT POLE

Add Super Stability to Your Greenhouse



Image: The adjustable support pole installed inside the greenhouse for enhanced stability.

Setup Video Guide

Video: A detailed guide on setting up the EAGLE PEAK 12x8 FT Instant Pop-up Greenhouse. This video demonstrates the quick assembly process.

Video: An overview of the EAGLE PEAK Pop Up Greenhouse features and ease of setup. While demonstrating an 8x6 model, the setup principles apply to the 12x8 model.

Video: A comprehensive look at the EAGLE PEAK 12'x8' Portable Large Walk-in Greenhouse, highlighting its features and assembly.

Operating Instructions

Your greenhouse is designed for optimal plant growth and protection. Utilize its features for best results:

- **Ventilation:** The greenhouse is equipped with zippered roll-up doors and mesh windows. Open these features to provide cross-ventilation and regulate internal temperature and humidity. Close them to retain heat and protect plants from external elements.

- **Access:** The large roll-up doors allow for easy walk-in access, making it convenient to tend to your plants and move items in and out.
- **Stability:** The included winter support pole enhances the structural integrity of the greenhouse, particularly important during periods of high wind or light snow. Always ensure the greenhouse is properly anchored.
- **Environmental Control:** The premium PE cover is designed to maintain optimal humidity levels and filter sunlight, creating a healthy growth environment.

THE ORIGINAL POP UP GREENHOUSE



Easy Set up



Water Resistant



UV Protection



Portable



Image: Dimensions of the 12x8 greenhouse, illustrating the spacious interior and access points.

Maintenance

Proper maintenance will extend the life of your EAGLE PEAK greenhouse:

- **Cleaning:** Clean the PE cover periodically with mild soap and water. Avoid harsh chemicals that could damage the material.
- **Inspection:** Regularly inspect the frame, cover, stakes, and ropes for any signs of wear, damage, or corrosion. Replace or repair components as needed.

- **Snow Removal:** In areas prone to snow, it is crucial to brush off snow accumulation from the roof promptly. Even small amounts of heavy, wet snow can cause structural stress and potential collapse.
- **Storage:** When not in use for extended periods, or during severe weather warnings, disassemble the greenhouse and store it in its carry bag in a dry, protected area.

Troubleshooting

Here are solutions to common issues you might encounter:

- **Greenhouse Instability:** Ensure all legs are fully extended and locked. Verify that stakes are firmly in the ground and wind ropes are taut. Consider additional anchoring methods like sandbags or heavy-duty ground anchors in very windy conditions.
- **Water Leakage:** Check for proper seating of the cover over the frame. Small tears in the PE cover can be repaired with appropriate repair tape designed for polyethylene.
- **Difficulty with Setup/Takedown:** Ensure the center lock mechanism is fully engaged or disengaged. If the cover gets caught in joints, gently adjust it before expanding or collapsing the frame.
- **Insufficient Light/Heat:** Ensure the cover is clean to maximize light transmission. For colder climates, supplementary heating may be required to maintain desired internal temperatures.

Specifications

Feature	Detail
Brand	EAGLE PEAK
Model Number	GH96EPT-WHT-AZ
Color	Clear/White
Product Dimensions (L x W x H)	141.7" x 94.5" x 87.6"
Item Weight	50.3 pounds
Cover Material	Polyethylene (PE)
Frame Material	Alloy Steel
Number of Doors	2 (Roll-Up)
Number of Vents	2 (Mesh Windows)
Special Features	Heavy Duty, Pop-Up, Patented Center Lock
Indoor/Outdoor Usage	Outdoor

Warranty and Support

EAGLE PEAK offers a **1-year limited after-sale protection** from the original date of purchase. This warranty covers the frame and cover. For any questions, issues, or warranty claims, please contact our professional service team. You can reach out to the seller, Eagle Peak, directly through your purchase platform for assistance.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question