



Manuals.plus /

- › OKD /
- › OKD Farmhouse Electric Fireplace TV Stand User Manual

## OKD PFC70

# OKD Farmhouse Electric Fireplace TV Stand User Manual

Model: PFC70 | Brand: OKD

## 1. INTRODUCTION

---

Thank you for choosing the OKD 3-Sided Glass Farmhouse Electric Fireplace TV Stand. This manual provides essential information for the safe assembly, operation, and maintenance of your new entertainment center. Please read all instructions carefully before beginning assembly or operation.



*Image: The fully assembled OKD Farmhouse Electric Fireplace TV Stand in Antique White, showcasing its design and integrated fireplace.*

## 2. SAFETY INFORMATION

---

To reduce the risk of fire, electric shock, or injury, please adhere to the following safety guidelines:

- Always unplug the fireplace from the power outlet before cleaning, performing maintenance, or relocating the unit.
- Do not operate the fireplace with a damaged cord or plug, or if the heater has malfunctioned, been dropped, or damaged in any manner.
- Keep combustible materials such as furniture, pillows, bedding, papers, clothes, and curtains at least 3 feet (0.9 m) from the front of the heater.
- Ensure the unit is placed on a firm, level surface capable of supporting its weight (up to 300 lbs).
- This product is designed for indoor use only. Do not use outdoors.
- The fireplace features overheat protection. If the heater overheats, it will automatically shut off. Unplug the unit and allow it to cool before restarting.

- Assembly requires two people. Follow all assembly steps carefully to ensure structural integrity.

### 3. PACKAGE CONTENTS

---

Your OKD Fireplace TV Stand will arrive in two separate packages. Please ensure you have received both packages and all components before beginning assembly. Inspect all parts for damage before assembly. If any parts are missing or damaged, contact customer support.



*Image: An illustration depicting the product being delivered in two separate packages, emphasizing that they may arrive on different days.*

#### Typical Components Include:

- TV Stand Panels (top, bottom, side, back)
- Fireplace Insert (36-inch electric fireplace)
- Drawer Components
- Cabinet Doors (with glass and barn door elements)
- Adjustable Glass Shelves
- Hardware Pack (screws, dowels, cam locks, etc.)
- Remote Control for Fireplace
- Assembly Instructions Manual

### 4. ASSEMBLY INSTRUCTIONS

---

Assembly is required for this product. It is recommended that two adults assemble this unit. Please follow the detailed step-by-step instructions provided in the separate assembly manual included with your packages. Below is a general overview of the assembly process:

1. **Unpack and Identify Parts:** Lay out all components on a soft, clean surface to prevent scratches. Verify all parts against the parts list in your assembly manual.
2. **Assemble the Main Frame:** Connect the base, side panels, and top panel using the provided hardware.
3. **Install the Fireplace Insert:** Carefully slide the 36-inch electric fireplace into its designated opening. Ensure it is securely seated.
4. **Assemble Drawers and Cabinets:** Construct the two drawers and attach the two storage cabinet doors. Install the adjustable glass shelves within the cabinets.
5. **Cable Management:** Utilize the cable management hole at the back of the unit to organize and route power cords for your TV and other devices.
6. **Final Checks:** Ensure all connections are tight and the unit is stable before placing any items on it.



*Image: A detailed diagram illustrating the overall dimensions of the TV stand (70" W x 17" D x 32" H) and the internal dimensions of a drawer.*



*Image: A top-down perspective of the TV stand, highlighting the open storage compartments and the pull-out drawers, demonstrating the ample storage space.*



*Image: A close-up view of an open drawer, showing its interior and a remote control placed inside, illustrating the practical storage for accessories.*



## 70" Farmhouse Fireplace TV Stand



Solid and Stable Base



Comfortable Handle



Adjustable Glass Shelves



2 Drawers & 2 Cabinets

*Image: A composite image highlighting key features such as the solid and stable base (3.93" height), comfortable handle, adjustable glass shelves, and the presence of two drawers and two cabinets.*

## 5. SETUP

### Placement:

Choose a suitable location for your TV stand. Ensure it is on a flat, stable surface and away from direct sunlight or heat sources. The stand is designed to accommodate TVs up to 80 inches.



*Image: A visual guide demonstrating the compatibility of the TV stand with various television sizes, indicating it can hold TVs up to 80 inches.*

### **Power Connection:**

Plug the fireplace power cord into a grounded 120V AC outlet. Do not use extension cords or power strips with this appliance.

## **6. OPERATING INSTRUCTIONS**

### **Electric Fireplace Operation:**

The 36-inch electric fireplace can be controlled via the touch screen control panel on the unit or the included remote control. Flame and heat functions can be operated separately.

## 36" 3-Sided Glass Fireplace



- DUAL CONTROL DESIGN**  
Touch screen control panel & remote control
- HEATING MATERIAL**  
Infra red quartz heating element
- PANORAMIC FIREPLACE**  
Glass surface for all- round enjoyment
- 400 SQ. FT. OF WARMTH(5118BTUS)**  
Temperature between 64° F to 82° F
- REAL FIRE EFFECT**  
3 Colors & 5 Levels flame & life-like logs
- ENERGY SAVING**  
Independent flame and temperature control
- TIMER**  
1-9 hours timing-enjoy your night
- NOISE LEVEL**  
Low noise

Image: A detailed view of the 36-inch 3-sided glass fireplace insert, highlighting its features such as dual control (touch screen and remote), infrared quartz heating, panoramic view, heating capacity (5118 BTUs for 400 sq. ft.), real fire effect with 3 colors and 5 flame levels, energy saving, timer (1-9 hours), and low noise level.

## 3 COLOR REALISTIC FIREPLACE FLAME



Image: Three panels showing the fireplace flames in different colors: blue, orange, and red, demonstrating the customizable flame effects.

- **Power:** Press the power button to turn the fireplace ON/OFF.
- **Heat:** Adjust the heat settings. The fireplace provides 5118 BTUs, suitable for heating up to 400 sq. ft., maintaining a temperature between 64°F to 82°F.
- **Flame Effect:** Choose from 3 elegant flame colors and 5-speed flame adjustments (P1-P5).
- **Timer:** Set the operational timer from 1 to 9 hours.
- **Brightness:** Adjust the flame brightness (L1-L5).

### LED Cabinet Lights:

The storage cabinets feature integrated LED lights. These lights can be turned on or off to illuminate your displayed items.



*Image: A close-up view of an open cabinet door, revealing the adjustable glass shelf and the internal LED lighting that illuminates the contents.*

## 7. MAINTENANCE

- **Cleaning:** Dust the unit regularly with a soft, dry cloth. For stubborn marks, use a slightly damp cloth and dry immediately. Do not use abrasive cleaners or polishes.
- **Fireplace Care:** The electric fireplace requires minimal maintenance. Ensure the air intake/output vents are clear of obstructions.
- **Hardware Check:** Periodically check all screws and connections to ensure they remain tight.

## 8. TROUBLESHOOTING

| Problem                      | Possible Cause   | Solution   |
|------------------------------|--|--|
| Fireplace does not turn on.  | No power, power cord loose, overheat protection activated. | Check power outlet, ensure cord is securely plugged in. Unplug and allow unit to cool for 15-20 minutes before plugging back in. |
| No heat output.              | Heat function not activated, thermostat setting too low.   | Ensure heat function is turned on. Increase thermostat setting.  |
| Remote control not working.  | Dead batteries, obstruction, remote out of range.          | Replace batteries. Remove any obstructions between remote and fireplace. Ensure you are within effective range.                  |
| Unit is unstable or wobbles. | Uneven floor, loose assembly hardware.                     | Move to a level surface. Re-tighten all assembly screws.   |

## 9. SPECIFICATIONS

**Brand:** OKD

**Model Name:** Fireplace TV Stand (PFC70)

**Color:** Antique White

**Product Dimensions:** 70"W x 17"D x 32"H

**Fireplace Dimensions:** 37.2"W x 8.2"D x 18"H

**Material:** Engineered Wood

**Weight Limit:** 300 Pounds

**Item Weight:** 183 Pounds

**Recommended TV Size:** Up to 80 inches

**Fireplace Heat Output:** 5118 BTUs

**Heating Area:** Up to 400 sq. ft.

**Temperature Range:** 64°F to 82°F

**Special Features:** 3-Sided Glass Fireplace, LED Cabinet Lights, Cable Management, Overheat Protection (ETL/FCC Certified)

**Assembly Required:** Yes

## 10. WARRANTY AND SUPPORT

---

For warranty information, technical support, or to order replacement parts, please contact OKD customer service. Refer to the contact information provided in your original purchase documentation or visit the official OKD website.

**OKD Customer Service:** Visit the OKD Store on Amazon