

[Manuals.plus](#) /

› [SANODESK](#) /

› SANODESK QS1 Electric Sit-Stand Desk 160x75 cm User Manual

SANODESK QS1W-1675-EU

SANODESK QS1 Electric Sit-Stand Desk 160x75 cm User Manual

Model: QS1W-1675-EU

1. INTRODUCTION

Thank you for choosing the SANODESK QS1 Electric Sit-Stand Desk. This manual provides essential information for the safe and efficient assembly, operation, and maintenance of your new desk. Please read it thoroughly before use and retain it for future reference.



Image 1.1: The SANODESK QS1 Electric Sit-Stand Desk, showcasing its spacious white desktop and integrated accessories like headphone and bag hooks.

2. SAFETY INFORMATION

Please observe the following safety precautions to prevent injury or damage to the product:

- Ensure all components are securely fastened before use.
- Keep children and pets away from the desk during operation.
- The desk features a child safety system and an automatic shut-off function that activates upon resistance to prevent injury.
- Do not overload the desk. The maximum load capacity is 60 kg.
- Avoid placing liquids directly on the control panel or motor components.
- Only use the provided power adapter.



Image 2.1: Safety and compliance certifications for the SANODESK QS1 desk.

3. PACKAGE CONTENTS

Verify that all components are present before beginning assembly:

- Desktop (160x75 cm, 2-piece)
- Electric Lifting Frame (2 legs, crossbar)
- Control Panel with LED Display
- Power Adapter and Cable
- Cup Holder
- Metal Hooks (2 pieces)
- Assembly Hardware (screws, tools)
- User Manual

4. SETUP AND ASSEMBLY

Follow these general steps for assembly. Refer to the included assembly diagram for detailed instructions.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Assemble Frame:** Attach the lifting columns to the feet, then connect the crossbar. Ensure all bolts are tightened securely.
3. **Attach Desktop:** Place the desktop sections onto the assembled frame. Align the pre-drilled holes and secure the desktop using the provided screws.
4. **Install Control Panel:** Mount the control panel to the underside of the desk in a convenient location. Connect the motor and power cables to the control panel.
5. **Install Accessories:** Attach the cup holder and metal hooks to the desired positions on the desk.
6. **Cable Management:** Use cable ties or clips (if provided) to organize and secure all cables to prevent snagging during height adjustments.
7. **Initial Calibration:** After connecting power, the desk may require an initial calibration. Press and hold the 'Down' button until the desk reaches its lowest point and slightly rises, indicating successful calibration.

5. OPERATING INSTRUCTIONS

The SANODESK QS1 features an advanced LED control panel for easy height adjustment and memory functions.

Commande Manuelle Pour Un Espace De Travail Personnalisé



Écran LED



Haut/Bas



S'asseoir/Se Lever



Verrouillage Enfant



Fonction Mémoire



Image 5.1: The LED control panel for the SANODESK QS1 desk.

5.1 Basic Height Adjustment

- **Raise Desk:** Press and hold the **Up (▲)** button to raise the desk to your desired height.
- **Lower Desk:** Press and hold the **Down (▼)** button to lower the desk to your desired height.
- The LED display will show the current height in centimeters.

5.2 Memory Presets

The control panel allows you to save two preferred height settings.

1. Set a Memory Position:

- Adjust the desk to your desired height using the Up/Down buttons.
- Press the **"M"** button (Memory). The LED display will show "S-".
- Immediately press either **"1"** or **"2"** to save the current height to that preset number. The display will show "S-1" or "S-2" to confirm.

2. Recall a Memory Position:

- Simply press the "1" or "2" button. The desk will automatically move to the saved height.

5.3 Child Safety Lock

To prevent accidental adjustments, activate the child safety lock:

- **Activate Lock:** Press and hold the "Lock" button (often represented by a padlock icon) for 3 seconds. The display will show "LOC" or a lock icon. All buttons will be disabled.
- **Deactivate Lock:** Press and hold the "Lock" button again for 3 seconds. The display will return to the height reading, and buttons will be active.

5.4 Anti-Collision System

The desk is equipped with an anti-collision system. If the desk encounters an obstacle during height adjustment, it will automatically stop and reverse slightly to prevent damage.



Image 5.2: The SANODESK QS1 desk operates quietly, below 51 dB, ensuring a peaceful work environment.

6. FEATURES

- **Electric Height Adjustment:** Smooth and quiet motor operation (below 51 dB) for seamless transitions between sitting and standing positions.
- **Adjustable Height Range:** From 71 cm to 116 cm (without top, frame adjustable from 71 cm to 121 cm).
- **Smart Memory Control Panel:** LED display with 2 programmable memory presets for customized heights.
- **Child Safety System:** Prevents accidental adjustments.
- **Anti-Collision Function:** Automatically stops and reverses upon encountering obstacles.
- **Sturdy Construction:** Robust design with a load capacity of up to 60 kg.
- **Integrated Accessories:** Includes a convenient cup holder and two metal hooks for headphones or bags.

CUP HOLDER FOR CONVENIENT ACCESS



Image 6.1: Integrated cup holder for convenient access.

| Crochets Métalliques (Lot De 2)

Accrochez Facilement
Vos Objets Fréquemment
Utilisés.



Image 6.2: Two metal hooks for organizing accessories.

7. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your SANODESK QS1 desk.

- **Cleaning:** Wipe the desktop and frame with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals.
- **Inspection:** Periodically check all screws and bolts to ensure they are tight. Retighten if necessary.
- **Cable Management:** Ensure cables are not pinched or tangled, especially during height adjustments.
- **Motor Care:** The motor is designed for maintenance-free operation. Do not attempt to open or lubricate the motor housing.

8. TROUBLESHOOTING

If you encounter issues with your SANODESK QS1 desk, refer to the following common solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Desk does not move.	Power cable disconnected, child lock active, motor overload.	Check power connection. Deactivate child lock. Reduce load on desk. Perform calibration.
Desk moves unevenly or makes unusual noise.	Loose connections, uneven load, obstruction.	Check all assembly connections. Redistribute weight evenly. Check for obstructions. Perform calibration.
LED display shows an error code.	Specific error (e.g., overload, sensor issue).	Refer to the specific error code in the full manual (if available) or contact customer support. Often, a power cycle (unplug, wait 30 seconds, plug back in) can resolve temporary errors.
Memory presets not working.	Presets not saved correctly.	Re-save the memory presets following the instructions in Section 5.2.

If the problem persists after attempting these solutions, please contact SANODESK customer support.

9. SPECIFICATIONS

Feature	Detail
Brand	SANODESK
Model Number	QS1W-1675-EU
Color	White
Desktop Dimensions (L x W)	160 cm x 75 cm
Height Adjustment Range	71 cm to 116 cm
Load Capacity	60 kg
Motor Type	Single Motor
Noise Level	Below 51 dB
Material	Wood (desktop), Metal/Alloy Steel (frame)
Special Features	Ergonomic, Height Adjustable, Electric, Memory Presets, Child Safety Lock, Anti-Collision
Item Weight	29.3 Kilograms



Image 9.1: Desk dimensions and load capacity.

Réglage En Hauteur De 73 À 118 Cm



Image 9.2: Visual representation of the height adjustment range.

10. WARRANTY INFORMATION

Specific warranty details are not provided in the product information. Please refer to the product packaging or contact SANODESK customer support for warranty terms and conditions.

11. CUSTOMER SUPPORT

For further assistance, technical support, or inquiries regarding your SANODESK QS1 Electric Sit-Stand Desk, please contact SANODESK customer service through their official website or the retailer where the product was purchased.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question