

[Manuals.plus](#) /

› [SANODESK](#) /

› SANODESK QS1 Electric Sit-Stand Desk User Manual

SANODESK QS1M1160

SANODESK QS1 Electric Sit-Stand Desk User Manual

Model: QS1M1160 | Brand: SANODESK

1. IMPORTANT SAFETY INFORMATION

Please read this manual carefully before assembly and operation to ensure safe and correct use of your SANODESK QS1 Electric Sit-Stand Desk. Keep this manual for future reference.

- This product is intended for adult use only. Keep children and pets away from the desk during operation.
- Ensure all cables are properly managed and secured to prevent tripping hazards or damage during height adjustments.
- Do not place objects taller than the maximum desk height under the desk to avoid collisions during lowering.
- Do not sit or stand on the desk.
- Do not open or attempt to repair the motor or control box. Contact qualified service personnel for repairs.
- Disconnect power before cleaning or maintenance.
- The desk features an integrated automatic shut-off system that stops the motor if resistance is encountered. Do not force the desk if it stops unexpectedly.

2. PRODUCT OVERVIEW

The SANODESK QS1 Electric Sit-Stand Desk is designed to provide a versatile and ergonomic workspace, allowing seamless transitions between sitting and standing positions. It features a robust single-motor system, a user-friendly control panel with memory presets, and thoughtful accessories for enhanced organization.



Figure 2.1: Overview of the SANODESK QS1 Electric Sit-Stand Desk with accessories.

Key Features:

- **Electric Height Adjustment:** Smooth and quiet transitions between sitting and standing heights.
- **Memory Presets:** Store and recall up to four preferred height settings.
- **Silent Operation:** Motor operates below 51 dB for a quiet work environment.
- **Child Safety System:** Enhanced safety features to prevent accidental operation.
- **Sedentary Reminder:** Promotes healthy work habits by reminding you to change positions.
- **Integrated Accessories:** Includes a cup holder and metal hooks for convenience.
- **Cable Management:** Designed for effortless organization of power cords and cables.

3. SETUP AND ASSEMBLY

This section provides general guidelines for assembling your SANODESK QS1. For detailed, step-by-step instructions, please refer to the dedicated assembly manual included in your product packaging.

3.1 Unpacking and Inspection

1. Carefully open the packaging and remove all components.
2. Verify that all parts listed in the assembly manual are present and undamaged. Contact customer support immediately if any parts are missing or damaged.
3. Keep packaging materials until assembly is complete in case of return or exchange.

3.2 Assembly Steps (General)

Assembly typically involves attaching the desk legs to the tabletop and connecting the motor and control panel. Ensure all screws are tightened securely.



Figure 3.1: Illustrative diagram of desk components and assembly points. Refer to your specific assembly guide for detailed steps.

3.3 Initial Power-Up

1. Once assembled, connect the power cable to the control box and then to a grounded power outlet.
2. The desk may perform an initial calibration cycle upon first power-up. Allow it to complete this process without interruption.

4. OPERATING INSTRUCTIONS

4.1 Control Panel Functions

The SANODESK QS1 features an intuitive control panel for easy height adjustment and memory functions.



Figure 4.1: Close-up of the control panel with LED display and function buttons.

LED Display: Shows the current desk height in centimeters.

Up/Down Buttons (▲ / ▼): Press and hold to raise or lower the desk. Release to stop at the desired height.

Sit/Stand Button (↕): This button may be used to toggle between pre-set sitting and standing heights or to activate a quick transition.

Memory Function Buttons (1, 2, 3, 4): Store and recall your favorite height settings.

4.2 Setting Memory Presets

1. Adjust the desk to your desired height using the Up/Down buttons.

2. Press the "M" or "SET" button (if available, otherwise proceed to next step).
3. Immediately press one of the memory buttons (1, 2, 3, or 4) until the display flashes or beeps, indicating the height has been saved.
4. To recall a saved height, simply press the corresponding memory button (1, 2, 3, or 4). The desk will automatically move to that height.

4.3 Sedentary Reminder Function

The desk is equipped with a sedentary reminder function to encourage regular movement. Consult your specific control panel's instructions for activation and customization of reminder intervals.

4.4 Child Safety Lock

To prevent accidental operation, especially by children, the control panel may feature a child safety lock. Typically, this is activated by pressing and holding a specific combination of buttons (e.g., "M" and "Down" simultaneously) for a few seconds until a lock indicator appears on the display. Repeat the process to unlock.

5. FEATURES AND ACCESSORIES

The SANODESK QS1 is designed with user convenience in mind, incorporating several useful features and accessories.

5.1 Cup Holder

A convenient cup holder is provided to keep your beverages secure and within easy reach, preventing spills on your workspace.

I SMOOTH AND QUIET MOVEMENT

operates with minimal noise, ideal for maintaining concentration and productivity



Figure 5.1: The integrated cup holder for convenient access to beverages.

5.2 Metal Hooks

Two sturdy metal hooks are included, allowing you to hang headphones, bags, or other frequently used items, keeping your desk surface clear and organized.

CUP HOLDER FOR CONVENIENT ACCESS



Figure 5.2: Metal hooks provide convenient storage for headphones or other items.

5.3 Cable Management

The desk is designed to facilitate neat cable organization, helping to maintain a clutter-free and professional workspace.



| UNDER-DESK STORAGE FOR CLUTTER-FREE ORGANIZATION

Figure 5.3: Under-desk storage for effective cable management.

I EFFORTLESS CABLE ORGANISATION



Figure 5.4: Example of improved cable organization with the desk's features.

6. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your SANODESK QS1.

- **Cleaning:** Wipe the desk surface and frame with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Cable Check:** Periodically inspect all cables for wear or damage. Ensure they are securely connected and not pinched during movement.
- **Screw Tightness:** Occasionally check and tighten any loose screws, especially on the frame and leg connections, to maintain stability.
- **Motor Care:** The motor is maintenance-free. Do not lubricate or attempt to open it.

7. TROUBLESHOOTING

If you encounter issues with your SANODESK QS1, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Desk does not move.	Power cable disconnected; Overload; Motor overheating; Safety lock engaged.	Check power connection. Reduce load on desk. Allow motor to cool down. Deactivate child safety lock.
Desk moves unevenly or makes unusual noise.	Loose connections; Obstruction; Uneven floor.	Check and tighten all screws. Remove any obstructions. Ensure desk is on a level surface.
Error code displayed (e.g., E01, E02).	Specific system error.	Refer to the detailed error code list in your assembly manual or contact customer support. Often, a power cycle (unplug for 30 seconds, then plug back in) can resolve minor errors.
Memory presets not working.	Presets not saved correctly.	Re-save the memory presets following the instructions in Section 4.2.

7.1 Reset Procedure

If the desk is unresponsive or behaving erratically, a factory reset may resolve the issue. Consult your specific control panel's instructions for the exact reset procedure. A common method involves pressing and holding the "Down" button until the desk reaches its lowest point, then continuing to hold for several seconds until it slightly rises and stops, indicating a successful reset.

8. SPECIFICATIONS

Technical specifications for the SANODESK QS1 Electric Sit-Stand Desk.

Attribute	Value
Brand	SANODESK
Model Number	QS1M1160
Color	Maple
Dimensions (L x W x H)	110 cm x 60 cm x 79 cm (fixed height)
Adjustable Height Range	73.5 cm to 118 cm
Weight	20.5 Kilograms
Material	Engineered Wood (top), Metal (frame)

Attribute	Value
Load Capacity	Up to 60 kg
Motor Noise Level	Below 51 dB
Special Features	Ergonomic, Height Adjustable, Electric, Memory Presets, Sedentary Reminder, Child Safety System, Silent Operation, Cup Holder, Metal Hooks, Cable Management



Figure 8.1: Key dimensions of the desk tabletop (110cm x 60cm).

DIFFERENT HEIGHTS FOR ALL



Figure 8.2: Illustration of the adjustable height range from minimum (73.5cm) to maximum (118cm).

9. WARRANTY AND SUPPORT

SANODESK products are manufactured to high-quality standards. For information regarding warranty coverage, please refer to the warranty card included with your product or visit the official SANODESK website.

If you require technical assistance, have questions about assembly, or need to report a defect, please contact SANODESK customer support:

- **Online Support:** Visit [SANODESK Official Store on Amazon](#) for FAQs and contact options.
- **Email:** Refer to your product packaging or warranty card for direct email support.

Please have your model number (QS1M1160) and purchase date ready when contacting support.

