

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [DELIPOP](#) /

› [DELIPOP Sputnik Light Fixture \(Model 30917720\) - Instruction Manual](#)

DELIPOP 30917720

DELIPOP Sputnik Light Fixture (Model 30917720) - Instruction Manual

For Model: 30917720

1. PRODUCT OVERVIEW

The DELIPOP Sputnik Light Fixture (Model 30917720) is an 8-light gold ceiling fixture designed to provide 360-degree illumination. It features a mid-century modern and industrial style, constructed from high-quality electroplated gold metal. This fixture is suitable for various indoor spaces including living rooms, bedrooms, kitchens, dining rooms, and home offices.



Figure 1: DELIPOP Sputnik Light Fixture in a living room setting.

2. SAFETY INFORMATION

Please read all instructions carefully before installation and use. Failure to follow these instructions may result in electric shock, fire, or other hazards.

- **WARNING:** To avoid electric shock, disconnect power at the circuit breaker or fuse box before installation.
- All electrical connections must be in accordance with local codes, ordinances, or the National Electric Code (NEC). Consult a qualified electrician if you are unfamiliar with electrical wiring.
- Do not install this fixture in wet or damp locations. This product is designed for indoor use only.
- Ensure the mounting surface can support the weight of the fixture.
- Do not exceed the maximum wattage specified for each bulb socket (60W).
- Keep flammable materials away from the light fixture when in operation.
- Always allow bulbs to cool before touching or replacing them.

3. PACKAGE CONTENTS

Carefully unpack the fixture and check that all components are present and undamaged. If any parts are missing or broken, contact customer support before proceeding with installation.

- Sputnik Light Fixture Body (pre-wired and pre-threaded arms)
- Mounting Hardware (Canopy, Mounting Plate, Wire Nuts, Screws, Anchors, Wrench)
- Instruction Manual





Figure 2: Included components and mounting hardware.

4. SPECIFICATIONS

Feature	Detail
Brand	DELIPOP

Model Number	30917720
Color	Gold
Material	Metal
Style	Mid-Century Modern, Industrial
Light Fixture Form	Close to Ceiling
Product Dimensions (L x W x H)	21.68" x 21.68" x 5.51"
Power Source	Corded Electric
Installation Type	Semi Flush Mount
Number of Light Sources	8
Voltage	110 Volts
Bulb Base	E26
Max Wattage per Bulb	60 Watts
Compatible Bulb Types	Edison, Halogen, CFL, Incandescent, LED (Bulbs NOT Included)
Item Weight	2.9 pounds

Product Size



Recommend E26 Bulbs

(Bulbs NOT Included)



Figure 3: Product dimensions and bulb recommendations.

5. SETUP AND INSTALLATION

The DELIPOP Sputnik Light Fixture is designed for easy installation, with all lamp arms pre-wired and pre-threaded. Follow these steps for safe and proper installation:

- 1. Turn Off Power:** Before starting, ensure the power supply to the installation area is completely turned off at the circuit breaker or fuse box.
- 2. Prepare Mounting Plate:** Attach the mounting plate to the junction box in your ceiling using the provided screws. Ensure it is securely fastened.
- 3. Assemble Fixture Arms:** The fixture arms are pre-wired. Gently screw each arm into the central hub of the fixture body. Ensure they are tightened securely.
- 4. Wire Connections:** Connect the fixture's wires to your household electrical wires. Typically, connect the black wire from the fixture to the black wire from the ceiling (live), the white wire from the fixture to the white wire from the ceiling (neutral), and the ground wire from the fixture to the ground wire from the ceiling. Use the provided wire nuts to secure connections.
- 5. Mount Fixture:** Carefully lift the assembled fixture and align the mounting holes on the canopy with the

screws on the mounting plate. Secure the fixture to the mounting plate with the decorative nuts.

- 6. Install Bulbs:** Screw 8 E26 base bulbs (not included) into the sockets. Ensure the bulbs do not exceed 60W each.
- 7. Restore Power:** Once installation is complete and all connections are secure, restore power at the circuit breaker.




Figure 4: Details of the E26 socket, metal lamp body, and base.

6. OPERATING INSTRUCTIONS

This light fixture operates using a standard wall switch (not included). Once installed and powered, simply use your wall switch to turn the light fixture on or off.

- Ensure compatible E26 bulbs are correctly installed.
- The fixture is compatible with various E26 bulb types, including Edison, Halogen, CFL, Incandescent, and LED.
- For dimmable functionality, use dimmable E26 bulbs and a compatible dimmer switch (sold separately).



Figure 5: Light fixture demonstrating ON and OFF states with different bulb types.

7. MAINTENANCE

Regular maintenance will help preserve the appearance and functionality of your light fixture.

- **Cleaning:** Always turn off the power and allow the fixture to cool before cleaning. Wipe the fixture with a soft, dry cloth. Do not use abrasive cleaners, solvents, or polishes as they may damage the finish.
- **Bulb Replacement:** Ensure the power is off and bulbs are cool before attempting to replace them. Unscrew the old bulb and screw in a new E26 bulb, ensuring it does not exceed the maximum 60W wattage.
- **Inspection:** Periodically check all connections and mounting hardware to ensure they remain secure.

8. TROUBLESHOOTING

If you encounter issues with your DELIPOP Sputnik Light Fixture, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Light does not turn on.	<ul style="list-style-type: none"> Power is off at the circuit breaker. Loose wire connections. Faulty bulb(s). Faulty wall switch. 	<ul style="list-style-type: none"> Check the circuit breaker and ensure power is on. Turn off power, check all wire connections, and re-secure if loose. Replace bulb(s) with new, working E26 bulbs. Test the wall switch or consult an electrician.
Light flickers.	<ul style="list-style-type: none"> Loose bulb. Incompatible dimmer switch/bulb. Loose wire connection. 	<ul style="list-style-type: none"> Tighten the bulb securely. Ensure dimmable bulbs are used with a compatible dimmer switch. Turn off power, check and tighten wire connections.
Fixture is unstable after installation.	<ul style="list-style-type: none"> Mounting plate not securely fastened. Fixture not properly secured to mounting plate. 	<ul style="list-style-type: none"> Turn off power, re-check and tighten mounting plate screws. Ensure decorative nuts securing the fixture to the mounting plate are tight.

9. WARRANTY AND CUSTOMER SUPPORT

DELIPOP is committed to customer satisfaction.

- **Warranty:** This product comes with a **48-month warranty** for new replacement products.
- **Customer Support:** If you have any questions, concerns, or require assistance, please contact DELIPOP customer support via email. We aim to respond within 12 hours to ensure a smooth and worry-free experience.
- For further assistance, please visit the [DELIPOP Store on Amazon](#).