

[Manuals.plus](#) /

› [LAVA](#) /

› LAVA ME PLAY Smart Guitars Instruction Manual

LAVA LAVA ME

LAVA ME PLAY Smart Guitars Instruction Manual

Model: LAVA ME

Brand: LAVA

INTRODUCTION

The LAVA ME PLAY Smart Guitar is an innovative acoustic-electric instrument designed for musicians of all levels. Featuring the advanced HILAVA 2.0 system, it integrates a suite of smart features directly into the guitar, including effects, drum machines, and learning tools. Its durable, all-weather body ensures consistent performance in various environments, while its ergonomic design prioritizes ease of play.

SETUP GUIDE

Unboxing & Initial Inspection

Carefully remove all components from the packaging. Verify that all items listed in the packing slip are present and undamaged. Inspect the guitar for any visible signs of transit damage.





The LAVA ME PLAY Smart Guitar in Nightfall & Frost White colorway.


Powering On & Initial Setup

To power on your LAVA ME PLAY guitar, locate the power button within the soundhole and press and hold it until the screen illuminates. Follow the on-screen prompts to select your preferred language and connect to a Wi-Fi network. A stable Wi-Fi connection is essential for software updates and accessing online features.

This video demonstrates the initial power-on sequence and basic setup steps for the LAVA ME PLAY guitar, including language selection and Wi-Fi connection.

App Installation & Device Activation

Download the LAVA+ app from your device's app store (App Store or Google Play). Once installed, open the app and follow the instructions to register your device. This typically involves scanning a QR code displayed on your guitar's screen using the LAVA+ app.



The HILAVA 2.0 system interface on the LAVA ME PLAY guitar, showing app icons for various functions.

OPERATING YOUR LAVA ME PLAY

Volume Adjustment


Adjust the guitar's volume using the integrated wheel located inside the soundhole. The on-screen display will show the current volume level as you adjust it.

Navigation & Interface

The LAVA ME PLAY features a highly responsive touchscreen for intuitive navigation. Swipe smoothly between features and applications. The display shows important information such as Wi-Fi connectivity and battery percentage.

Core Features (Apps)

- **Tuner:** Utilize the built-in tuner for precise string tuning. It supports standard EADGBe tuning and various alternate tunings, making it a valuable tool for beginners and experienced players alike.




Create

**100+ Grooves & Backing Tracks.
Inspire. Record and Share.**

The integrated tuner display on the LAVA ME PLAY, guiding users to pluck strings for accurate tuning.

- **Effects:** Experiment with dozens of built-in effects to shape your sound. Choose from various presets or create custom templates by combining multiple effects like reverb, delay, and chorus.



**Dozens of Effects. 100+ Drum Kits.
Extra Playful. Ultra Versatile.**


A selection of customizable effects available within the HILAVA 2.0 system, allowing for diverse soundscapes.

- **Practice/Learn:** Access a comprehensive library of lessons and exercises. Improve your skills with modules for chord transitions, strumming, scale training, ear training, and single note practice.



The learning interface of the LAVA ME PLAY, offering various exercises and skill-building modules.

- **Recorder:** Capture your musical ideas directly on the guitar. The built-in recorder allows you to record your playing and listen back, helping you track your progress and refine your compositions.
- **LiveDrums:** Enhance your performances with over 100 drum kits and adjustable BPM. Create dynamic and expressive music by integrating drum variations into your songs.
- **Create (Loops & Improvs):** Inspire your creativity with over 100 grooves and backing tracks. Record multi-track loops and improvise over backing tracks, then share your creations with the LAVA+ community.



The 'Create' section of the HILAVA 2.0 system, featuring options for loops and improvisations.

Settings

Access the settings menu to customize your guitar's experience. Options include:

- Software Updates: Keep your HILAVA 2.0 system up-to-date with the latest features and improvements.
- Sounds: Adjust master, media, and guitar volumes, as well as equalizer and acoustic boost settings.
- Wallpaper: Personalize your guitar's display.
- WLAN & Bluetooth: Manage your wireless connections.
- Display & Brightness: Adjust screen brightness and auto-lock settings.

MAINTENANCE AND CARE

Cleaning

Wipe down your LAVA ME PLAY guitar regularly with a soft, dry cloth. For deeper cleaning, use a slightly damp cloth and mild soap, ensuring no moisture enters the electronics or soundhole. Avoid abrasive cleaners.

Storage

The LAVA ME PLAY features an all-weather body, making it resilient to various conditions. However, for optimal longevity, store the guitar within the recommended temperature range of -4°F to 122°F (-20°C to 50°C) and humidity between 10% and 90%.



Recommended temperature and humidity ranges for optimal guitar care.

String Replacement

Replace strings as needed to maintain optimal tone and playability. Refer to the specifications for the recommended string gauge (light Phosphor Bronze).

Truss Rod Adjustment

The guitar features an accessible truss rod for adjusting neck relief, ensuring comfortable playability with its 2.3mm action. If you are unfamiliar with truss rod adjustments, it is recommended to seek professional assistance.



Design

Two-tone Colorways. All-weather Body.

Close-up of the LAVA ME PLAY neck, highlighting the 2.3mm action and accessible truss rod for easy playability adjustments.

TROUBLESHOOTING

Common Issues

- **Wi-Fi Connectivity:** If experiencing issues, ensure your Wi-Fi network is stable and within range. Try restarting both the guitar and your router.
- **Screen Responsiveness:** If the touchscreen is unresponsive, try a soft reset by holding the power button. Ensure the screen is clean and free of debris.

Software Updates

Regularly check for and install software updates via Wi-Fi to ensure optimal performance and access to the latest features. Updates are delivered over-the-air directly to your guitar.

SPECIFICATIONS

Feature	Detail
Item Weight	10.03 pounds
Package Dimensions	41 x 16.5 x 11.3 inches
Item model number	LAVA ME
Batteries	1 Lithium Ion batteries required. (included)
Date First Available	August 3, 2023
Back Material	HPL
Body Material	High Performance HPL
Color Name	Nightfall & Frost White
Connector Type	Type-C,Data Transfer & Microphone Support
Fretboard Material	Jatoba Wood
Guitar Pickup Configuration	L3 with DSP processor with FreeBoost 2.0
Scale Length	25.5 inches
String Gauge	light
String Material	Phosphor Bronze
Top Material	HPL
Neck Material Type	Okoume Wood
Number of Strings	6
Guitar Bridge System	Adjustable
Size	36 inch with Ideal Bag
Proficiency Level	All
Battery type	Lithium Ion
Brand	LAVA
Color	Nightfall & Frost White
Top Material Type	HPL
Back Material Type	HPL
Fretboard Material Type	Jatoba Wood
String Material Type	Phosphor Bronze
Hand Orientation	Right

WARRANTY AND SUPPORT

LAVA offers various protection plans for your LAVA ME PLAY Smart Guitar, including 3-Year and 4-Year Protection Plans, as well as a Complete Protect monthly plan. These plans provide extended coverage beyond the standard manufacturer's warranty.

- **3-Year Protection Plan:** Available for \$48.99.
- **4-Year Protection Plan:** Available for \$63.99.
- **Complete Protect:** A monthly plan at \$16.99/month covering eligible past and future purchases.

For detailed warranty information, technical support, or to inquire about protection plans, please visit the official LAVA website or contact their customer service directly.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question