

[Manuals.plus](#) /

› [Genérico](#) /

› User Manual: Compatible 5V Power Adapter for Digital Photo Frames

Genérico 5vv

User Manual: Compatible 5V Power Adapter for Digital Photo Frames

Model: 5vv

[Setup](#) [Operating Instructions](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#)

INTRODUCTION

This manual provides essential information for the safe and effective use of your new 5V power adapter, compatible with various digital photo frames, including the Grandin DPF 711. Please read this manual thoroughly before use and retain it for future reference. This power adapter is designed to provide stable 5V DC power to compatible electronic devices.



Figure 1: The 5V power adapter featuring a black casing, European two-pin plug, and a DC barrel connector at the end of its cable.

IMPORTANT SAFETY INSTRUCTIONS

- Ensure the power adapter's voltage and current ratings match your device's requirements before connecting. This adapter provides 5V DC output.
- Do not expose the adapter to water, moisture, or extreme temperatures.
- Avoid dropping or subjecting the adapter to severe impacts.
- Do not attempt to disassemble or repair the adapter. Refer all servicing to qualified personnel.
- Unplug the adapter from the power outlet when not in use for extended periods.
- Keep out of reach of children.

SETUP

1. **Verify Compatibility:** Before connecting, confirm that your digital photo frame or other device requires a 5V DC input and has a compatible power input port (typically a DC barrel jack). The adapter's output connector is a standard DC barrel type.
2. **Connect to Device:** Carefully insert the DC barrel connector of the power adapter into the power input port of your digital photo frame. Ensure a snug fit.

- 3. **Connect to Power Outlet:** Plug the two-pin European plug of the power adapter into a standard, grounded wall outlet (AC 100-240V, 50/60Hz).
- 4. **Power On Device:** Once connected, power on your digital photo frame or device according to its own operating instructions.

OPERATING INSTRUCTIONS

The 5V power adapter operates automatically once connected to a power source and a compatible device. It provides a stable 5V DC output to power your device. There are no user-adjustable settings on the adapter itself.

- **Normal Operation:** When properly connected, the adapter will supply power to your device. Some adapters may have an indicator light (not guaranteed on this model) to show power is active.
- **Disconnection:** To disconnect, first power off your device if applicable, then unplug the adapter from the wall outlet, and finally disconnect the DC barrel connector from your device.

MAINTENANCE

This power adapter requires minimal maintenance. Following these guidelines will help ensure its longevity:

- **Cleaning:** Disconnect the adapter from all power sources before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or abrasive materials.
- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid tightly coiling the cable to prevent damage.
- **Inspection:** Periodically inspect the cable and connectors for any signs of damage, such as fraying, cuts, or bent pins. If damage is observed, discontinue use immediately.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not power on.	Adapter not properly plugged into wall outlet. Adapter not properly connected to device. Wall outlet is not active. Device power switch is off. Adapter or device is faulty.	Ensure adapter is fully inserted into the wall outlet. Ensure DC connector is fully inserted into the device's power port. Test the wall outlet with another appliance. Check the device's power switch. Try a different compatible adapter or test the device with its original adapter if available.
Adapter feels warm during use.	Normal operation. Overload or faulty device.	A slight warmth is normal. If excessively hot, disconnect immediately. Ensure the device's power requirements do not exceed the adapter's output.

If troubleshooting steps do not resolve the issue, contact customer support or a qualified technician.

SPECIFICATIONS

Model: 5vv

Brand: Genérico

Input: AC 100-240V, 50/60Hz

Output: DC 5V (Current rating not specified, assume standard for digital photo frames, e.g., 1A-2A.*Note: User should verify specific current needs of their device.*)

Connector Type: DC Barrel Plug (standard size for 5V devices)

Compatibility: Designed for devices requiring 5V DC power, such as Grandin DPF 711 digital photo frames.

WARRANTY AND SUPPORT

For information regarding warranty coverage or technical support, please refer to the original purchase documentation or contact the seller directly. As this is a generic compatible product, specific warranty terms may vary.

© 2023 Genérico. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question