

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [BoxWave](#) /

› [BoxWave AccuPoint Active Stylus Pen for Newland SP930 - Instruction Manual](#)

BoxWave AccuPoint Active Stylus

BoxWave AccuPoint Active Stylus Pen Instruction Manual

Model: AccuPoint Active Stylus

INTRODUCTION

This manual provides instructions for the BoxWave AccuPoint Active Stylus Pen, designed for use with the Newland SP930 and other compatible touchscreen devices. This stylus offers precise input without the need for Bluetooth pairing.

PACKAGE CONTENTS

- AccuPoint Active Stylus Pen
- MicroUSB Charging Cable

SETUP

Charging the Stylus

Before initial use, fully charge the stylus. Connect the included MicroUSB cable to the charging port on the stylus and to any standard USB power source (e.g., computer, wall adapter). The indicator light will show charging status.



Image: The stylus connected to a MicroUSB cable for charging. The indicator light changes color to show charging status: red for charging, green for full charge.

- **Charging Indicator:** Red light indicates charging.
- **Fully Charged Indicator:** Green light indicates a full charge.
- A full charge provides approximately 12 hours of use.

Powering On/Off

Press the button on the stylus barrel to turn it on. The indicator light will illuminate blue. Press the button again to turn it off.



Image: The BoxWave AccuPoint Active Stylus with its power indicator light glowing blue, signifying it is active.

OPERATING INSTRUCTIONS

Using the Stylus

The AccuPoint Active Stylus does not require Bluetooth pairing. Simply turn it on and begin using it on your touchscreen device. The stylus emits electronic pulses to interact with the screen, allowing for natural writing and drawing positions.



Tap, Swipe, or Write Naturally With the AccuPoint Active Stylus

No pairing required! The AccuPoint Active Stylus emits quick electronic pulses to interact with your device's screen.

(Please note: the AccuPoint Active Stylus does not support palm rejection)

BoxWave AccuPoint Active Stylus

Image: The stylus being used on a tablet, demonstrating its functionality for tapping, swiping, and writing.

- **Ultra Fine Tip:** The 2mm tip allows for accurate tapping, swiping, and drawing.
- **No Pairing:** No Bluetooth connection is needed.
- **Compatibility:** Works with most capacitive touchscreen devices, including the Newland SP930.

Important Notes

- The AccuPoint Stylus does **not** support Palm Rejection.
- The AccuPoint Stylus does **not** support Pressure Sensitivity.

MAINTENANCE

Cleaning

To clean the stylus, gently wipe the barrel with a soft, dry cloth. For the tip, use a slightly damp cloth if necessary, ensuring no moisture enters the stylus body.

Storage

Store the stylus in a cool, dry place away from direct sunlight and extreme temperatures. Ensure the stylus is turned off when not in use to conserve battery life.

Battery Care

To prolong battery life, avoid fully discharging the stylus frequently. Recharge it when the indicator light suggests low battery.

TROUBLESHOOTING

Stylus Not Responding

- Ensure the stylus is turned on (blue indicator light).
- Check battery level and charge if necessary.
- Ensure the device screen is clean and free of debris.
- Test the stylus on another compatible device to rule out device-specific issues.

Charging Issues

- Verify the MicroUSB cable is securely connected to both the stylus and the power source.

- Try a different USB port or power adapter.
- Ensure the charging port on the stylus is clean and free of obstructions.

SPECIFICATIONS

Item Weight	1.3 ounces
Battery Type	Product Specific (included)
Battery Life	Up to 12 hours of use
Color	Metallic Silver
Tip Size	2mm (Ultra Fine Tip)
Material	Brushed Aluminum Barrel

WARRANTY AND SUPPORT

Warranty Information

BoxWave products typically come with a manufacturer's warranty. Please refer to the product packaging or the official BoxWave website for specific warranty terms and conditions. Extended protection plans may also be available for purchase.

Customer Support

For technical assistance, troubleshooting, or product inquiries, please contact BoxWave Corporation customer support. Limited third-party tech support for your device may be available (up to 3 inquiries via messaging).

Note: BoxWave is not affiliated with or endorsed by Newland.

