

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [AGPTEK](#) /

› [AGPTEK W1S 16GB MP3 Player with Bluetooth and WiFi User Manual](#)

AGPTEK W1S

AGPTEK W1S 16GB MP3 Player User Manual

Model: W1S

INTRODUCTION

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your AGPTEK W1S 16GB MP3 Player. Please read this manual thoroughly before using the device to ensure proper functionality and to maximize your user experience.

SAFETY INFORMATION

- Do not expose the device to extreme temperatures, direct sunlight, or high humidity.
- Avoid dropping or subjecting the device to strong impacts.
- Do not attempt to disassemble or repair the device yourself. Contact customer support for assistance.
- Use only the provided charging cable and a compatible power adapter.
- Keep the device away from water and other liquids.

DEVICE OVERVIEW

The AGPTEK W1S features a 3.5-inch high-resolution touchscreen and an intuitive interface for easy navigation.

Built-in Multiple Mainstream Music APPs



Note: WiFi is only used for browsing websites, listening to music and watching videos online, not suitable for downloading and installing other APPs.

Image: Front and back view of the AGPTEK W1S MP3 Player, showcasing its sleek design and physical buttons.

Key Features:

- **3.5-inch HD Touchscreen:** Provides a clear display and responsive touch control.
- **Android 8.1 Operating System:** Ensures faster and smoother operation.
- **2GB RAM, 16GB ROM:** Ample memory for system performance and internal storage.
- **Expandable Storage:** Supports microSD cards up to 128GB.
- **Bluetooth 4.0:** For wireless audio connections.
- **Wi-Fi Connectivity:** For online music streaming and browsing.
- **Pre-installed Apps:** Includes Spotify, Deezer, Amazon Music, Audible, YouTube, Pandora, TikTok, Google Chrome, and more.
- **Audio Formats:** Supports MP3, WAV, WMA, OGG, APE, FLAC, ACC-LC, etc.

SETUP

1. Charging the Device

Before first use, fully charge your AGPTEK W1S MP3 player. Connect the device to a power source using the provided USB cable. A full charge typically takes 2 to 2.5 hours.



Gives You Long Time Music Enjoyment

2-2.5H
Charging Time

	Speaker	Headphone
Local Music Playback	13H	15H
Online Music Playback	8.5 H	15H
Local Videos Playback	4.5 H	5H

Note: Due to playback conditions and file size, usage time will deviate from ideal.

Image: The AGPTEK W1S MP3 Player connected to a laptop via USB-C for charging, displaying a 90% battery level and indicating a 2-2.5 hour charging time.

2. Power On/Off

- **To Power On:** Press and hold the power button until the screen lights up.
- **To Power Off:** Press and hold the power button, then select "Power Off" from the options on the screen.

3. Initial Setup

Upon first power-on, follow the on-screen prompts to select your language, connect to a Wi-Fi network, and set up basic preferences.

4. Installing a MicroSD Card (Optional)

The device supports microSD cards up to 128GB for expanded storage. Locate the microSD card slot on the side of the player. Gently insert the card until it clicks into place. To remove, push the card in slightly until it springs out.

5. Transferring Music and Files

- Connect the MP3 player to your computer using the USB cable.
- The device will appear as a removable storage drive.
- Drag and drop your music, video, or e-book files into the appropriate folders on the device or inserted microSD card.
- Safely eject the device from your computer before disconnecting the cable.

OPERATING INSTRUCTIONS

1. Basic Navigation

The AGPTEK W1S features a responsive touchscreen. Swipe left/right to navigate between screens, tap icons to open applications, and use the physical buttons for volume control and power.

2. Music Playback

Access your music library through the pre-installed music player app. The device supports various audio formats including MP3, WAV, WMA, OGG, APE, FLAC, and ACC-LC.

BLUETOOTH 4.0

Free Your Hands and Enjoy the Freedom of Music



Not supported to connect to the mobile phone to listen to music via Bluetooth.

Image: The AGPTEK W1S MP3 Player displaying a music playback screen with album art and controls, held by a person dancing in a group, illustrating high-fidelity lossless sound quality.

3. Bluetooth Connectivity

To connect to Bluetooth headphones or speakers:

1. Go to **Settings > Bluetooth**.
2. Turn Bluetooth **On**.
3. Ensure your Bluetooth device is in pairing mode.
4. Select your device from the list of available devices to pair.

Gives You Long Time Music Enjoyment


2-2.5H
Charging Time



	Speaker	Headphone
Local Music Playback	13H	15H
Online Music Playback	8.5 H	15H
Local Videos Playback	4.5 H	5H

Note: Due to playback conditions and file size, usage time will deviate from ideal.

Image: The AGPTEK W1S MP3 Player shown alongside a white Bluetooth speaker, black over-ear headphones, and white wireless earbuds, demonstrating its Bluetooth 4.0 connectivity for wireless audio enjoyment.

4. Wi-Fi and Pre-installed Applications

Connect to a Wi-Fi network via **Settings > Wi-Fi** to access online streaming services and browse the internet. The device comes with pre-installed apps like Spotify, Deezer, Amazon Music, Audible, YouTube, Pandora, TikTok, and Google Chrome.

3.5" HD Screen

Play high-definition video without lag



Image: The AGPTEK W1S MP3 Player screen displaying icons for various pre-installed mainstream music and media applications such as Spotify, Pandora, Amazon Music, Deezer, Audible, YouTube, FM Radio, Sound Recorder, Gallery, and Google Chrome.

Note: Wi-Fi is primarily for browsing websites, listening to music, and watching videos online. It is not suitable for downloading and installing other applications beyond those pre-installed.

Intelligent Octa-Core Processor



Image: The AGPTEK W1S MP3 Player screen showing a music streaming interface with album art and playback controls, demonstrating the ability to enjoy music online and download songs using Wi-Fi.

5. Audible and E-books

The pre-installed Audible app allows you to enjoy audiobooks. You can also transfer and read e-books on the device's 3.5-inch HD screen.

Enjoy Music Online and Download Songs with WiFi

Supports multiple music formats including MP3, FLAC, AAC, WAV, WMA, APE and more




Image: The AGPTEK W1S MP3 Player's 3.5-inch HD screen displaying a high-definition video scene, emphasizing its capability to play video without lag.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the device. Avoid liquid cleaners.
- **Software Updates:** Periodically check for software updates in the device settings to ensure optimal performance and access to new features.
- **Storage Management:** Regularly manage your files to free up storage space. Delete unnecessary files or transfer them to a computer.

TROUBLESHOOTING

Problem	Solution
---------	----------

Problem	Solution
Device does not power on.	Ensure the device is fully charged. If the battery is depleted, connect it to a charger for at least 15 minutes before attempting to power on again.
Cannot connect to Wi-Fi.	Check if Wi-Fi is enabled in settings. Ensure you are within range of a known Wi-Fi network and have entered the correct password. Try restarting the device and your Wi-Fi router.
Bluetooth device not pairing.	Ensure Bluetooth is enabled on both the player and the accessory. Place devices close to each other and ensure the accessory is in pairing mode. Try restarting both devices.
MicroSD card not recognized.	Ensure the card is inserted correctly. Try reinserting it. Format the card on a computer if it's new or if issues persist (this will erase all data on the card). Ensure the card is not larger than 128GB.
Device is slow or unresponsive.	Close unused applications. Clear cache if possible. Restart the device. If issues persist, consider a factory reset (backup your data first).

SPECIFICATIONS

Feature	Detail
Brand	AGPTEK
Model Name	W1S
Model Number	APMPW1SB-CA
Color	Black
Screen Size	3.5 Inches
Operating System	Android 8.1
RAM	2GB
Internal Storage (ROM)	16GB
Expandable Storage	Supports MicroSD up to 128GB
Connectivity	Bluetooth 4.0, Wi-Fi
Battery Type	Lithium-polymer
Compatible Audio Formats	MP3, WAV, WMA, OGG, APE, FLAC, ACC-LC
Compatible Devices	Headphones

High-fidelity Lossless Sound Quality



Image: An exploded diagram illustrating the internal components of the AGPTEK W1S, highlighting the intelligent octa-core processor, 2GB RAM, and 16GB internal memory for fast and smooth performance.

WARRANTY AND SUPPORT

AGPTEK is committed to providing reliable products and excellent customer service.

- **Warranty:** 2-Year Warranty
- **Technical Assistance:** Lifetime Technical Support
- **Online Service:** 24/7 Online Support

For further assistance, please refer to the official AGPTEK website or contact their customer support directly.



Image: An infographic detailing AGPTEK's customer service offerings, including a 2-year warranty, lifetime technical assistance, and 24/7 online service.