

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [GreenPan](#) /

> [GreenPan Click Chef Cookware Set \(CC007784-004\) Instruction Manual](#)

GreenPan CC007784-004

GreenPan Click Chef Cookware Set Instruction Manual

Model: CC007784-004

1. PRODUCT OVERVIEW

Thank you for choosing the GreenPan Click Chef Cookware Set. This set features a ceramic non-stick coating reinforced with diamond particles, ensuring durability and superior cooking performance. The innovative removable handle design allows for versatile cooking, easy storage, and convenient serving. This cookware is free from PFOA, PFAS, lead, and cadmium.




Image 1: The GreenPan Click Chef Cookware Set, highlighting its PFAS-free non-stick surface, removable handle, and compatibility with various heat sources including gas, radiant, halogen, IH (200V), and oven.

2. SETUP AND FIRST USE

2.1 Unpacking and Initial Cleaning

1. Remove all packaging materials and labels from the cookware.
2. Wash the pans and handle thoroughly with warm soapy water using a soft sponge or cloth. Rinse and dry completely.

2.2 Attaching and Detaching the Removable Handle

The Click Chef handle features a 2-level locking system for secure attachment and easy removal.

- **To Attach:** Align the handle with the pan's rim. Press the 'PUSH' button on the handle and slide it onto the pan until it clicks securely into place. Ensure the handle is firmly attached before use.
- **To Detach:** Press the 'PUSH' button and slide the handle away from the pan.

Important: When attaching the handle to the egg pan, install it around the middle of the round large curved surface. Incorrect attachment may prevent removal.



Image 2: Detailed view of the 2-stage locking system on the removable handle, demonstrating secure attachment and easy release with one hand.

2.3 First Use Recommendations

- Before first use, lightly coat the non-stick surface with a small amount of cooking oil. Wipe off any excess.
- Always preheat the pan over medium heat for 30 seconds to 1 minute before adding food or oil.

3. OPERATING INSTRUCTIONS

3.1 Heat Source Compatibility

This cookware set is compatible with a variety of heat sources:

- Gas Stoves
- Induction Cooktops (IH 200V compatible)
- Radiant Heaters
- Halogen Heaters
- Ovens (up to 315°C / 600°F, with handle removed)




Image 3: Demonstrates the cookware's versatility across different heat sources, including induction and gas, and its oven-safe capability when the handle is removed.

3.2 Recommended Heat Settings

Always use low to medium heat for cooking. High heat can damage the non-stick coating over time and is generally not necessary due to the excellent heat conductivity of the pans.

- **Preheating:** Medium heat for 30 seconds to 1 minute.
- **Cooking:** Use medium heat for most tasks like frying and sautéing. Reduce to low heat for simmering.
- **For IH (Induction Heating) cooktops:** Always use medium heat or lower for preheating and cooking.



Image 4: Visual guide for recommended heat levels (medium, low, very low) and proper preheating technique to ensure optimal cooking and longevity of the non-stick coating.

3.3 Using the Cookware

- Use wooden, silicone, or heat-resistant plastic utensils to protect the non-stick surface. Avoid metal utensils.

- The functional trimmed edge design makes pouring liquids easy and drip-free.
- With the handle removed, the pans can be used directly as serving dishes or for temporary storage in the refrigerator.




Image 5: Illustrates the easy-pour rim design, the effective non-stick surface, and the convenience of using the pan as a serving dish or for temporary food storage.

4. MAINTENANCE AND CARE

4.1 Cleaning Instructions

The ceramic non-stick coating makes cleaning effortless.

- Allow the pan to cool completely before washing to prevent warping and thermal shock to the non-stick coating.
- Wash with warm soapy water and a soft sponge or cloth. For stubborn food residues, soak the pan in warm soapy water for a few minutes before cleaning.
- The cookware is dishwasher safe, but hand washing is recommended to prolong the life of the non-stick coating.
- The handle mounting hardware does not have rivets, ensuring a clean interior and easy cleaning without food residue buildup.



Image 6: Shows the ease of cleaning the non-stick surface under running water and the space-saving benefit of stacking the pans for storage.

4.2 Storage

The removable handle design allows for efficient, space-saving storage.

- Stack the pans together after removing the handles.
- Use the provided felt protective sheets between pans to prevent scratches and damage to the non-stick surface.

5. TROUBLESHOOTING

5.1 Food Sticking to the Pan

- **Issue:** Food begins to stick after some use.
- **Solution:** Ensure you are always preheating the pan over medium heat for 30 seconds to 1 minute before adding food. Use a small amount of oil or butter. Avoid using high heat, which can degrade the non-stick coating over time. Ensure the pan is thoroughly cleaned after each use, as residue buildup can reduce non-stick performance.

5.2 Handle Not Attaching/Detaching Properly

- **Issue:** The handle does not click securely or is difficult to remove.
- **Solution:** Ensure the handle is correctly aligned with the pan's rim. Press the 'PUSH' button firmly when attaching or detaching. For the egg pan, verify the handle is installed around the middle of the round large curved surface as specified in Section 2.2.

6. SPECIFICATIONS

Feature	Detail
Brand	GreenPan
Model Name	Green Pan Click Chef Set of 4
Model Number	CC007784-004
Color	Oxford Blue
Material	Body: Aluminum alloy; Removable handle: Phenolic resin (heat-resistant up to 180°C / 356°F), Stainless steel, Silicone rubber; Protective Sheet: Felt
Capacity	5 Liters (total for set, specific pan capacities vary)
Product Dimensions	7.87 x 7.87 x 1.77 inches (individual pan dimensions may vary)
Item Weight	1.74 Kilograms / 3.83 pounds (total for set)
Special Features	Induction Stove Compatible, Non-Stick Ceramic Coating, Oven Safe (without handle)
Compatible Devices	Gas, Smooth Surface Induction
Oven Safe	Yes (up to 315°C / 600°F, handle removed)
Dishwasher Safe	Yes (hand washing recommended)
Coating	Ceramic non-stick reinforced with diamond particles, PFAS-free, PFOA-free, lead-free, cadmium-free

7. WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the GreenPan official website or contact your retailer. Keep your purchase receipt for any warranty claims.

