Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Timex /
- > Timex Men's Expedition North Sierra 41mm Watch Instruction Manual

Timex TW2W21900JR

Timex Men's Expedition North Sierra 41mm Watch

Model: TW2W21900JR

Introduction Setup Operation Maintenance Troubleshooting Specifications Warranty & Support

1. Introduction

This instruction manual provides essential information for the proper use and care of your Timex Men's Expedition North Sierra 41mm Watch (Model: TW2W21900JR). Please read this manual thoroughly to ensure optimal performance and longevity of your timepiece.




Image 1.1: Front view of the Timex Expedition North Sierra 41mm Watch, featuring a black dial, luminous hands and markers, and a black strap.

2.1 Setting the Time and Date

- 1. **Pull out the crown:** Locate the crown on the right side of the watch case. Gently pull it out to the second click position.
- 2. **Set the time:** Rotate the crown clockwise or counter-clockwise to move the hour and minute hands to the desired time. Ensure the AM/PM is correctly set if your watch has a date function that changes at midnight.
- 3. **Set the date:** If your watch has a date display, push the crown in one click (to the first click position). Rotate the crown to adjust the date. Avoid setting the date between 9 PM and 3 AM, as this can damage the movement.
- 4. **Push in the crown:** Once the time and date are set, push the crown back into its original position against the watch case. This will start the watch movement.



Image 2.1: Side view of the watch, highlighting the crown used for setting time and date.

2.2 Solar Charging

This watch features a solar-powered movement. For initial charge or if the watch has stopped, expose the dial to a strong light source (natural sunlight is ideal) for several hours. Avoid extreme heat. Regular

3. OPERATING INSTRUCTIONS

3.1 Timekeeping

Your Timex Expedition North Sierra watch is designed for accurate timekeeping. The hour, minute, and second hands continuously display the current time. The date window, if present, updates once every 24 hours.

3.2 Water Resistance

This watch is water resistant up to 200 meters (660 feet). This rating makes it suitable for swimming, showering, and recreational diving. Important: Do not operate the crown or pushers while the watch is wet or submerged, as this can compromise the water resistance. Ensure the crown is fully pushed in before exposing the watch to water.



Image 3.1: Detail of the watch case back, indicating "WR 200M" for water resistance.

3.3 Rotating Bezel

The watch features a unidirectional rotating bezel. This bezel can be used to measure elapsed time, typically for diving or other timed activities.

1. **To measure elapsed time:** Rotate the bezel so that the zero marker aligns with the minute hand. As time passes, the minute hand will point to the elapsed time on the bezel.

4. CARE AND MAINTENANCE

4.1 Cleaning Your Watch

- Case and Crystal: Wipe the watch case and crystal with a soft, damp cloth. For stubborn dirt, a mild soap solution can be used, followed by rinsing with clean water and thorough drying.
- **Strap:** For leather straps, avoid prolonged exposure to water and direct sunlight. Clean with a dry, soft cloth. For synthetic or metal straps, a mild soap solution and soft brush can be used, followed by rinsing and drying.

4.2 General Care

- Avoid exposing your watch to extreme temperatures, strong magnetic fields, or harsh chemicals.
- Ensure it receives adequate light exposure to maintain its solar charge. Store it in a well-lit area when not in use.
- Have your watch serviced by an authorized Timex service center if you notice any issues or for routine maintenance.





Image 4.1: Rear view of the watch, showing the black leather strap and stainless steel case back.

5. TROUBLESHOOTING

· Watch not running:

- Ensure the crown is fully pushed in.
- Expose the watch to strong light for several hours to charge its solar movement.

• Time is inaccurate:

- Reset the time as described in Section 2.1.
- Avoid strong magnetic fields which can affect accuracy.
- $\circ~$ If the issue persists, professional servicing may be required.

· Date not changing:

- $\circ\,$ Ensure the time is set correctly for AM/PM. The date changes around midnight.
- Manually advance the date using the crown (Section 2.1).

6. PRODUCT SPECIFICATIONS

Feature	Detail
Model Number	TW2W21900JR
Case Diameter	41mm
Strap Material	Leather (Black)

Feature	Detail
Strap Length	8 inches
Dial Color	Black
Lens Material	Mineral Glass
Water Resistance	200 meters (660 feet)
Movement Type	Quartz (Solar-powered)
Case Material	Stainless Steel

7. WARRANTY AND SUPPORT

Your Timex watch is covered by a limited warranty against manufacturing defects. For detailed warranty information, including terms, conditions, and duration, please refer to the warranty card included with your purchase or visit the official Timex website.

For customer support, service, or to locate an authorized service center, please visit the Timex official website or contact their customer service department directly.

© 2023 Timex. All rights reserved.

Related Documents - TW2W21900JR



<u>Timex Expedition North Slack Tide User Guide - Setup and Operation</u>

Official user guide for the Timex Expedition North Slack Tide watch, covering setup, time and date setting, tide cycle hand adjustment, water resistance, safety precautions, and warranty information.



TIMEX W24 Expedition North Tide-Temp-Compass Watch User Guide

Comprehensive guide to the TIMEX W24 Expedition North watch, detailing its Tide-Temp-Compass features, water resistancy, usage, and care instructions.



Timex Expedition North Slack Tide User Guide and Safety Information

Comprehensive user guide for the Timex Expedition North Slack Tide watch, covering setup, features, water resistance, safety precautions, warranty, and battery information.

