Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

onerbl AC DC Adapter

onerbl AC DC Adapter Instruction Manual

For ONN ONA17AA015 CD Mini Stereo System

Model: AC DC Adapter

1. Introduction

This manual provides essential instructions for the safe and effective use of your onerbl AC DC Adapter. This adapter is specifically designed to provide power to the ONN ONA17AA015 CD Mini Stereo System. Please read this manual thoroughly before use and retain it for future reference.



Image 1.1: The onerbl AC DC Adapter, showing the main unit with a two-prong plug and the DC output cable with its connector.

2. Safety Information

To ensure safe operation and prevent damage, observe the following precautions:

- **Compatibility:** Use this adapter only with devices that match its voltage and current specifications, specifically the ONN ONA17AA015 CD Mini Stereo System. Using it with incompatible devices may cause damage.
- **Indoor Use Only:** This adapter is intended for indoor use in dry locations. Do not expose it to water, moisture, or high humidity.
- **Ventilation:** Ensure adequate ventilation around the adapter. Do not cover it or place it in an enclosed space that could restrict airflow.
- **Cable Care:** Do not bend, twist, or pull the power cord excessively. Avoid placing heavy objects on the cord.
- **Disconnection:** Always grasp the plug, not the cord, when disconnecting from the power outlet.
- **Damage:** If the adapter or cord appears damaged, discontinue use immediately and seek professional assistance.
- **Children:** Keep the adapter out of reach of children.



Image 2.1: Illustration of the adapter's built-in safety features, including short-circuit, over-voltage, and over-current protection.

3. Setup and Connection

Follow these steps to connect the onerbl AC DC Adapter to your ONN ONA17AA015 CD Mini Stereo System:

1. **Verify Compatibility:** Ensure your device is the ONN ONA17AA015 CD Mini Stereo System or another device requiring the exact same power specifications.
2. **Connect to Device:** Insert the DC output connector of the adapter firmly into the power input port of your ONN ONA17AA015 CD Mini Stereo System.
3. **Connect to Power Outlet:** Plug the AC input prongs of the adapter into a standard 100-240V AC wall outlet.
4. **Power On:** Once connected, your stereo system should be ready to power on.



Image 3.1: The AC DC Adapter connected to a power strip, illustrating a typical setup for powering a device.

4. Operation

The onerbl AC DC Adapter operates automatically once connected. It converts the alternating current (AC) from your wall outlet into direct current (DC) required by your ONN ONA17AA015 CD Mini Stereo System. No user intervention is required for its basic function.

- Ensure the adapter is securely plugged into both the wall outlet and the device.
- The adapter is designed for continuous operation within its specified limits.

5. Maintenance and Care

Proper care will extend the life of your adapter:

- **Cleaning:** Disconnect the adapter from the power outlet before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or solvents.

- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid tightly coiling the cable.
- **Inspection:** Periodically inspect the adapter and cable for any signs of wear, cuts, or damage.



Image 5.1: Illustration highlighting the durable design of the cable, featuring copper wire and a PVC jacket for longevity.

6. Troubleshooting

If you encounter issues with your adapter, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Device not powering on.	Adapter not properly connected. No power from outlet. Faulty adapter or device.	Ensure both ends of the adapter are securely plugged in. Test the wall outlet with another device. Verify the adapter's specifications match the device's requirements. If possible, test with another compatible adapter or device to isolate the issue.
Adapter feels unusually hot.	Overload. Poor ventilation. Internal fault.	Disconnect the adapter immediately. Ensure the device is compatible and not drawing excessive power. Provide adequate ventilation around the adapter. If overheating persists, discontinue use.

Problem	Possible Cause	Solution
Visible damage to adapter or cable.	Physical stress or accident.	Discontinue use immediately to prevent electrical hazards. Replace the adapter with a new, compatible unit.

7. Specifications

Key technical details of the onerbl AC DC Adapter:

- **Input:** AC 100-240V, 50/60Hz (Worldwide AC Input)
- **Output:** Specific voltage and current designed to match the requirements of the ONN ONA17AA015 CD Mini Stereo System.
- **Compatibility:** Specifically designed for ONN ONA17AA015 CD Mini Stereo System.
- **Safety Features:** Over Voltage Protection, Over Heat Protection, Short-circuit Protection, Over-current Protection.
- **Cable Length:** Approximately 76 inches (6.3 feet).



Image 7.1: Physical dimensions of the adapter unit and its cable length, showing 2.6 inches length, 1.6 inches width, 1.2 inches height, and a 76-inch cable.



Image 7.2: Front and side views of the adapter, displaying input specifications (100-240VAC, 0.3A, 50/60Hz) and 'Made in China' label.

8. Warranty and Support

For warranty information or technical support, please refer to the retailer or manufacturer's official website. Keep your purchase receipt as proof of purchase.

© 2023 onerbl. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CDPT9CB2

More documents and user manuals: **https://manuals.plus/**