



Manuals.plus /

› KEEPEEZ /

› KEEPEEZ Electric Composter FWD-501 User Manual

KEEPEEZ FWD-501

KEEPEEZ Electric Composter FWD-501 User Manual

Model: FWD-501

INTRODUCTION

Thank you for choosing the KEEPEEZ Electric Composter. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read it thoroughly before first use and keep it for future reference.

SAFETY INSTRUCTIONS

- Always unplug the composter before cleaning or performing maintenance.
- Do not immerse the main unit in water or other liquids.
- Ensure the composter is placed on a stable, level surface.
- Keep out of reach of children and pets.
- Do not operate the composter if the power cord or plug is damaged.
- Avoid placing hands or objects into the composter bucket during operation.
- Use only KEEPEEZ approved replacement parts and accessories.

PRODUCT OVERVIEW

The KEEPEEZ Electric Composter is designed to convert food waste into nutrient-rich soil conditioner efficiently. It features a 4-liter capacity bucket, an activated carbon filter system for odor control, and a one-button operation for ease of use.



Image: The KEEPEEZ Electric Composter, a compact countertop appliance.

SETUP

1. **Unpacking:** Carefully remove all packaging materials and inspect the composter for any damage. Retain packaging for future transport if needed.
2. **Placement:** Place the composter on a flat, stable, and heat-resistant surface in your kitchen or utility area. Ensure adequate ventilation around the unit.
3. **Filter Installation:** The composter comes with an upgraded activated charcoal system, including one removable charcoal box and two built-in charcoal boxes. Ensure all filters are correctly seated in their designated compartments to effectively absorb odors. Refer to the diagram below for filter locations.

SAVE ENERGY ECO-CONSCIOUS



\$20 Per Year

Power Usage: 0.5KWh for full, 4L Disposal



Activated Charcoa

Keeps Odor Away



Methane Emissions Avoided

Avoids 20lbs of CH₄ emissions per 100 cycles

Image: Internal view of the composter highlighting the activated charcoal filter system.

4. **Power Connection:** Plug the power cord into a grounded electrical outlet.

OPERATING INSTRUCTIONS

1. **Adding Food Waste:** Open the lid and place food scraps into the 4-liter capacity bucket. The composter can process a variety of organic materials.

TURNING FOOD & WASTE INTO COMPOST

Up to 80% of your waste can go into composter




Image: Diagram illustrating acceptable food waste types for composting, including animal products, coffee grounds, yard waste, fruits, vegetables, degradable paper, and bread/grain products.

- Starting the Cycle:** Close the lid securely. Press the one-button operation to start the composting cycle. The unit will automatically begin the process of high-temperature drying, grinding, and cooling.
- Composting Process:** A typical composting cycle takes approximately 4-8 hours. During this time, the composter will reduce the volume of food waste by up to 90%, transforming it into a natural fertilizer.

COMPOST IN 8 HOURS, KEEPS ODOR AWAY



XMAS

TRADITIONAL COMPOSTER



Image: The KEEPEEZ composter operating in a kitchen, demonstrating its odor-free operation and 4-8 hour cycle time.

4. **Cycle Completion:** Once the cycle is complete, the unit will indicate that the process is finished. The resulting material is a dry, nutrient-rich soil conditioner ready for use in gardens or potted plants.



Image: Composted material from the KEEPEEZ composter being used to enrich soil for plants.

MAINTENANCE

- **Cleaning the Bucket:** The composter bucket is made of cast aluminum and is dishwasher safe. For manual cleaning, wash with warm, soapy water and a non-abrasive sponge. Ensure the bucket is completely dry before placing it back into the unit.
- **Self-Cleaning Function:** The unit features a self-cleaning function. Refer to the control panel for instructions on activating this mode.

BE SPARED WORRY OF WASTE AND CLEAN



KEEPEEZ

KEEPEEZ

4L Capacity



Cuts down the volume of food waste by up to 90%

KEEPEEZ

90% Less Waste

Before

After



Dishwasher-Safe

Easy-to-Clean
Dishwasher-Safe Accessories



Auto Clean

Image: Visual representation of the composter's dishwasher-safe accessories and auto-clean feature.

- **Filter Replacement:** The activated carbon filters should be replaced periodically to maintain optimal odor control. The frequency depends on usage. Replacement filters can be purchased from authorized KEEPEEZ retailers or the official website.
- **Exterior Cleaning:** Wipe the exterior of the composter with a damp cloth. Do not use abrasive cleaners or solvents.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Unit does not power on.	Not plugged in; power outage; faulty outlet.	Check power cord connection; verify power to the outlet; try a different outlet.
Composting cycle not completing or results are wet/soupy.	Overfilling the bucket; incorrect food waste type; lid not sealed properly.	Do not exceed the 4L capacity; ensure only recommended food waste is added; check lid for proper closure.
Unpleasant odors during operation.	Carbon filters are saturated or incorrectly installed.	Check filter installation; replace carbon filters if they are old or saturated.
Unit is leaking.	Bucket not seated correctly; seal damage; overfilling.	Ensure the bucket is properly inserted; inspect seals for damage; avoid overfilling.

SPECIFICATIONS

Brand: KEEPEEZ

Model Number: FWD-501

Material: Stainless Steel

Color: Silver

Capacity: 1 Gallon (4 Liters)

Product Dimensions: 14.5"L x 13.6"W x 19.9"H

Item Weight: 19.1 Pounds

Manufacturer: KEEPEEZ



Image: The KEEPEEZ Electric Composter with key dimensions (10.3" width, 15.5" height) highlighted.

WARRANTY AND SUPPORT

The KEEPEEZ Electric Composter FWD-501 comes with a **3-year warranty**, which includes a 1-year basic warranty and 2 additional years of extended coverage. This warranty covers defects in materials and workmanship under normal use. For technical support, warranty claims, or inquiries about replacement parts (such as carbon filters), please contact KEEPEEZ customer service. Our team is available to provide professional technical support.

Please visit the official KEEPEEZ website or refer to your purchase documentation for the most current contact information.