

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

> [Bewinner](#) /

> [Bewinner A4 Thermal Printer Bluetooth - 200dpi Inkless Portable Wireless Printer User Manual](#)

## Bewinner Bewinner6s1nywm8k0

# Bewinner A4 Thermal Printer User Manual

Model: Bewinner6s1nywm8k0

## 1. INTRODUCTION

---

This manual provides detailed instructions for the operation, maintenance, and troubleshooting of your Bewinner A4 Thermal Printer. Please read this manual thoroughly before using the device to ensure proper function and longevity.



Image: Bewinner A4 Thermal Printer and accessories.

## 2. PRODUCT OVERVIEW

---

### Key Features

- **Inkless Printing:** Utilizes thermal technology, eliminating the need for ink cartridges or toner.
- **Portable Design:** Compact and lightweight for easy transport and use in various environments.
- **High Resolution:** 200dpi print resolution for clear and readable documents.
- **Wide Compatibility:** Supports Bluetooth connection with iOS and Android smartphones.
- **Rechargeable Battery:** Built-in 1000mAh battery provides continuous printing for approximately 90 sheets of A4 thermal paper on a full charge.
- **A4 Paper Support:** Accommodates thermal paper with widths of 210mm or 218mm.

### Components and Structure

The printer includes the main unit, a power data cable, and a specification sheet. Refer to the diagram below for key structural components:



Image: Product structure and packing list.

- **Feed Hole:** Where thermal paper is inserted.
- **Power Switch:** Controls device power.
- **Charging Port:** Type-C interface for charging.
- **Exit Hole:** Where printed paper emerges.
- **Open Button:** Used to open the paper cover.

## 3. SETUP

---

### 3.1 Unpacking

Carefully remove all components from the packaging. Verify that the printer host, power data cable, and specification sheet are present.

### 3.2 Charging the Printer

Before first use, fully charge the printer. Connect the provided Type-C power data cable to the printer's charging port and a 5V/2A mobile phone power adapter. The red indicator light will illuminate during charging. A full charge takes approximately 1.5 hours.

### 3.3 Loading Thermal Paper

1. Press the cover release button to open the paper compartment flap.
2. Insert the A4 thermal paper into the feed hole, ensuring it is aligned correctly. The printer supports paper widths of 210mm or 218mm.
3. Close the paper compartment flap securely.

# WRONG NOTE ARRANGEMENT BID FARE WELL TO MESSY KNOWLEDGE POINTS

Printed at 10mm/s



Image: Printer in operation, demonstrating paper feed.

## 3.4 Application Installation

To operate the printer wirelessly, install the 'iPrint' application on your smartphone:

- **For Apple iOS users:** Search for "iPrint" in the App Store and download the application.
- **For Android users:** Search for "iPrint" in the Google Play Store and download the application.

## 4. OPERATING INSTRUCTIONS

### 4.1 Power On and Off

- **Power On:** Long press the power button for approximately 3 seconds until the indicator light illuminates.
- **Power Off:** Long press the power button for approximately 3 seconds until the indicator light turns off.

### 4.2 Bluetooth Connection

Ensure your printer is powered on and your smartphone's Bluetooth is enabled.

1. Open the 'iPrint' application on your smartphone.

2. Within the application, navigate to the "Select Device" option.
3. Go to the "My Device" page and select the Bluetooth name corresponding to your printer (e.g., GT08).
4. If the printer's Bluetooth name does not appear, tap the "Refresh" button to scan again.

### 4.3 Indicator Light Status

Indicator Status	Meaning
Steady On	Bluetooth Connected
Flicker	Waiting for Connection
Red Light	Charging

## 5. MAINTENANCE

---

### 5.1 Cleaning the Print Head

If print quality degrades or lines appear smudged, the print head may require cleaning. Gently wipe the print head with an alcohol wipe. Ensure the printer is off and cooled down before cleaning.

### 5.2 Storage

Store the printer in a cool, dry place away from direct sunlight, high humidity, and excessive dust. Avoid extreme temperatures.

### 5.3 Safety Precautions

- Do not charge or operate the printer in hot, humid, or dusty environments.
- Always use a 5V/2A power adapter for charging.
- After printing, avoid touching the print head directly as it may be hot and cause burns.
- Insert and remove the charging cable carefully to prevent damage to the interface.

## 6. TROUBLESHOOTING

---

### Common Issues and Solutions

- **No device found when adding to the app:**  
A: Ensure the printer is powered on and its indicator light is active. Verify that your mobile device's Bluetooth is enabled and functioning correctly. Exclude other Bluetooth devices that might interfere with the connection.
- **Printer cannot print:**  
A: Confirm your mobile device's Bluetooth is on and that no other devices are connected to the printer. Check if thermal paper is jammed. If so, refer to the paper jam instructions.
- **Print head overheating:**  
A: If the print head becomes excessively hot, wait for it to cool down before attempting further printing.
- **Printout is blank or has no content:**  
A: This may be due to incorrect installation of the thermal paper or print head. Ensure the paper is loaded correctly and the print head is properly seated.
- **Printed text is faded:**  
A: Check the printer's battery level; low power can affect print quality. Clean the print head if there

are smudges, using an alcohol wipe.

## 7. SPECIFICATIONS

---

Feature	Specification
Product Name	A4 Portable Printer
Product Model	Bewinner6s1nywm8k0
Net Product Weight	475g (1.05 lbs)
Product Dimensions	265mm x 58mm x 30mm (10.43 x 2.28 x 1.18 inches)
Print Type	Thermal Printing
Print Resolution	200dpi
Input Voltage	DC 5V/2A
Battery Capacity	1000mAh
Automatic Shutdown	30 minutes of inactivity
Standby Time	Approximately 90 days
Charging Time	Approximately 1.5 hours
Continuous Printing	Approximately 90 sheets of A4 thermal paper
Paper Width Specification	210mm or 218mm (A4 width)
Charging Interface	Type-C
Connectivity Technology	Bluetooth 4.0, USB 3.0
Compatible Devices	PC, Smartphones (Android, iOS)

## 8. WARRANTY AND SUPPORT

---

This Bewinner product is manufactured under quality control standards. For warranty information or technical support, please refer to the documentation included with your purchase or contact Bewinner customer service. Keep your purchase receipt as proof of purchase.