

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [OXO](#) /
- › [OXO Good Grips Toilet Brush with Rim-Cleaner Replacement Head Refill Instruction Manual](#)

OXO 12256800

OXO Good Grips Toilet Brush with Rim-Cleaner Replacement Head Refill Instruction Manual

Model: 12256800

INTRODUCTION

This manual provides detailed instructions for the installation, use, and maintenance of your OXO Good Grips Toilet Brush with Rim-Cleaner Replacement Head Refill. This product is designed to extend the life of your existing OXO Good Grips Toilet Brush, offering effective cleaning for both the bowl and under the rim.



Image: Two OXO Good Grips Toilet Brush Replacement Heads, showing the white bristles and blue rim-cleaner bristles.

SETUP AND INSTALLATION

To replace the brush head on your OXO Good Grips Toilet Brush, follow these steps:

1. **Remove the old brush head:** Grasp the handle of your OXO Good Grips Toilet Brush firmly. Twist the old brush head counter-clockwise until it detaches from the handle. Dispose of the old head responsibly.
2. **Prepare the new brush head:** Unpack the new OXO Good Grips Toilet Brush Replacement Head.
3. **Attach the new brush head:** Align the threaded base of the new replacement head with the end of the toilet brush handle. Twist the new head clockwise until it is securely fastened. Ensure it is tightened sufficiently to prevent detachment during use.

**Extends the
life of your
Toilet Brush**




Image: An OXO Toilet Brush handle with a new replacement head securely attached, demonstrating how the head extends the life of the brush.

OPERATING INSTRUCTIONS

The OXO Good Grips Toilet Brush with Rim-Cleaner Replacement Head is designed for efficient and thorough cleaning of your toilet bowl.

- **General Cleaning:** Use the main white bristles to scrub the interior surfaces of the toilet bowl. The tapered head design allows for deep reach into the bowl.
- **Rim Cleaning:** Utilize the angled blue bristles specifically designed to clean under the toilet rim, targeting hard-to-reach areas where grime can accumulate.

- **Bristle Configuration:** The brush's bristle configuration is effective even with low-flush toilets, ensuring comprehensive cleaning.

Tapered head reaches deep into bowls



Image: A close-up view of the OXO toilet brush head, highlighting its tapered design for reaching deep into the toilet bowl.

Angled bristles target toilet rims



Image: The OXO toilet brush with its angled blue bristles positioned to clean effectively under the toilet rim.

MAINTENANCE

Proper maintenance will ensure the longevity and effectiveness of your replacement brush head:

- **Rinsing:** After each use, rinse the brush head thoroughly with clean water to remove any debris or cleaning solution residue.
- **Drying:** Allow the brush head to air dry completely before storing it in its holder. This helps prevent bacterial growth and maintains bristle integrity.
- **Replacement:** Replace the brush head when bristles show signs of wear, such as fraying, bending, or reduced cleaning effectiveness. The frequency of replacement depends on usage.



Image: A detailed view of the brush head's base, illustrating how replacing only the head reduces plastic waste.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Brush head detaches during use.	Brush head not securely tightened.	Ensure the replacement head is twisted clockwise until it is firmly secured to the handle. Apply adequate force to prevent loosening.
Reduced cleaning effectiveness.	Bristles are worn or damaged.	It is time to replace the brush head with a new one.
Unpleasant odor from brush.	Insufficient rinsing or drying after use.	Rinse the brush head thoroughly after each use and allow it to air dry completely before storing. Consider using a disinfectant spray on the bristles periodically.

SPECIFICATIONS

Brand: OXO

Model Number: 12256800

Color: White (Bristles), Blue (Rim Cleaner Bristles)

Material: Plastic

Item Weight: 7 ounces (approximate, for pack of 2)

Product Dimensions: 3.5 x 4.9 x 7.5 inches (approximate, per head)

Included Components: Replacement Brush Heads (Pack of 2)

Surface Recommendation: Ceramic

Item Firmness Description: Medium




Image: Diagram showing the dimensions of the OXO toilet brush replacement head: 7.5 inches (19.0 cm) in height and 4.9 inches (12.4 cm) in width.

WARRANTY AND SUPPORT

OXO products are designed for durability and performance. While specific warranty details for replacement parts may vary, OXO stands behind its products. For any questions, concerns, or support regarding your

OXO Good Grips Toilet Brush Replacement Head, please contact OXO Customer Service.

You can typically find contact information on the official OXO website or through the retailer where the product was purchased. Please have your model number (12256800) and purchase details ready when contacting support.

Note: OXO is proud to partner with 1% for the Planet, committing 1% of annual sales to support environmental nonprofits.



Image: The OXO logo alongside the "1% for the Planet" logo, indicating OXO's commitment to environmental support.

© 2024 OXO. All rights reserved.
For more information, visit www.oxo.com