

[Manuals.plus](#) /

› [Sector No Limits](#) /

› Sector No Limits Men's Chronograph Analog Watch, Collection 450 - R3273776008

Sector No Limits R3273776008

Sector No Limits Collection 450 Men's Chronograph Analog Watch

Model: R3273776008

1. PRODUCT OVERVIEW

The Sector No Limits Collection 450 watch, model R3273776008, is a men's analog chronograph timepiece. It features a robust stainless steel case and bracelet, a quartz movement, and a black dial protected by mineral glass. Designed for durability, it offers water resistance up to 10 ATM (100 meters). The watch includes a chronograph function for precise time measurement and a secure deployant clasp with a safety lock.





Figure 1: Front view of the Sector No Limits Collection 450 watch.

Key Features:

- **Movement:** Quartz analog movement with chronograph function.
- **Case:** 43.00 mm diameter stainless steel case, 11.50 mm thickness.
- **Dial:** Black dial with mineral glass protection.
- **Bracelet:** Stainless steel bracelet with a deployant clasp and safety lock.
- **Water Resistance:** 10 ATM (100 meters).

2. SETUP AND INITIAL USE

2.1 Setting the Time and Date

1. **Pull out the crown:** Gently pull the crown (located on the right side of the watch case) to position 2 for date adjustment, or position 3 for time adjustment.



Figure 2: Side view illustrating the crown and pushers.

2. **Adjust the date (if applicable):** In position 2, turn the crown clockwise or counter-clockwise to set the correct date. Avoid setting the date between 9 PM and 3 AM to prevent damage to the movement.
3. **Adjust the time:** In position 3, turn the crown to set the hour and minute hands. Ensure the AM/PM is correctly set if your watch has a 24-hour indicator or date function (the date changes at midnight).
4. **Push in the crown:** Once set, push the crown back into position 1 (normal operating position) to start the watch and ensure water resistance.

2.2 Adjusting the Bracelet

The stainless steel bracelet can be adjusted by removing or adding links to achieve a comfortable fit. This procedure typically requires specialized tools and is best performed by a qualified watchmaker or jeweler to avoid damaging the bracelet or clasp.



Figure 3: Detail of the deployant clasp.

3. OPERATING THE CHRONOGRAPH

Your watch is equipped with a chronograph function, allowing you to measure elapsed time independently of the main time display.

1. **Start:** Press the upper pusher (button A) to start the chronograph. The chronograph second hand and minute counter will begin to move.
2. **Stop:** Press the upper pusher (button A) again to stop the chronograph. The elapsed time will be indicated by the chronograph hands.
3. **Reset:** After stopping the chronograph, press the lower pusher (button B) to reset all chronograph hands to their zero positions.
4. **Split Time (if applicable):** Some chronographs allow for split time measurement. Consult a detailed movement manual if this feature is desired.

4. MAINTENANCE AND CARE

4.1 Cleaning

To maintain the appearance of your watch, regularly wipe the case and bracelet with a soft, dry cloth. For stainless steel, a slightly damp cloth can be used, followed by immediate drying. Avoid using harsh chemicals or abrasive materials.

4.2 Water Resistance

This watch is water resistant up to 10 ATM (100 meters). This rating means it is suitable for swimming, snorkeling, and showering. However, it is not recommended for diving. Always ensure the crown is fully pushed in before exposing the watch to water. Avoid operating the pushers or crown while the watch is wet or submerged. Water resistance is not a permanent condition and may decrease over time due to wear and tear or impacts. It is recommended to have the water resistance checked periodically by an authorized service center.

4.3 Battery Replacement

As a quartz watch, it is powered by a battery. When the battery runs low, the second hand may start to jump every few seconds (End-of-Life indicator). Battery replacement should only be performed by an authorized service center to ensure proper sealing and maintain water resistance.

4.4 Storage

When not wearing your watch, store it in a cool, dry place, away from direct sunlight, extreme temperatures, and strong magnetic fields.

5. TROUBLESHOOTING

- **Watch not running:**
 - Check if the crown is fully pushed in.
 - The battery may need replacement. Contact an authorized service center.
- **Time is incorrect:**
 - Reset the time as described in Section 2.1.
 - If the issue persists, the movement may require inspection by a professional.
- **Chronograph hands do not reset to zero:**

- This may indicate a need for calibration or service. Consult an authorized service center.

6. SPECIFICATIONS

Model Number	R3273776008
Brand	Sector No Limits
Movement Type	Quartz
Display Type	Analog
Case Material	Stainless Steel
Case Diameter	43 mm
Case Thickness	11.50 mm
Band Material	Stainless Steel
Band Width	2.2 cm
Crystal Material	Mineral Glass
Water Resistance	10 ATM (100 Meters)
Special Features	Chronograph
Clasp Type	Deployant Clasp with Safety Lock

7. WARRANTY AND SUPPORT

7.1 Manufacturer's Warranty

This Sector No Limits watch is covered by a **3-year manufacturer's warranty** from the date of purchase. The warranty covers manufacturing defects and material flaws under normal use. It does not cover damage resulting from improper use, accidents, unauthorized repairs, or normal wear and tear (e.g., battery, crystal, strap). Please retain your proof of purchase and the original warranty certificate.



Figure 4: Original packaging, including warranty certificate.

7.2 Customer Support

For warranty claims, service, or technical assistance, please contact an authorized Sector No Limits service center. Refer to the official Sector No Limits website or the documentation included with your watch for contact information and a list of authorized service providers.