

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [SKMEI](#) /
- › [SKMEI Model 9318 Men's Quartz Stopwatch Watch User Manual](#)

SKMEI 9318

SKMEI Model 9318 Men's Quartz Stopwatch Watch User Manual

Your guide to setting up, operating, and maintaining your timepiece.

INTRODUCTION

Thank you for choosing the SKMEI Model 9318 Quartz Stopwatch Watch. This watch combines classic analog design with practical stopwatch functionality and a 24-hour display. Designed for durability and style, this manual will guide you through its features and ensure proper use and care.



Image: A detailed view of the SKMEI Model 9318 watch, showcasing its beige dial, black leather strap, and the arrangement of its sub-dials and pushers.

WATCH COMPONENTS


Familiarize yourself with the key components of your SKMEI 9318 watch:



Watch Case



Watch Dial



Watch Band



Watch mirror



Watch Clasp



Back cover

Image: A visual breakdown of the watch components, including the watch case, dial, band, mirror, clasp, and back cover, aiding in identification.

- **Crown:** Used for setting time and date.
- **Pushers (A & B):** Used for operating the stopwatch function.
- **Main Dial:** Displays hours, minutes, and seconds.
- **Sub-dials:** Include stopwatch minute counter, stopwatch second counter, and a 24-hour indicator.
- **Strap:** Genuine leather strap with a buckle clasp.

SETUP INSTRUCTIONS

1. Setting the Time

1. Pull the crown out to position 2 (the outermost position).
2. Rotate the crown to move the hour and minute hands until the desired time is displayed. Ensure the 24-hour sub-dial aligns correctly for AM/PM.
3. Once the time is set, push the crown back into position 0 (normal operating position).

2. Setting the Date

1. Pull the crown out to position 1 (the first click).

2. Rotate the crown to adjust the date.
3. Once the date is set, push the crown back into position 0.

Note: Avoid setting the date between 9:00 PM and 3:00 AM, as this may interfere with the automatic date change mechanism. If you need to set the date during this period, first set the time outside this range, adjust the date, then reset the time.

3. Adjusting the Strap

The genuine leather strap features a standard buckle clasp. Adjust the strap by selecting the appropriate hole for a comfortable and secure fit on your wrist.

OPERATING INSTRUCTIONS

Using the Stopwatch Function

Your SKMEI 9318 watch is equipped with a stopwatch function for measuring elapsed time.

1. **Start:** Press pusher A (top right button) to start the stopwatch. The stopwatch second hand and minute sub-dial will begin to move.
2. **Stop:** Press pusher A again to stop the stopwatch. The elapsed time will be displayed on the sub-dials.
3. **Reset:** After stopping the stopwatch, press pusher B (bottom right button) to reset all stopwatch hands back to their zero positions.

Understanding the 24-Hour Sub-dial

The 24-hour sub-dial operates in conjunction with the main hour hand, indicating whether the main time display is AM or PM. It cannot be set independently and automatically synchronizes with the 12-hour time setting.

MAINTENANCE AND CARE

- **Water Resistance (30 Meters / 3 ATM):** This watch is designed to withstand splashes, rain, and brief immersion in water. It is **not** suitable for swimming, diving, or showering. Avoid pressing buttons or operating the crown when the watch is wet.
- **Cleaning:** Wipe the watch case and crystal with a soft, dry cloth. For the leather strap, use a slightly damp cloth and mild soap if necessary, then dry thoroughly. Avoid harsh chemicals.
- **Battery Replacement:** The watch is powered by a quartz movement and requires a battery. When the watch stops or runs erratically, it may be time for a battery replacement. It is recommended to have the battery replaced by a qualified watch technician to ensure proper sealing and water resistance.
- **Temperature:** Avoid exposing the watch to extreme temperatures (hot or cold) or sudden temperature changes, as this can affect its accuracy and lifespan.
- **Magnetic Fields:** Keep the watch away from strong magnetic fields, which can interfere with the quartz movement.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Watch not running	Crown is pulled out; battery is depleted.	Push crown back to position 0; replace battery (professional service recommended).
Time/Date is incorrect	Time/Date not set correctly; accidental crown movement.	Refer to "Setup Instructions" to reset time and date.
Stopwatch not functioning or resetting	Incorrect operation; internal mechanism issue.	Ensure correct pusher sequence (Start A, Stop A, Reset B); if problem persists, seek professional repair.
Condensation inside watch	Exposure to extreme temperature changes or water ingress.	Seek professional service immediately to prevent damage.

SPECIFICATIONS

Key specifications for the SKMEI Model 9318 watch:



52.6mm

44mm

PRODUCT PARAMETER

- BRAND: SKMEI
- MODEL: 9318
- WEIGHT: 64.6g
- MOV'T: Quartz
- CRYSTAL: Glass
- CASE: Zinc alloy
- BAND: Leather
- BUCKLE: Stainless steel
- W/P: 30m
- FUNCTION: Time, Date, Stopwatch



Case width: 44mm



Case thickness: 13mm



Band Width: 20mm



Watch length: 255mm

Image: A graphic detailing the product parameters of the SKMEI 9318 watch, including dimensions and material

specifications.

- **Brand:** SKMEI
- **Model Number:** 9318
- **Movement Type:** Quartz
- **Display Type:** Analog
- **Case Material:** Zinc Alloy
- **Crystal Material:** Glass
- **Band Material:** Genuine Leather
- **Clasp Type:** Buckle
- **Case Diameter:** 44 Millimetres
- **Case Thickness:** 13 Millimetres
- **Band Width:** 20 Millimetres
- **Band Length:** 255 Millimetres
- **Item Weight:** 64.6 Grams
- **Water Resistance Depth:** 30 Metres (3 ATM)
- **Functions:** Time, Date, Stopwatch, 24-hour display

WARRANTY AND SUPPORT

Your SKMEI Model 9318 watch comes with a limited manufacturer warranty.

- **Warranty Period:** Enjoy peace of mind with a 9-month Manufacturer Warranty from the date of purchase.
- **Service Inquiries:** For any service-related inquiries or feedback, please contact the Skmei India Helpline at **1800-889-6251**.
- **Operating Hours:** Monday to Saturday, 9:00 AM to 6:00 PM.

Please retain your proof of purchase for warranty claims.