Dyson TP10

Dyson Purifier Cool™ Gen1 TP10 - Instruction Manual

Model: TP10 | Brand: Dyson

Product Overview

The Dyson Purifier Cool™ Gen1 purifying fan automatically senses, captures and traps pollutants to purify your whole room, while removing 99.97% of particles as small as 0.3 microns. It features Air Multiplier technology for whole-room air projection and purification coverage. The unit is fully sealed to HEPA Standard, ensuring that captured pollutants remain inside.

- Air Multiplier technology circulates purified air throughout the whole room.
- Curved and magnetized remote control stores neatly on the machine. Not app compatible.
- Oscillates up to 350°.
- Programmed to turn off after pre-set intervals of 1, 2, 4 and 8 hours.
- Fully sealed to HEPA Standard. So what goes inside, stays inside.
- Night mode monitors and purifies using the quietest settings, with a dimmed display.





Image: Dyson Purifier Cool™ Gen1 TP10 unit with its remote control.

Setup

Unboxing and Assembly

Your Dyson Purifier Cool™ Gen1 TP10 comes with the main purifier unit, a 360 Combi: Glass HEPA + Carbon Air Purifier Filter, a power cord, and a remote control. Minimal assembly is required to get your device operational.

1. Carefully remove all components from the packaging.

2. Locate the filter. The filter is designed for easy installation.
3. Align the filter with the base of the purifier and secure it according to the markings.
4. Place the purifier on a stable, level surface, ensuring adequate clearance around the unit for optimal airflow.
5. Connect the power cord to the unit and then to a wall outlet.



Image: Components included in the box: Dyson Purifier Cool™ Gen1 TP10, remote control, and 360 Combi: Glass HEPA + Carbon Air Purifier Filter.

Operating Instructions

Remote Control Functions

The Dyson Purifier Cool™ Gen1 TP10 is controlled via a curved and magnetized remote control that conveniently stores on top of the unit. The remote allows for comprehensive control over the device's functions.



Image: Detailed view of the remote control with labeled buttons for Power, 10 fan speeds, Auto mode, Night mode, Oscillation (0-350°), and Pollution details/filter life/maintenance information.

- **Power Button:** Turns the unit on or off.
- **Fan Speed Control (+/-):** Adjusts the fan speed from 1 to 10.
- **Auto Mode:** Automatically senses and reacts to air quality changes, adjusting purification and airflow as needed.
- **Night Mode:** Operates with the quietest settings and a dimmed display for undisturbed sleep.
- **Oscillation Control:** Adjusts the oscillation angle up to 350° to project purified air around the whole room.
- **Information Button (i):** Displays pollution details, filter life, and maintenance alerts on the unit's LCD screen.

Sensing and Reporting

Integrated sensors continuously analyze and diagnose airborne pollutants in real-time, displaying results on the LCD screen. This allows you to monitor the air quality in your environment.



Image: Internal view of the Dyson Purifier Cool™ Gen1 TP10 highlighting the integrated sensors that analyze and diagnose airborne pollutants.

The device is designed to capture various common household pollutants, including:

- Common allergens: Pet dander, pollen, and dust (PM10).
- Industrial emissions (PM2.5).
- Ultrafine particles (PM0.1).
- Formaldehyde (HCHO) from carpets, rugs, and flooring.
- Odors from household fumes and cooking.
- Nitrogen dioxide from gas stoves and car exhaust.
- Benzene and VOCs from cleaning products and candles.

Maintenance

Filter Care

The filter in your Dyson Purifier Cool™ Gen1 TP10 is quick and easy to change. The device provides automatic filter-life notifications on the LCD screen, indicating when a replacement is needed. Regular filter replacement ensures optimal purification performance.



Image: Hands demonstrating the easy process of replacing the filter in the Dyson Purifier Cool™ Gen1 TP10.

Troubleshooting

If you encounter any issues with your Dyson Purifier Cool™ Gen1 TP10, please refer to the following common troubleshooting steps:

- **No Power:** Ensure the power cord is securely plugged into both the unit and a working wall outlet. Check the circuit breaker if necessary.
- **Poor Airflow:** Verify that the filter is correctly installed and not clogged. Clean any dust or debris from the exterior vents.
- **Unusual Noise:** Check for any obstructions in the air intake or outlet. Ensure the unit is on a stable, level surface.
- **Filter Life Indicator:** If the filter indicator light is on, it's time to replace the filter. Follow the maintenance

instructions.

- **Remote Control Not Working:** Ensure there are no obstructions between the remote and the unit. Check and replace the remote control batteries if needed.

For further assistance, please contact Dyson customer support or visit the official Dyson website.

Specifications

Feature	Detail
Brand	Dyson
Model	TP10 (664609-01)
Color	White
Product Dimensions	8.66"D x 8.66"W x 41.34"H
Item Weight	10.43 pounds
Floor Area Coverage	101 Square Feet
Controller Type	Remote Control
Included Components	TP10 Purifier, Filter, Cord, Remote
UPC	885609031262

Warranty and Support

Dyson products typically come with a manufacturer's warranty covering defects in materials and workmanship. For specific warranty details, including duration and coverage, please refer to the warranty card included with your product or visit the official Dyson website.
For customer support, product registration, or to purchase replacement filters and accessories, please visit the Dyson Store on Amazon or the official Dyson website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

How do I reset?

To address issues with your Dyson Purifier Cool Gen1 TP10, including failure to oscillate, please follow these steps:1. Troubleshooting OscillationCheck the Remote: Press the Oscillation Control button on your remote to ensure the feature...

Read full answer