



[Manuals.plus](#) /

› [E-Greetshopping](#) /

› E-Greetshopping B39 Bluetooth Over-Ear Headphones User Manual

E-Greetshopping B39

E-Greetshopping B39 Bluetooth Over-Ear Headphones

USER MANUAL

Introduction



Image: E-Greetshopping B39 Bluetooth Over-Ear Headphones in yellow.

Thank you for choosing the E-Greetshopping B39 Bluetooth Over-Ear Headphones. This manual provides essential information for setting up, operating, and maintaining your headphones. Please read it carefully to ensure optimal performance and longevity of your device.

Product Features

- **Colorful LED Light Design:** LED lights on both sides of the headphones change with the rhythm of music, enhancing your listening experience.
- **Superb Sound Quality:** Built-in premium speakers deliver clear audio with superior bass depth and high-definition clarity.
- **Dual Connectivity Modes:** Supports both wireless Bluetooth 5.0 and wired 3.5mm audio cable connections.
- **Hands-Free Calling:** Integrated high-quality microphone for clear hands-free phone calls.
- **Foldable & Ergonomic Design:** Space-saving foldable structure and adjustable headband with ultra-soft ear cups

for comfortable, long-lasting wear.

- **TF Card Support:** Play music directly from a TF card (up to 32GB) for standalone playback.



Image: Details of the ergonomic and scalable design with comfortable earcups.




Image: The foldable design of the headphones for easy portability and storage.

Package Contents

The package includes the following items:

- 1 x E-Greetshopping B39 Bluetooth Over-Ear Headphones
- 1 x Audio Cable (3.5mm)
- 1 x USB Charging Cable (Micro USB)

Controls and Functions



Turn on/off
Mode switching



play/pause
Answer/hang up the phone



Short press the previous song
Long press to increase volume



Single press one song
Long press to decrease volume

Image: Close-up view of the right earcup showing control buttons and ports.

Button/Port	Function
Power Button (On/Off) / Mode Switching	Long press to turn headphones on/off. Short press to switch between Bluetooth, TF Card, and FM Radio modes (if applicable).
Play/Pause / Answer/Hang Up Call	Short press to play/pause music. Short press to answer an incoming call or hang up an active call.
Previous Song / Volume Up	Short press for previous song. Long press to increase volume.
Next Song / Volume Down	Short press for next song. Long press to decrease volume.
Micro USB Port	For charging the headphones.
3.5mm Audio Jack	For wired connection using the included audio cable.

Button/Port	Function
TF Card Slot	Insert a TF card (MicroSD) for direct music playback.

Setup

1. Bluetooth Pairing

1. Ensure the headphones are charged.
2. Long press the Power button to turn on the headphones. The LED indicator will flash, indicating pairing mode.
3. On your device (smartphone, tablet, PC), enable Bluetooth and search for available devices.
4. Select "B39" from the list of devices.
5. Once connected, the LED indicator will stop flashing or change to a steady light (refer to LED light behavior for specifics).

2. Wired Connection

To use the headphones in wired mode:

1. Connect one end of the included 3.5mm audio cable to the 3.5mm audio jack on the headphones.
2. Connect the other end of the audio cable to the audio output port of your device.
3. The headphones will automatically switch to wired mode. Note that some functions like LED lights or built-in microphone might be limited in wired mode depending on the device.

3. TF Card Playback

To play music directly from a TF card:

1. Insert a TF (MicroSD) card with music files into the TF card slot on the headphones.
2. Turn on the headphones. If not already in TF card mode, short press the Power button to cycle through modes until TF card playback begins.

Operating Instructions

Music Playback

- **Play/Pause:** Short press the Play/Pause button.
- **Next Song:** Short press the "Next Song" button.
- **Previous Song:** Short press the "Previous Song" button.
- **Volume Up:** Long press the "Volume Up" button.
- **Volume Down:** Long press the "Volume Down" button.

Call Management

- **Answer/End Call:** Short press the Play/Pause button when a call comes in or during a call.
- **Reject Call:** Long press the Play/Pause button when a call comes in.

LED Lights



Image: E-Greetshopping B39 headphones featuring dynamic LED lighting.

The LED lights on the earcups are designed to sync with the rhythm of your music. Specific controls for changing LED patterns or turning them off are not detailed in the product information. They are generally activated automatically when the headphones are powered on and playing music.

Charging

To charge your E-Greetshopping B39 headphones:

- Connect the Micro USB charging cable to the Micro USB port on the headphones.

- Connect the other end of the USB cable to a 5V/1A USB power adapter or a computer's USB port.
- The LED indicator will typically show a red light during charging and turn off or change color when fully charged.

Maintenance and Care

- Keep the headphones dry. Do not expose them to water or moisture.
- Clean the earcups and headband with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.
- Store the headphones in a cool, dry place when not in use. The foldable design allows for compact storage.
- Avoid extreme temperatures.
- Do not attempt to disassemble or modify the headphones, as this will void any potential warranty.

Troubleshooting

Problem	Solution
Headphones do not turn on.	Ensure the headphones are fully charged. Connect them to a power source using the USB cable.
Cannot pair via Bluetooth.	<ul style="list-style-type: none"> ◦ Ensure headphones are in pairing mode (LED flashing). ◦ Make sure Bluetooth is enabled on your device. ◦ Move headphones closer to your device (within 10 meters). ◦ Forget "B39" from your device's Bluetooth list and try pairing again. ◦ Restart both the headphones and your device.
No sound in Bluetooth mode.	<ul style="list-style-type: none"> ◦ Check if the headphones are successfully paired and connected. ◦ Adjust the volume on both the headphones and your connected device. ◦ Ensure the correct audio output is selected on your device.
No sound in wired mode.	<ul style="list-style-type: none"> ◦ Ensure the 3.5mm audio cable is securely connected to both the headphones and your device. ◦ Test with a different audio cable if available. ◦ Check the volume on your device.
LED lights are not working or not syncing.	<ul style="list-style-type: none"> ◦ Ensure the headphones are powered on and playing audio. ◦ The lights are designed to sync with music rhythm; ensure music is playing.

Specifications

Ergonomic design

Automatic fitting and fine adjustment design

No need to worry about the collet when wearing it

Comfortable earmuffs



Noise reduction

Long lasting without pain



Image: Audio frequency response curve illustrating sound performance.

Feature	Detail
Model	B39
Color Options	Yellow, Green, Blue, Pink
Dimensions (L x W x H)	175 x 165 x 68 mm (6.89 x 6.50 x 2.68 inches)
Material	ABS plastic
Bluetooth Version	5.0
Wireless Range	Up to 10 meters (33 feet)
Impedance	32 Ohm

Feature	Detail
Sensitivity	96 dB +/- 3 dB
TF Card Support	Up to 32 GB
Charging Port	Micro USB
Charging Voltage/Current	5V/1A
Connectivity Technology	Wireless (Bluetooth), Wired (3.5mm)
Control Type	Media Control, Touch
Noise Control	Sound Isolation

Safety Information

- Do not use the headphones at high volume for extended periods to prevent hearing damage.
- Do not use the headphones while driving, cycling, or in situations where you need to hear ambient sounds.
- Keep out of reach of children.
- Dispose of the product responsibly according to local regulations.

Warranty and Support

E-Greetshopping is committed to providing a worry-free shopping experience. If you encounter any issues or have questions about your B39 Bluetooth Over-Ear Headphones, please contact our customer service team. You can typically find contact information through your order details or by reaching out to the seller directly. We aim to respond to inquiries within 24 hours.

